



6C5

MP MASTER



MA20606



Digitized by the Internet Archive
in 2026

https://archive.org/details/manualsplus_11899



ROHDE & SCHWARZ

Measuring Instruments
and Systems Division

MICROFICHED
INSTRUMENT SHG
3-5-98
dep

Operating Manual

SPECTRUM ANALYZER

FSB

848.0020.52

Printed in the Federal
Republic of Germany

	Page
1 Specifications	
Data Sheet	
2 Operation	2.1
2.1 Explanation of Operating Controls	2.1
2.1.1 Front Panel of Display Unit	2.1
2.1.2 Front Panel of RF Unit	2.3
2.1.3 Rear Panel of Display Unit	2.7
2.1.4 Rear Panel of RF Unit	2.9
2.2 Preparation for Use	2.12
2.2.1 Fitting the Instrument Handles	2.12
2.2.2 Adjustment of Power Supply/Fuse Replacement	2.12
2.2.3 Mechanical Connection of the two Units	2.12
2.2.4 Electrical Connection of the two Units	2.12
2.2.5 Installation in 19-inch Rack	2.13
2.3 Manual Operation	2.14
2.3.1 Switching On and Subsequent Response of Instrument	2.14
2.3.2 General Operation Concept	2.14
2.3.3 Explanation of Terms	2.15
2.3.4 Menu Operation Structure	2.15
2.3.4.1 Schematic Representation of Hierarchy	2.16
2.3.4.2 Schematic Representation of Menu Operation	2.16
2.3.4.3 Width Control of a Menu	2.17
2.3.4.4 Possible Status of Softkeys	2.17
2.3.4.5 Data Input/Data Variation	2.17
2.3.4.6 Changing the Softkey Labelling Using an External Keyboard	2.19
2.3.5 MODE	2.20
2.3.6 ANALYZER	2.21
2.3.6.1 Theory of Operation	2.21
2.3.6.2 Explanation of Screen Inscriptions	2.25
2.3.6.3 PRESET	2.26
2.3.6.4 Explanation of Hardkey Functions and Menus	2.27
2.3.7 RECEIVER	2.67
2.3.7.1 Theory of Operation	2.67
2.3.7.2 RECEIVER Menu	2.68
2.3.8 SETUP	2.75
2.3.8.1 Theory of Operation	2.75
2.3.8.2 SETUP Menu	2.75

	Page
2.4 Remote Control of Instrument	2.77
2.4.1 IEC Bus	2.77
2.4.1.1 Setting the Device Address	2.78
2.4.1.2 Local/Remote Switchover	2.78
2.4.1.3 Interface Messages	2.79
2.4.1.3.1 Universal Commands	2.79
2.4.1.3.2 Addressed Commands	2.79
2.4.1.4 Device Messages	2.81
2.4.1.4.1 Commands Received by the Analyzer in Listener Mode (Controller to Device Messages)	2.81
2.4.1.4.2 Messages Sent by the Analyzer in Talker Mode (Device to Controller Messages)	2.83
2.4.1.4.3 Device-independent Commands (Common Commands)	2.84
2.4.1.4.4 Device-specific Commands	2.88
2.4.1.5 Service Request and Status Register	2.104
2.4.1.6 Resetting of Device Functions	2.109
2.4.1.7 Command Processing Sequence and Synchronization	2.110
2.4.1.8 Error Handling	2.110
2.4.1.9 Programming Examples	2.111
2.4.1.10 Trace Record	2.121
2.5 Interfaces	2.133
2.5.1 IEC Bus Interface	2.133
2.5.1.1 Interface Characteristics	2.133
2.5.1.2 Pin Assignment and Signal Designations	2.133
2.5.2 Parallel Printer Interface (Centronics)	2.134
2.5.2.1 Interface Characteristics	2.134
2.5.2.2 Pin Assignment and Signal Designations	2.134
2.5.2.3 Signal Timing Sequence	2.134
2.5.3 Serial Interface	2.135
2.5.3.1 Interface Characteristics	2.135
2.5.3.2 Interface Data	2.135
2.5.3.3 Pin Assignment and Signal Designations	2.135
2.5.4 External Floppy Interface	2.136
2.5.4.1 Pin Assignment and Signal Description	2.136
2.5.5 External Video Interface	2.137
2.5.5.1 Interface Description	2.137
2.5.5.2 Signal Timing Sequence	2.137
2.5.6 Keyboard Interface	2.139
2.5.6.1 Interface Characteristics	2.139
2.5.6.2 Connector	2.139
2.5.6.3 Signal Timing Sequence	2.139
2.5.7 USER PORT	2.140
2.5.7.1 Interface Characteristics	2.140
2.5.7.2 Pin Assignment and Signal Designations	2.140
2.5.7.3 Electrical Characteristics	2.140
2.5.8 PROBE CODE	2.141
2.5.8.1 Interface Characteristics	2.141
2.5.8.2 Pin Assignment and Signal Designations	2.141
2.6 Index	2.142

2 Operation

(see Figs. 2-1 and 2-2 in Appendix)

The bold-faced, italic numbers refer to the item numbers in Figs. 2-1 and 2-2. The values in this section are not guaranteed; only the specifications of the data sheet are binding.

2.1 Explanation of Operating Controls

2.1.1 Front Panel of Display Unit

1


Colour monitor for displaying results.

Caution!

(For physical reasons, the instrument is sensitive to magnetic fields and also generates electric and magnetic fields itself).

2


SCREEN



Selection of menu for setting up of monitor **1**.

3


MODE



Selection of menu for operating mode.

4

DISPLAY



Selection of menu for formatting of display.

5

SPECIAL FUNCTIONS



Selection of menu for special functions.




One or more special functions switched on.



No special function active.

6


DISPLAY LINE



Selection of menu for superimposing (measurement) lines on screen.

7

PLOT



Selection of menu for documentation.

8


HELP



Selection of menu for operator support.

9

SWEEP



Selection of menu for operator support.




Sweep active.



Sweep not active.
Reset phase.

10

TRIGGER



Selection of menu for setting sweep trigger.

11

TRACE



Selection of menu for defining mode of video memory.

12

MULTI MARKER



Selection of menu for max. 8 level markers.

13


MARKER



Selection of menu for reference and delta marker.

14

AUTO



Selection of menu for various automatic functions.




Automatic system of corresponding function on.



Automatic system of corresponding function not in operation.

15

COUPLED FUNCTIONS



Selection of menu for automatic coupling of span, resolution bandwidth, video bandwidth and sweep time.



Selected parameter is coupled to the other parameters.



Parameter is not incorporated in coupling.
(manual control).

2.1.2 Front Panel of RF Unit

16


PHONES



Headphones connection. This is only active if the frequency span is zero (receiver mode).

25

LOCAL



Switches back from IEC-bus control to manual operation.

22



8 selection keys for menu control. Function depends on selected menu.



REMOTE


Instrument is controlled by an external controller.



SRQ

Instrument is sending a Service Request.

23



Centre key: enables return to next higher menu level.

Left and right keys: extension of selection range of menu when more than 8 menu functions are available.



Further menu functions can be selected in the corresponding direction.



Menu level is empty in the corresponding direction.

24


KEYBOARD



Socket for external keyboard. Connected in parallel to socket 60 on rear panel.

26

FREQUENCY



Selection of frequency menu.

27

SPAN



Selection of span menu.

28

BACK SPACE



Used to correct faulty entries.

Incorrect number keyed in before pressing associated ENTER key **31**:
last number keyed in is cleared.

Incorrect entry of complete sequence terminated by ENTER **31**:
the complete sequence is cleared and the previous value is set again (undo function).

29

SAVE



Selection of save function for settings.



30

RECALL



Selection of stored settings.


31



GHz	s
V	-dBm
MHz	ms
mV	+dBm
kHz	μs
μV	dB
Hz	ns
nV	dB..

Numeric keypad to enter numbers (consisting of 12 numeric keys and 4 ENTER keys).

32



Spinwheel for modifying numeric values. The parameter to be modified must first be selected.

Magnetic latching indicates the step size when rotating; the number of steps per rotation is 24.

33



Rapid variation of data to larger values.


34



Rapid variation of data to smaller values.

35

HOLD




Blocking of data variation by **32**, **33**, **34**.



ENABLED

Data variation enabled.

36



Selection of DC isolation for input 37. Caution when operating without DC isolation: DC voltage can destroy input divider and/or input mixer.

Observe automatic function AC/DC 14.

DC  DC coupling is switched on.

AC  AC coupling is switched on. Not more than 20 V DC may be applied.

37

RF INPUT
MAX +30 dBm



N socket, impedance 50 Ω .

Maximum power:

Normal mode (≥ 10 dB attenuation):

< +30 dBm.

With 0-dB RF attenuation: < +20 dBm.

Caution with broadband signals: connect ahead pulse-insensitive attenuator or pulse limiter.

38

CAL OUTPUT
-20 dBm/100 MHz



BNC socket, 50 Ω .
Level -20 dBm ± 0.2 dB.

Used to check the level calibration or the input divider.

39

PROBE/CODE



12-way Tuchel socket. Used for DC supply and taking into account the characteristics of level and/or frequency converters connected ahead.

40

UNITS



Selection of menu for selection of level unit.

41

LEVEL RANGE



Selection of menu for the displayed level range.

42

REF LEVEL



Selection of menu for the reference level.

43

PRESET



Instrument is reset to a defined status (as when switching on with 46).

44

STANDBY

☐ DISPLAY

☐ RF


The corresponding unit is supplied with AC power.
Condition: ON/OFF key 46 is switched off.

- ☐ The corresponding unit is switched on by means of the ON/OFF key 46 or the AC supply is missing.

CHECK

☐ DISPLAY

☐ RF


Following the activation of the ON/OFF switch 46, a self-test runs for approx. 10 s.

An error is present if one or both of the LEDs lights up at the end of this test period.

45

☐ SELFTEST

☐ CAL


A self-test or a calibration procedure has been triggered.

- ☐ The corresponding process has not been selected or has been successfully terminated.

46

☐ ON


ON/OFF key for internal DC supply.

Check the AC supply before switching on for the first time.



Instrument is switched on.

- ☐ Internal DC voltages are switched off (except the + 12 V supply for the oven-controlled reference oscillator). AC power is still present in the instrument.

2.1.3 Rear Panel of Display Unit

51

EXT SWEEP TRG
 $\pm 5\text{ V}/\pm 20\text{ V}_{\text{MAX}}$



High-impedance BNC input for an external start signal for the frequency sweep.

Nominal level: $\pm 5\text{ V}$.
Maximum level: $\pm 20\text{ V}$.

52

IF OUT
[NARROW]
21.4 MHz



21.4-MHz IF output (narrowband).

53

VIDEO OUTPUT
0... +1 V



BNC output 50 Ω , for IF video signal.

Level 0 V: lower range limit
Level +1 V: upper range limit

54

Label with instrument type, identity No., serial No.

55


DC blower.

The performance of the blower depends on the ambient temperature. If the blower does not run when the instrument is switched on, an error message appears on monitor 1 and the instrument is switched off after approx. 10 min.

56

DC blower inside instrument (power pack).

57



Prerequisite: AC power must be present.



A21, A22:
Power pack A21, A22 operating correctly.



A21, A22:
Voltage on module A21, A22 has failed or is overloaded.




ERROR:

- Error sources:
- Excess temperature
 - DC blower 55 not running
 - Vital module missing in display unit.

The instrument restarts automatically when cooled down following switch-off caused by an excessive temperature.

58




Power switch.

When switched on, AC power is present inside the instrument.

59

100/120 V T4.0 47 ...
220/240 V T2.5 440 Hz



AC power selector and connection. Check the AC supply and the fuse before switching on for the first time.


60

KEYBOARD




Socket for external keyboard. Connected in parallel with socket 24 on front panel.

61



IEC-bus connector.

62



BNC sockets for an external black-and-white monitor, a colour monitor or a hardcopy device. The control signals can be modified in accordance with the external device.

63

ANALYZER BUS X132


Connector for cable to RF unit, item 69.

64

ANALYZER BUS X133

Connector for cable to RF unit, item 82.


65



Connector for control of external components (TTL level).


2.1.4 Rear Panel of RF Unit

66




Similar to Centronics interface. Used to control external printers.

67



RS-232 interface.

68



Connection for up to three floppy disk drives.

69

ANALYZER BUS X132

Connector for cable to display unit, item 63.

70

Label with instrument type, identity No., serial No.

71

DC blower.


The performance of the blower depends on the ambient temperature. If the blower does not run when the instrument is switched on, an error message appears on monitor 1 and the instrument is switched off after approx. 10 min.

72

DC blower inside instrument (power pack).

73

POWER




Power switch.

When switched on, AC power is present inside the instrument.

74

100/120 V T4.0 47...
220/240 V T2.5 440 Hz



AC power selector and connection. Check the AC supply and the fuse before switching on for the first time.

75

☐ A22 ——— SUPPLY CHECK ——— A21 ☐
☐ OVEN ☐ ERROR

Prerequisite: AC power must be present.



A21, A22:
Power pack A21, A22 operating correctly.



A21, A22:
Voltage on module A21, A22 has failed or is overloaded.



ERROR:

Error sources:

- Excess temperature
- DC blower 71 not running

The instrument restarts automatically when cooled down following switch-off caused by an excessive temperature.



OVEN:
Internal reference oscillator is being heated.

76

10 MHz REF 
50 Ω -200 Ω
> 10 dBm 0.5...5 Vpp

BNC socket, 50 Ω.

Optional output for internal reference signal or input for external reference signal.

78

SWEEP ——— STOP
OUTPUT 5 V 

BNC socket, TTL level.

Change in logic level indicates stop of sweep.

79

START ——— SWEEP
OUTPUT 5 V 

BNC socket, TTL level.

Change in logic level indicates start of sweep.

80

SWEEP OUTPUT
0...5 V



BNC socket.

The voltage proportional to the span is:
0 V at start frequency
+ 5 V at stop frequency

81

IF OUTPUT
221.4 MHz



BNC socket, 50 Ω .

Broadband IF output 221.4 MHz.

82

ANALYZER BUS X133

Connector for cable to display unit, item **64**.

2.2 Preparation for Use

2.2.1 Fitting the Instrument Handles

The handles are supplied loose with each unit. The two longer handles must be connected to the left and right of the display unit using the supplied screws, the two shorter handles must be connected to the RF unit.

2.2.2 Adjustment of Power Supply/Fuse Replacement

The units are set in the factory to an AC supply of 220 V. If the local supply varies by more than $\pm 10\%$ from this value, the voltage selector and the fuse on the rear of both units must be changed according to Table 2-1. The AC supply frequency must be between 47 and 440 Hz.

Table 2-1 Selection of fuses

Nominal AC supply voltage	Permissible tolerance	Permissible voltage range	Fuse	
			RF unit	Display unit
100 V	$\pm 10\%$	90 to 110 V	T4.0 020.7600	T4.0 020.7600
120 V	$\pm 10\%$	108 to 132 V	T4.0 020.7600	T4.0 020.7600
220 V	$\pm 10\%$	198 to 242 V	T2.5 020.7575	T2.5 020.7575
240 V	$\pm 10\%$	216 to 264 V	T2.5 020.7575	T2.5 020.7575

Adjustment procedure:

Caution! When working on lines upon which the AC supply could be present, always ensure that there is no connection to the supply network.

Once the two AC connectors have been removed from the AC filters of the two units, the plastic cover of the voltage selector can be lifted off using a screwdriver on the pin side of the filter units.

The cover contains a fuse corresponding to the set AC supply; this must be removed. Replacement fuses are stored in four holders inside the filter unit. Select the correct fuse according to Table 2-1 and insert into the cover. Replace the cover such that the arrow on the frame points to the required voltage.

2.2.3 Mechanical Connection of the two Units

Place the display unit onto the RF unit such that the front panel of the former protrudes approx. 3 cm beyond the front panel of the RF unit.

Push the display unit towards the rear panel so that the holder locks in place. Subsequently remove the two supplied links from the rear panel of the display unit and screw the two units together (4 milled screws).

2.2.4 Electrical Connection of the two Units

Once the mechanical connection has been made, the electrical connection can be made using the supplied set of cables:

- Connection between **63** (display unit) and **69** (RF unit) using cable W2.
- Connection between **64** (display unit) and **82** (RF unit) using cable W1.

The connectors are secured using the two screws on each plug.

The power switches **58** (display unit) and **73** (RF unit) must be switched off.

Caution! Connect the instrument exclusively to a socket with a protective earth contact.

- Connection from **59** (display unit) to AC socket.
- Connection from **74** (RF unit) to AC socket.

With housing opened, note that AC voltage may be present on the line filter connections even with the instrument power switched off.

2.2.5 Installation in 19-inch Rack

Because of the large total weight, the two units must be installed separately in the rack.

When installing in a 19-inch cabinet, ensure that the ventilation is sufficient to dissipate the power loss from the instrument.

The cooling air is to be supplied at the left (viewed from the rear), whereas a uniform heat dissipation must be ensured at the right.

It may be necessary to use a vertical sheet to separate the cooling air from the dissipated heat. Make sure that a thermal short-circuit cannot occur.

2.3 Manual Operation

2.3.1 Switching On and Subsequent Response of Instrument

With the two power switches **58** and **73** on the rear panel and the ON/OFF key **46** on the front panel switched off, insert the two AC cables into the sockets **59** and **74** and connect to the AC supply.

The two LEDs STANDBY DISPLAY and STANDBY RF **44** light up when the two power switches **58** and **73** are switched on. The LED OVEN **75** on the rear panel of the RF unit indicates that the internal reference oscillator is being heated. The two power switches remain on in normal mode; the instrument is only switched on and off using ON/OFF key **46**. When this key is pressed, the LED ON **46** lights up and the two LEDs STANDBY **44** go out; the two LEDs CHECK DISPLAY and CHECK RF **44** light up for approx. 10 s. An extensive test sequence is carried out during this time which activates display **1** and outputs the result at the end of the test.

The speed of rotation of the blowers **55** and **71** at the rear of the units is monitored and is dependent on the ambient temperature. LEDs A21, A22 (green) **57** and A21, A22 (green) **75** indicate that the power packs A21 and A22 in each unit are operating correctly. If one of these LEDs goes out, this indicates a failure or overloading of the corresponding power pack. The two LEDs ERROR (red) **57**, **75** must not light up during normal operation; if so, this means that the switch-on command is blocked.

Possible causes:

- Excess temperature in instrument (instrument switches on again automatically following cooling down with hysteresis).
- Blower **55** or **71** not running.
- Important modules missing (e.g. microprocessor, graphics, I/O modules).

The internal reference oscillator OCXO (oven-controlled oscillator) is heated further nevertheless. When the instrument is connected to the AC supply for the first time, the reference oscillator requires approx. 5 min (depending on the ambient temperature) to come close enough to its nominal frequency such that all internal synchronization loops for frequency processing can lock in. Various error messages may occur on display **1** during this time which are then automatically cancelled after the warm-up period. The instrument automatically assumes a status which exactly corresponds to the last status before switching off. Thus manual setting of the old status is superfluous and setting errors are prevented. For this reason, the status of the other LEDs on the two front panels cannot be predicted.

2.3.2 General Operation Concept

In order to combine the many facilities of the instrument with as easy as possible operation, hardkey operation where each function has its associated key has been eliminated. Alternate operation, e.g. softkey technique where a minimum number of keys contains a maximum number of alternate functions, has neither been adopted so that the user is not required to continually consider the assignment of functions to keys.

The operating concept of the analyzer is a compromise between hardkey and softkey operation:

- 48 keys with fixed functions for selecting menus (e.g. markers), such as for direct functions (e.g. LOCAL **25**) and for entering numbers (e.g. numeric keypad **31**).
- 8 keys with changing functions for selections from a menu.
- 1 spinwheel for all adjustable parameters.

This type of operation together with excellent operator prompting results in a minimum menu depth and thus very easy operation.

2.3.3 Explanation of Terms


Hardkeys:



Keys with fixed function.

Softkeys:

8 keys (SK1 to SK8) in the monitor frame whose functions (F1 to F8) are variable and depend on the respective menu.



Main menu:

Functions are assigned to the softkeys by pressing a hardkey.

Submenu:

Functions are assigned to the softkeys by pressing a softkey.

Menu width:

If more than 8 functions are possible in a menu level, this menu can be extended to $n + 8$ functions (supplementary menu).

Mode:

(Higher) operating mode of instrument.

Function:

Higher operating mode of instrument, can be modified using hardkey or softkey.

Special Function:

Lower operating mode of instrument.

Display:


Output on screen.

2.3.4 Menu Operation Structure


The lower-level menu hierarchies are selected from a higher-level menu. These lower-level menu hierarchies therefore each have a characteristic format in display 1 as well as special functions suitable for this mode (and also further lower-level menus which can be selected) where the keys in the monitor frame may have different functions. All hardkeys retain their fixed functions, some are switched off in various modes and therefore have no functions.

2.3.4.1 Schematic Representation of Hierarchy

The description of the keys and their operation are explained in detail for ANALYZER mode. In the case of the other modes, their special features are merely described.



2.3.4.2 Schematic Representation of Menu Operation



2.3.4.3 Width Control of a Menu

If up to 8 functions can be selected:



LEDs 23 do not light up.

Keys 23 (left and right) have no effect.

If more than 8 functions can be selected:



One of the two LEDs lights up.

One of the two keys provides further functions of the same menu level (supplementary menu).

2.3.4.4 Possible Status of Softkeys

The following colours refer to the basic setting of the instrument. If the colours are changed by the user, the wording of the subsequent description is correspondingly changed:

Green: colour of markers and softkeys.

Red: colour of display graticule and labelling.

Yellow: colour of trace 1.

The background colour of the softkey pad is referred to as marking in the following text.

Status and their changes can be denoted by marking the softkeys.

Change in status when pressing an inactive softkey

Softkey is marked in green:

- Pressing causes immediate change in status.
- Dependent softkeys are inactivated (dependent softkeys are those whose status are mutually exclusive, e.g.: GRID ABS/REL).

Softkey is marked in red:

- Specified function is the new input function.
- Previously active input function is inactivated (e.g.: START, STOP, CENTER) or marked in green.

Change in status when pressing a softkey marked in green

Softkey remains marked in green:

- No change in status.

Softkey is not marked:

- Specified function becomes inactive (e.g. AUTO ZOOM, SIGNAL TRACK).

Softkey is marked in red:

- Specified function becomes active input function. This change in status is only possible with softkeys which are an input function and also describe an active status.
- Previously active input function is inactivated.

Change in status when pressing a softkey marked in red

Softkey remains marked in red:

- No change in status.

2.3.4.5 Data Input / Data Variation

Data entry is made using the numeric keypad 31 in all modes. The process is terminated by pressing the unit key corresponding to the input value; this key has the function of an ENTER key.

Correction of faulty entries:

- The last digit entered is cleared by pressing BACK SPACE 28 before the unit key and can be overwritten by another number.

Example:

Entry	Screen display
BACK SPACE	Span 123.5
4 5 6 MHz	Span 123.
	Span 123.456 MHz

- If the unit key has already been pressed, BACK SPACE 28 deletes the complete last entry, i.e. the instrument is reset to the old setting.

Example:

Entry	Screen display
1 GHz	Center Frequency 123.456 MHz
BACK SPACE	Center Frequency 1 GHz
	Center Frequency 123.456 MHz

Advantage of this method: the old status is reestablished if the entry is totally incorrect (undo function).

The intelligence of the instrument determines the resolution with which parameters may be entered for particular settings. Excess digits are automatically suppressed.

Negative numbers:

The numeric keypad **31** contains a minus sign so that it is directly possible, for example, to enter negative values for the level or frequency offset.

Example: Entry -10.7 MHz:

-	1	0	.	7	MHz
--------------	--------------	--------------	--------------	--------------	----------------

There is a further possibility for entering level values less than 0 dB (unit), which occurs very frequently, thus saving the pressing of one key.

Example: Entry -40 dBm:

4	0	-dBm
--------------	--------------	-----------------

Data can also be indirectly entered using the key RECALL **30**, (N) **31** (N = 0 to 9) if corresponding data have previously been stored using SAVE **29** (N) **31**.

The current entry is output in display **1** at position A3 (see 2.3.6.2) in the form: function/data value/unit (or ENTER).

Blocking the data entry:

The numeric entry can be blocked by pressing the key HOLD **35** (LED ENABLED goes out).

Reactivation of data entry:

Blocking is cancelled by pressing the key HOLD **35** and the softkeys UNLOCK, i.e. a numeric input using **31** is possible again.

(Blocking of all hardkeys is possible for special applications, see 2.3.6.4.)

Data variation:

Two basic methods of data variation are possible:

Step-by-step variation using **33** and **34** or quasi-continuous variation using **32**.

Step-by-step variation:

After selecting a function by means of **26, 27, 41, 42**, the corresponding parameter can be increased by the set step sizes by pressing key **33** or decreased by pressing key **34**. The step size depends on the respective parameter and the operating mode of the instrument. The selected parameter is output in display **1** at position A3 (see 2.3.6.2). Key **33** or **34** can be pressed several times in any sequence (without further pressing of a function key), and the selected parameter is changed accordingly.

Quasi-continuous variation:

Following selection of a function by means of **26, 27, 41, 42** and a step variation (coarse) by means of **33, 34**, the corresponding parameter can be finely adjusted (= quasi-continuously) by rotating the knob **32**.

Parameters are changed to smaller values by rotating the knob in a counterclockwise direction (corresponding to **34**) or to larger values by rotating the knob in a clockwise direction (corresponding to **33**).

The step size of the variation depends on the respective parameter and the operating mode of the instrument. The selected parameter is output in display **1** at position A3 (see 2.3.6.2). Key **32** can be rotated several times in any direction (without further pressing of a function key), and the selected parameter is changed accordingly.

2.3.4.6 Changing the Softkey Labelling Using an External Keyboard

A keyboard can be connected to the front or rear of the display unit and used for documentation purposes to write two lines of text with 84 characters each instead of the softkey labelling before the screen contents is output e.g. on a printer or plotter. This text is stored in a volatile memory and is therefore no longer available if the instrument is switched on and off again.

Refer to the hardkey function PLOT (see 2.3.6.4).

2.3.5 MODE



MODE 3

Following switch-on the instrument selects the last setting before it was switched off, once the self-test routine has been executed (the MODE menu is not displayed).

The self-test examines the digital hardware (all RAMs, including the screen RAM and the CMOS RAM with battery back-up) and the peripheral ICs. An extensive test of the analog hardware is also carried out. A test is also made to see whether the connections between the display unit and RF unit are made and whether the power supply is correct. Error messages are output on the screen in the event of faults except in the case of faults which prevent a screen output. In this case, the LED field TRACE 11 is used for the fault output.

The switch-on routine is executed if the hardkey PRESET 43 is pressed, and the instrument changes into analyzer mode with the default setting.

It is also possible to press the hardkey MENU 23 in which case the MODE menu with the initialization display is selected without having to execute the switch-on routine.

If the internal back-up battery for the CMOS-RAM has been replaced, the instrument is always started via the switch-on routine and the initialization display is retained, since no valid data have been stored.

Screen display:



The operating mode of the instrument is selected by pressing one of these softkeys. The possible modes are:

ANALYZER mode (see 2.3.6). The instrument operates as an RF analyzer characterized by simple operating technique and a large number of test functions.

RECEIVER mode (see 2.3.7). This mode is a special function of the ANALYZER mode and provides the instrument with additional functions for use as a test or communications receiver.

SET UP mode (see 2.3.8). Communication to and from the peripheral units (printer, plotter, user port, etc.) are largely defined in this mode.

In addition, further operating modes of the analyzer can be selected depending on the options fitted in the instrument. The description of these modes is contained in the respective manual of each model.

For the controller function "MSDOS" refer to the FS-K1 manual. With an external double floppy-disk station attached and the system disk FS-K1 inserted this softkey allows for loading the operating system MS-DOS with the R&S Basic interpreter. Without these accessories the following error message is output in the command line

"DOS-BOOT: Wrong Disk or Disk not ready"

2.3.6 ANALYZER

2.3.6.1 Theory of Operation

Basic theory:

The analyzer operates according to the principle of "sweeping signal system" analysis when used in ANALYZER mode where a particular frequency range (SPAN) is scanned by changing an internal oscillator frequency using an analyzer filter with a matched resolution bandwidth.

All spectral components of the signal which fall in the passband of this filter cause the filter to be excited and thus produce an output signal. This signal is displayed directly in the LIN RANGE mode following rectification or the logarithm is taken and the signal rectified in the LOG RANGE mode.

The frequency range to be analyzed is defined by any combination of the start frequency, centre frequency, stop frequency and span.

The parameters, resolution bandwidth, video bandwidth and sweep time important for the analysis are coupled depending on the displayed frequency range by means of a corresponding algorithm (COUPLED mode).

The analysis is represented on a colour display with the frequency in the x-direction and the associated amplitudes in the y-direction with the correspondingly selected scale.

Circuitry:

The analyzer has been dimensioned for optimum dynamic characteristics (thermal noise up to wideband overloading) with a minimum of active elements.

The block diagram (Fig. 2-3) shows the signal flow in the instrument.

The input signal passes through a selectable input attenuator (attenuation range 0 to 81 dB in 1-dB steps) via which the internal level calibration signal is also connected. After passing through the input lowpass, the input signal (100 Hz to 5000 MHz) is converted in a balanced high-level mixer to the 1st intermediate frequency of 5421.4 MHz. This mixing produces two sidebands which must be handled differently in order to keep the ripple of conversion as low as possible. The lower-frequency signal (1st ZF) is applied to a low-noise amplifier via a ring filter and a bandpass switched in series, the 2nd sideband (input frequency + 1st oscillator frequency) is applied to an ohmic terminating resistor. Selection at the 1st intermediate frequency is made using a five-stage iris-coupled cavity resonator filter with a low transmission loss. The 6-dB bandwidth of this filter is approx. 40 MHz. The IF level is increased in a further IF amplifier. In order to prevent internal inherent noise, this is followed by a cascade of lowpass filters with different cut-off frequencies which are optimally adapted to one another according to their spurious frequencies. The 1st IF signal is stepped down to the 2nd IF of 221.4 MHz in a second, balanced high-level mixing stage. The 200 MHz reference signal is used to switch to the 3rd IF of 21.4 MHz. The 3rd IF signal is amplified (according to the mode) in a selectable low-noise amplifier: the frequency response correction is also carried out here and is derived from the tuning voltage of the 1st conversion oscillator.

In order to obtain high frequency stability and low spurious FM, the complete frequency processing circuit (1st and 2nd oscillators) is designed in synthesizer technique which combines high frequency accuracy with extremely small tuning steps and low phase noise. The complex relationship between display processing and synthesizer control require a 16-bit microprocessor system.

The IF signal (21.4 MHz) applied from the RF unit to the display unit is limited in bandwidth at the frequencies 21.4 MHz or 4.194 MHz by a 5-stage selection filter, according to the set bandwidth. The filter bandwidth can be changed within a very large range (almost 6 decades) with the same relative selection response and the transient response optimized for the frequency analysis procedure. In the course of this filter bank, the signal passes through an amplifier with a selectable gain corresponding to the set reference level.

In linear mode, the IF signal passes through a 40-dB amplifier prior to rectification. In the logarithmic modes, the logarithm of the IF signal is taken in a precision amplifier and rectified.

The detector characteristic can be selected and enables a measurement optimally adapted to the signal together with the selectable video filter (cutoff frequency 1 Hz to 3 MHz). An additional parallel IF branch with automatic gain control and AM and FM demodulators enable the set signal to be monitored and thus simultaneous display on the screen.

A second 16-bit microprocessor system handles the communication with the frequency processor system as well as the level and bandwidth control.

Furthermore, this processor enables single-key operation, numeric entry, data manipulation, coupling of sweep time with span and resolution bandwidth, internal calibration, self-test, support routines for the user as well as external communication (e.g. IEC bus, various interfaces). In addition, this processor provides all information required for the screen display to the graphics system. This graphics system contains another 16-bit processor, a dual port RAM bank and a special graphics processor, and enables display of curves, grid, setting parameters and various additional features on a high-resolution (9-inch) colour monitor.




Fig. 2-3 Block diagram of analyzer (RF unit)





Fig. 2-3 Block diagram of analyzer (display unit)


2.3.6.2 Explanation of Screen Inscriptions



- A1 R&S logo can be switched off in the screen menu.
- A2 Status line: This line displays particular operating status and instrument messages (e.g. error messages):
FRQOFF: Frequency offset is active
LVLOFF: Level offset is active
MSG: Instrument message indicating overloads or errors. More detailed information can be obtained using the functions STATUS and ERROR REPORT in the HELP menu.
- UNCAL: If the sweep time is not automatically coupled with the resolution bandwidth, i.e. if it is fixed or only manually variable, the resolution filters can no longer settle at small bandwidths and an additional frequency and level error is produced. The resulting erroneous measurement is indicated by UNCAL.
- TRIG: The trigger setting is not "Free Run", i.e. the start of the sweep may depend on the signal.
- *: The symbol "*" is displayed in the status line whenever an instrument parameter has been altered during a sweep, i.e. the display of the trace corresponds only partially to the new setting. The

symbol "*" disappears as soon as a complete sweep has been performed without changing parameters.

2.3.6.3 PRESET



PRESET 43

The following basic setting is called by pressing the hardkey PRESET 43:

- A3 Command line: activated during entries, outputs the current value of the selected parameter and is used to enter new numeric values.
- A4 RES BW: display of currently set resolution bandwidth. Usually the 3-dB bandwidth is output, also the 6-dB bandwidth with pulse signals.
- A5 TRACKING GENERATOR: level display or "OFF" of tracking generator if it is installed in the instrument.
- A6 CF.Stp: display of currently set centre frequency step size.
- A7 LINE: display of currently set threshold line, if active.
- A8 VID.BW: display of currently set video bandwidth. The 3-dB bandwidth is always output.
- A9 RF.ATT: display of set RF attenuation.
- A10 MIXER LEV: display of level at mixer required for full deflection to reference line. Calculated from (REF.LEV.) minus (RF.ATT).
- A11 UNIT: in the case of long units, e.g. dBV/m/MHz, the symbol "dB*" is used.
- A12 STOP: indication of set stop frequency.
- A13 SWEEP: indication of set sweep time.
- A14 CENTER: indication of set centre frequency.
- A15 SPAN: indication of set span.
- A16 START: indication of set start frequency.
- A17 Function field: 8 function fields assigned to the softkeys.
- A18 Scale field: level scale corresponding to set diagram. Either relative or absolute data.
- A19 REF.LEV.: level required at socket RF INPUT 37 for full-scale deflection.
- A20 MARKER: for data associated with the marker(s) (e.g. marker frequency and level).

Instrument mode Analyzer	Setting	
CENTER FREQUENCY	1000 MHz	
CENTER FREQUENCY STEP SIZE	200 MHz	
SPAN	5000 MHz	
INPUT	AC	
RF.ATT	20 dB	COUPLED
RF.ATT STEPS	5 dB	
REF.LEVEL	-10dBm	
REF.LEVEL STEPS	10 dB	
LEVEL RANGE	100 dB	LOG
DETECTOR	AUTOPEAK	COUPLED
SWEEP TIME	20ms	COUPLED
RES.BW	3 MHz	COUPLED
VIDEO BW	3 MHz	COUPLED
SWEEP		CONT.
TRIGGER		FREE RUN
TRACE	1	CLR/WRITE
TRACE	2,3,4	BLANK
REFERENZ		INT.
FREQ. OFFSET	0 HZ	
REF. LEVEL OFFSET	0 dB	

All active special functions are switched off automatically.


2.3.6.4 Explanation of Hardkey Functions and Menus





SCREEN 2

The hardkey SCREEN 2 is used to call the menu to format the screen elements or to set the colours.

Screen display:



Submenu LINE STYLE:



The screen colour and intensity are selectable. To set the colour, the intensities of the three fundamental colours are displayed as horizontal bars. The spinwheel 32 can be used to change the proportion of the currently active colour bar. The colours red, green or blue are selected using the STEP keys 33 and 34. The inscription of the active colour bar is in inverted video. The selected color setting is stored even after switch-off. The preferred setting can also be changed.



Screen brightness.

The screen brightness can be adjusted in 64 steps using the spinwheel 32:

Counterclockwise: darker
Clockwise: brighter

A coloured bar at the top right of the display serves as an indicator.



Color setting for grid.



Colour setting for trace 1.



Colour setting for traces 2, 3 and 4.



Colour setting for the eight softkey labels.



Colour setting for the background.



Resetting of modified colours to their preferred settings. A previously activated input is aborted.



Return to last set menu.

Supplementary menu SCREEN




The line oscillator of the internal monitor electronics is switched off and the screen cleared. The signals for the external monitor always remain active! As with the BACK function, the last set menu is automatically selected after switching off the internal monitor. Thus, the respective parameter of the main menu also becomes active again and can be varied via the spinwheel with the monitor electronics switched off.

The monitor is switched on again by pressing any key.



Selection of a submenu to modify the elements for display formatting. The following types of line can be selected:

- continuous
- dashed
- dotted
- dot-and-dashed



Selection of marker symbol using STEP keys **33** and **34**.

The following symbols can be selected:

- ▼ triangle
- circle
- + cross (vertical)
- X cross (diagonal)

Submenu *LINE STYLE*

LOGO
ON OFF

Switching on/off of the R&S logo (A1) in the display.

COLOR
SET DEF.

Saving of the current colour setting as new preferred setting.

BACK

Return to the last set menu.

GRID

Selection of grid display.

DISPLAY
LINE 1 2

Selection of display of the two adjustable horizontal level lines 1 and 2.

FREQ.
LINE 1 2

Selection of display of the two adjustable vertical frequency lines 1 and 2.

BACK

Return to the last set menu.




DISPLAY 4

The hardkey **DISPLAY 4** is used to select the menu to activate or inactivate the display elements.

The status of the corresponding element is displayed by inverting the corresponding soft-key field.

Screen display:



Main menu



Grid lines switched on/off.



Traces 1 to 4 switched on/off.



Selection of a submenu for switching on/off a maximum of eight possible markers.



Return to the last set menu.

Submenu MARKER



Reference marker switched on/off.




Delta marker switched on/off.



Multimarker switched on/off.




Return to the last set menu.



SPECIAL FUNCTIONS 5

Selection of menu for activating additional functions for special applications.

Screen display:



Main menu

INPUT
IMP.

Selection of a submenu for setting the input impedance (50 Ω or 75 Ω using the R&S matching pads).

TRANSD.
FACTOR

Selection of a submenu for selection and input of transducer factors.

MIXER
LEVEL

Selection of a submenu for entering the mixer level.

COUNTER
RESOL.

Selection of a submenu for setting the frequency counter resolution (10 kHz to 0.1 Hz).

DETECTOR

Selection of a submenu for defining the DETECTOR mode.

CAL.COR.
ON OFF

Switching on and off the correction values for level, bandwidth and offset corrections determined in the calibration routine.

Supplementary menu SPECIAL FUNCTIONS

SERVICE

Selection of service routines for checking instrument and board functions for adjustment and service purposes via the numeric keypad. For details about these functions refer to the Service Manual.

Submenu INPUT IMP.

INP.IMP.
50 Ω

Setting an input impedance of 50 Ω . Each level indication refers to the 50 Ω system.

INP.IMP.
75 Ω /RAM

Setting an input impedance of 75 Ω with the R&S matching pad RAM. Each level indication refers to the 75 Ω system (analyzer and RAM).

INP.IMP.
75 Ω /RAZ

Setting an input impedance of 75 Ω by means of the R&S matching pad RAZ. Each level indication refers to the 75 Ω system (analyzer and RAZ).

Submenu *TRANSD. FACTOR*

Four different correction tables with max. 25 frequency and level sample points can be defined. These sample points are entered, changed or inserted separately for frequency and level via the numeric keypad. They are displayed in a table, where they are sorted in ascending order of the frequencies. The four correction tables are stored in the battery-backed memory of the analyzer, thus ensuring that they remain stored even after switching off the instrument.

One of these correction curves can be activated respectively. A curve interpolation between the sample points is carried out for the current analyzer setting. Thus the definition of the correction curve can be restricted to the peak values and inflection points. The ranges below the first and above the last defined frequency are not included in the correction.

TRANS.TAB.
SELECT

Selection of the correction tables 1 to 4 via the numeric keypad. The current correction values are displayed in a table.

TRANS.TAB.
EDIT

Selection of a submenu for entering, inserting, changing and clearing sample points in the current correction table.

TRANS.TAB.
COPY

Copy of the current correction table into another table, which is defined by entering one of the numbers 1 to 4.

TRANS.TAB.
ON OFF

Switching on/off of the current correction table. A new curve interpolation with reference to the start and stop frequency is carried out with activating the correction table as well as with each change of the analyzer frequency setting.

PRINT
START

Start of a hardcopy-output of the screen contents to the printer via the parallel interface **66**.

PRINT
ABORT

Abortion of a current output to the printer.

Submenu TRANSD. FACTOR TABLE EDIT

EDIT T.F.T.
CLR ALL

This softkey is used for clearing the whole table.

EDIT T.F.T.
INSERT

Insertion of new sample points. After terminating the input the table is updated and displayed in ascending order of frequencies. If all values in the table are assigned a sample point, this softkey has no function.

EDIT T.F.T.
CHANGE

The sample point *i* selected via the PREVIOUS/NEXT softkey (represented in the table in reverse characters) may be changed via the numeric keypad or the step keys, i.e. the value may be altered with reference to the cursor position. The cursor can be positioned by means of the spinwheel. Upon a change of the frequency value the table is sorted again in ascending order of the frequencies. If the table is empty, this softkey has no function.

EDIT T.F.T.
CLEAR

The sample point *i* (represented in the table in reverse characters) is cleared, the table is updated. If the table is empty, this softkey has no function.

EDIT T.F.T.
PREVIOUS

Selection of the next lower frequency sample point in the table. The sample point in question is displayed in reverse characters. If it is the first sample point, the subsequent value is the last sample point of the table ("WRAPAROUND").

EDIT T.F.T.
NEXT

Selection of the next higher frequency sample point in the table. The sample point in question is displayed in reverse characters. If it is the last defined value in the table, the subsequent value is the first sample point of the table.

Submenu MIXER LEVEL

MIXER LVL
COUPLED

Automatic adjustment of the RF attenuation for the mixer level with reference to the operating modes selected (LOW NOISE, LOW DISTORTION or NORMAL).

MIXER LVL
MANUAL

The rated mixer level can be entered via the numeric keypad, the step keys or the spinwheel. It is set by means of the RF attenuation, i.e. the COUPLED MODE must be selected for the RF attenuation. In the LOW DISTORTION mode the mixer level is set in steps of 1 dB – whereas in steps of 5 dB in the other modes – referred to the reference level. The mixer level is always lower than the reference level.

The rated mixer level is indicated in the display field (A 10) above the grid.

Note:

The special function MIXER LEVEL MANUAL is disabled (COUPLED mode) in the operating modes LOW DISTORTION, LOW NOISE and NORMAL.

Submenu COUNTER RESOLUTION

CNT. RES.
10 KHZ

...

CNT. RES.
0,1 HZ

Setting of resolution of built-in counter from 10 kHz to 0.1 Hz with corresponding gate time. The resolution of the counter result in the marker field corresponds to the resolution of the counter.

Submenu DETECTOR

Selection of DETECTOR mode for special applications.

COUPLED

Automatic selection of the detector mode depending on the active write mode of the traces.

Clear Write = AUTOPEAK

Max Hold = Pos.PEAK

Average = Sample

AUTOPEAK

Automatic switchover between maximum and minimum peak detector depending on the input signal (noise or signal edges).

POS.PEAK

Fixed selection of positive peak-value detector.

NEG.PEAK

Fixed selection of negative peak-value detector.

SAMPLE

Fixed selection of random sample mode without peak detectors connected ahead (as with AVERAGE mode).




DISPLAY LINE 6

The hardkey **DISPLAY LINE 6** is used to select a menu to activate additional level/frequency or tolerance lines.

The status of the corresponding element is displayed by an inverted (= activated) representation of the softkey field.

The frequency and level values of the activated lines can be displayed and printed out in tabular form using the **STATUS** function in the **HELP** menu.

Screen display:



Main menu



DISPLAY
LINE 1 2

Switching on/off of two lines whose position can be changed using the spinwheel **32**, the STEP keys **33**, **34** or by a numeric input **31**. The level value of these lines is displayed on the screen. Pressing the softkey again switches off the function.



THRESH.
LINE

Switching on and off of a level line used to define a threshold value. This threshold value can define a lower limit for the marker function **NEXT PEAK** or the multimarker function **PEAK SEARCH** or suspend automatic signal tracking for the function **SIGNAL TRACK** when the limit value has fallen below.

REF.
LINE


Switching on/off a level line used for difference mode and normalization (elimination of frequency responses). Pressing the softkey again switches off the function.

TOL.
LINES

Selection of a submenu for selection and input of max. 8 tolerance lines and for activating the LIMIT CHECK.

N dB
DOWN

One level line is set to the peak value, the second level line is set n dB below the peak value of the signal. When searching for the peak, the level is excluded at a frequency of 0 Hz. The level can be changed using the spinwheel, the STEP keys and by directly entering numbers. The value is displayed in the command line. The two lines are switched off again by pressing the softkey again.

FREQ.
LINE 1 2

Switching on/off of two frequency lines, the position of which can be changed using the spinwheel, the STEP keys or by directly entering numbers. The lines are switched off by pressing the softkey again.

Submenu TOL. LINES

Max. 8 tolerance lines with max. 16 sample points can be defined. After each sweep a LIMIT CHECK can be carried out. The sample points are frequency and level values, which can be positioned or changed interactively via spinwheel or STEP keys by means of cursor control. They can also be defined by numeric inputs. The tolerance lines are no graphic lines but actually defined frequency and level values. Upon change of the instrument setting (frequency or

reference level) the tolerance lines are automatically adapted and, if necessary, clipped, i.e. they do not exceed the grid, even if the physical definition range is beyond the instrument setting.

Limit Check is indicated beside the grid, the active tolerance lines being displayed with their numbers and additionally with an arrow facing upwards or downwards in case of limit check. A limit violation is indicated by a change of the inscription colour. With the respective configuration a Service Request may be sent from the IEC bus (s. Section 2.4).

Note:


The tolerance lines are all stored in the battery-backed CMOS RAM of the analyzer and are not lost in case of switch-off.

TOL. LINES
SELECT

Selection of one of the tolerance lines 1 to 8 by entering the respective number. The current tolerance line is indicated in the command line.

TOL. LINES
EDIT

Selection of a submenu for entering, inserting, changing or clearing sample points for the current tolerance line.

TOL. LINES
COPY

Copy of the current tolerance line to another tolerance line defined by entering the respective number (1 to 8).

TOL. LINES
ON OFF

Switching on/off of the current tolerance line. With activating the tolerance line as with each change of the frequency and level setting or change of the analyzer level range an adaptation of the tolerance lines with reference to the start and stop frequency is carried out.

LIMIT CHK
TRACE

Selection of the trace (1 to 4) for limit check of the current tolerance line.

LIMIT CHK
LOWER

With activating the limit check the **current(ly active)** tolerance line is defined to be the bottom limit line, i.e. values below this line violate the limit.

LIMIT CHK
UPPER

With activating the Limit Check the current tolerance line is defined to be the top limit line, i.e. values above this line violate the limit.

LIMIT CHK
ON OFF

Switching on/off of Limit Check with the current tolerance line for the trace selected at the end of the sweep. The result is then indicated beside the grid, i.e. the number of the tolerance line with the arrow facing upwards or downwards (depending on the limit lines selected) is displayed with the respective colour.

Submenu TOLERANCE LINES EDIT

This submenu is selected for entering, changing or clearing the current tolerance line via cursor control. The curve segments of the tolerance line which change due to a variation of the current sample point, are dashed

For first editing a new tolerance line the cursor is positioned in the centre of the display, whereas it is located on the last sample point for all further editing procedures. The cursor can only be moved along the frequency or the level axis. Exact positioning is possible by entering numbers.

Entering a new tolerance line:

A tolerance should be defined from "the left to the right", i.e. from low to high frequencies. After positioning the cursor to the first sample point, the latter is fixed using the SET softkey. The MOVE softkey is activated simultaneously (for defining the next sample point!). The position of the second sample point is also fixed with the SET softkey. The tolerance line is completed in this way – the end of the line is fixed by pressing the MOVE softkey again.

Changing a sample point:

The cursor can be positioned along the tolerance line to the various sample points using the softkeys PREVIOUS and NEXT. The sample points can then be varied by pressing the MOVE softkey. Frequency changes are limited by the respective sample points to the left and to the right.

Insertion of an additional sample point:

The additional sample point is defined by means of the cursor. The new point is integrated in the polyline by means of the SET softkey and saved by actuating the MOVE softkey.

Deletion of a sample point:

The cursor is positioned to the required sample point by means of the softkeys PREVIOUS or NEXT. By pressing the CLEAR softkey this sample point can then be deleted.

EDIT TOL.
CLEAR

If the cursor is positioned on a sample point of the tolerance line, this point is deleted from the active poyline.

CURSOR
FREQ

Switchover to the frequency value of the cursor position. The frequency can be changed via the spinwheel, the STEP keys or via the numeric keypad.

EDIT TOL.
CLR ALL

The current tolerance line is deleted, the cursor is placed in the centre of the screen.

CURSOR
LEVEL

Switchover to the level value of the cursor position. The level can be changed via the spinwheel, the STEP keys or via the numeric keypad.

EDIT TOL.
PREVIOUS

The cursor is positioned to the next lower frequency sample point of the current tolerance line.

EDIT TOL.
SET

Marking a new sample point for the current tolerance line. The MOVE mode is immediately activated. If the cursor is positioned between two sample points of the tolerance line, the new sample point is automatically inserted in the polyline.

EDIT TOL.
NEXT

The cursor is positioned to the next higher frequency sample point of the current tolerance line.

EDIT TOL.
MOVE

With the MOVE mode activated the current sample point position can be changed by means of the cursor. With the MOVE mode not activated and the cursor positioned to a sample point, the MOVE mode can be activated by pressing the respective softkey. The cursor position thus determines the current sample point, which can change its position as well. If the cursor is not positioned to a sample point, this softkey has no function. The MOVE mode is deactivated by pressing the softkey again.


SHIFT
FREQ

The current tolerance line can be varied within the frequency axis via spinwheel or STEP keys.

SHIFT
LEVEL

The current tolerance line can be varied within the level axis via spinwheel or STEP keys.

Supplementary menu TOLERANCE LINES EDIT



PLOT 7

These functions can be used to output hardcopies on a printer.

The printer and plotter are selected in the menu **SETUP**. The printer or plotter output takes place in the background from a sufficiently large buffer memory so that the analyzer is ready again for new measurements after a few seconds.

For colored printer or plotter outputs (PDN COLOR) the buffer memory is occupied several times, thus increasing the time period which passes until the instrument is ready again for new measurements.

Note:

The output to the plotter is carried out in the controller mode via the IEC-bus interface. With an external controller attached or with the internal controller function FS-K1 activated the output to the plotter is initiated by a corresponding IEC-bus command, which transfers the controller function to the analyzer (see example in Section 2.4.1.9). When an external controller is attached, the output to the plotter cannot be manually started in order to prevent a collision of active controllers at the IEC bus.

Screen display:



Start of hardcopy output of screen contents on printer via parallel interface **66**.

If the "PDN COLOR" option has been selected in the **SETUP** menu, the current colour of the screen elements is output on a colour printer. The colour can be changed in the **SCREEN** menu.

With this setting the background is not printed, the "white" colour is printed black, the "black" colour is not printed. For all further colours the respective red, green and blue portion is added with printing, when the intensity is higher than 50%.




Start of hardcopy output of complete screen contents including grid and inscriptions on plotter via IEC-bus interface **61**.



Start of output of the visible TRACE memory (memories) on plotter via IEC-bus interface **61**. This is particularly important for repeated measurements with unchanged instrument settings.



Instead of the softkey menu, two lines of text with 84 characters each can be entered using the external keyboard. The text entry is terminated by pressing the MENU UP key **23**.




Abort current output on printer or plotter.

This has no effect on the buffer memories (of variable size) in the printers.




Return to the last menu selected.




HELP 8

The hardkey **HELP 8** is used to call functions which inform the operator of further instrument functions available, identify the current instrument status and enable access to calibration routines.

Screen display:



Submenu STATUS:



Main menu

EXPLAIN

General information on instrument function and special facilities offered by the softkey menu selected before. The respective functions are illustrated.

STATUS

Selection of a submenu which permits to list the current instrument data, error messages and calibration correction values. These tables can be output via a connected printer.

CALIBR.
SHORT

Triggering of a short calibration. A level calibration is carried out at a frequency of 100 MHz and an offset correction of the resolution filter performed.

CALIBR.
TOTAL

Triggering of the total calibration. In this case the 3-dB and 6-dB bandwidths are also calibrated for all resolution bandwidths as well as the amplitude deviations and any frequency offset. The amplifiers connected in series and the logarithmic and linear display ranges are also calibrated. Besides the offset display of the FM demodulator is also calibrated.

Note:

Actuating the **PRESET** key during total calibration causes all data stored in the CMOS RAM to be cleared. The instrument switches to the default setting with the initialization display. This "cold start" corresponds to the instrument setting after replacement of the battery.

BACK

Return to the last menu selected.

Submenu STATUS

INSTR.
STATE

Output of current instrument status in tabular form on the screen. If active, the following elements are listed:

- Markers (ref., delta and multimarker)
- Display lines (level lines, frequency lines, etc.) with frequency and/or level values as well as the current TRIGGER setting (free run, video, etc.).

Example: INSTRUMENT STATE with marker, multimarker and display lines.

INSTRUMENT STATE			
REF. MARKER	FREQUENCY / TIME	LEVEL	TRIGGER FREE
DELTA MARKER	100.00000 MHz	-19.16 dBm	
MULTI MARKER 1	100.00000 MHz	-19.16 dBm	
MULTI MARKER 2	200.00000 MHz	-49.61 dBm	
MULTI MARKER 3	300.00000 MHz	-80.03 dBm	
MULTI MARKER 4	400.00000 MHz	-87.83 dBm	
MULTI MARKER 5	500.00000 MHz	-87.78 dBm	
MULTI MARKER 6	600.00000 MHz	-87.98 dBm	
DISPLAY LINE 1		-22.77 dBm	
DISPLAY LINE 2		-56.94 dBm	
THRESH. LINE			
LEVEL LINE			
N dB DOWN LINE			
FREQUENCY LINE 1			
FREQUENCY LINE 2			

ERROR
REPORT

Output of messages (e.g. overload) in tabular form on the screen by displaying "MSG" (message) in the status line A2. The messages that have occurred after the last ERROR QUIT (or PRESET) are listed for RF unit and display unit separately. Messages that have been added after the last selection of the function ERROR REPORT are distinguished in terms of colour.

Note:

Sweep is stopped during status output. Thus error messages of synthesizers or overload are not indicated.

Example: ERROR REPORT with overload message.

STATUS ERROR REPORT	
RF-UNIT : LEVEL 2. IF	DISPLAY-UNIT: A34

ERROR
QUIT

Cancels and clears messages on the ERROR REPORT display.

CAL. COR.
DATA

Output of all correction values determined by the internal calibration routine. The display is made in tabular form on the screen on a total of five pages. The STEP keys can be used to switch between the individual table pages.

Example: CALIBRATION DATA

If a significant deviation from the internal correction values occurs during the calibration procedure, the respective parameter is marked in the table by the remark "check". A correction of this deviation is carried out (exception: tracking level, AF unit and bandwidths may show deviations, which cannot be corrected).



Return to the last menu selected.

Additional tests are performed during total calibration (e.g. calibration level present?) in order to ensure an error-free run of the calibration routine. Calibration is aborted in case of a machine error. This is indicated in the table by the message "Calibration:aborted".

Use ↑ + keys to Page Up/Down		CALIBRATION DATA	Page 1 of 5
Calibration : passed		Bandwidth	
Preamplifier : passed		6 Hz : passed	
Step Gain10.0dB : passed		10 Hz : passed	
Step Gain 1.0dB : passed		30 Hz : passed	
Step Gain 0.1dB : passed		100 Hz : passed	
LIN : passed		180 Hz : passed	
LOG : passed		300 Hz : passed	
		800 Hz : passed	
		1 kHz : passed	
AF Unit : passed		1 kHz : passed	
Tracking Level :		3 kHz : passed	
Attenuator : passed		10 kHz : passed	
		30 kHz : passed	
		80 kHz : passed	
		100 kHz : passed	
		300 kHz : passed	
		1 MHz : passed	
		3 MHz : passed	



Start of hardcopy output of screen contents on printer via parallel interface 66.





Aborts a currently running printer output.



SWEEP 9

The hardkey SWEEP 9 can be used to define the parameters for frequency sweep (time, start, single sweep etc.).


Screen display:




The current sweep is interrupted when this softkey is pressed and subsequently restarted automatically. The continuous sweep, i.e. an automatic restart once a sweep has been completed, is the normal sweep form.




Triggers the start of the sweep in SINGLE SWEEP mode.



Switches to operating mode SINGLE SWEEP.



The sweep time can be changed using the spinwheel, the STEP keys and by directly entering a number. Pressing the SWEEP TIME key removes the sweep time from the coupled functions and retains the set value in fixed mode.



DISPLAY OFF can be used to switch off the screen for one sweep. The measurement is then only started when the START softkey is pressed. The screen is switched off immediately before the sweep is started. It is switched on again automatically at the end of the sweep. The measured curve is visible immediately.

Advantage: Interference from built-in monitor is avoided!

The sweep time can be entered between 20 ms and 1980 s if the span is >0 Hz. With zero span, the sweep time can be additionally reduced to

10 ms
8 ms
4 ms
2 ms
1 ms
800 μ s
400 μ s
200 μ s.

With sweep times <8 ms, no longer 901 but accordingly less test points are displayed, and the trace is graphically interpolated.



TRIGGER 10

Selection of menu to adjust triggering of the sweep.

If the trigger setting is not FREE RUN, "TRIG" is displayed in the status line A2.

Screen display:



The sweeps are triggered in continuous or free-running mode.



Triggered by external signal.




Triggered synchronous to frequency of AC supply voltage.



Trigger slope selection. The current sign is displayed by inverting the softkey field. This function is only relevant to the operating modes TRIGGER EXTERNAL and TRIGGER VIDEO.



Triggered by video signal. The trigger threshold is displayed as a dashed level line in the diagram and can be varied using the spinwheel. The trigger line disappears when the menu is left.



TRACE 11

Selection of menu for selection of the current TRACE memory. The traces 1 to 4 can be selected by entering the respective number. All softkey functions mentioned apply for the current TRACE indicated in the command line (A3). The operating modes CLEAR WRITE, MAX HOLD and AVERAGE are provided for active writing to the trace memory.



Each trace record consists of the measured values and the associated instrument setting. The function SAVE 1 to 4 allows for storing the TRACES 1 to 4 together with the instrument setting. The TRACE data are not cleared in case of switching off the instrument.

Note:

The diagram inscription (frequency and level axis) always corresponds to the current hardware setting of the analyzer. In VIEW mode the marker indicates the measured values of the curve. They may differ from the current instrument setting.

TRACE 1 can be written to or displayed separately from the other trace memories. It is then displayed on the screen by a separation in terms of colour. Only in VIEW mode traces 3 and 4 are displayed graphically. Writing is, however, possible in all modes but not displayed.

Screen display:



The current TRACE is cleared and the sweep restarted. With each sweep the TRACE is rewritten to. Switching TRACE 2 into the CLEAR/WRITE mode causes TRACES 3 and 4 to enter the BLANK mode, if they were displayed earlier in VIEW mode.



With each sweep the max. value resulting from the addition of the new measured value and the stored trace data is transferred to the current trace. The trace memory is cleared and the procedure is restarted by pressing the softkey again.



The average value is calculated from several sweeps and stored in the current trace. The first sweep after activating this function or after changing the instrument setting is performed with CLEAR/WRITE, then the average value is determined according to the formula

$$Y(n) = \frac{(n-1)}{n} \times Y(n-1) + \frac{1}{n} \times Y(\text{new})$$

where n is the number of average samples.

If AVERAGE SAMPLES = 0, $n = 10$.

The number of average samples for the



AVERAGE mode can be determined by entering numbers up to max. 32767. If the number of average samples = 0 (preferred setting) continuous averaging is performed by applying the above-mentioned formula with $n = 10$. In SINGLE SWEEP mode the new sweep is thus averaged with the trace contents.

If the number of average samples $n = 1$ to 32767, n sweeps are performed and averaged. A single sweep thus consists of the number of sweeps entered which are then averaged.



Selection of submenu for forming the difference of trace 1 and the other traces or the reference line.



VIEW is used to display the current trace memory and for writing to the trace. Switching trace 3 or 4 to VIEW mode causes trace 2 to be switched to VIEW mode also, if it has been written to earlier.

Only in VIEW mode these traces can be displayed together.



BLANK is used to clear the current trace memory on the screen. The stored trace contents is retained and can be displayed again using VIEW.



Copy of the current trace memory into another one, which is defined by entering one of the numbers 1 to 4. This trace memory is then automatically switched to the VIEW mode.

Submenu DIFF.




With the sweep stopped, the difference between trace 1 and traces 2 to 4 or the reference line is formed and stored in memory 1 again. During the sweep, the stored curve or the reference line is subtracted from the current measured value. If the difference mode is activated, all other measurements (max. hold, average) refer to this difference.

If the reference line is switched on during formation of the difference between trace 1 and traces 2 to 4, this procedure is referred to as normalization with the reference line being the 0-dB reference. The diagram labelling is switched to "relative". This 0-dB reference can be changed by shifting the reference line.



Switching off of difference mode.




MULTI MARKER 12

This function permits the use of a maximum of eight markers, marker 1 being always used as reference marker and marker 2 as delta marker so that the remaining six multimarkers can be set independently.

The frequency and level values of the active markers can be displayed and printed out in tabular form using the function STATUS in the HELP menu.

Screen display:




Sets the next multimarker (in increasing sequence) to the current marker position.



Clears the set multimarker if the active marker is at this position.



Clears all set multimarkers.



Sets the active marker to the position of the next multimarker with smaller frequency, if available.



Sets the active marker to the position of the next multimarker with greater frequency, if available.



Sets all six multimarkers to the six greatest signals in the spectrum. The frequency 0 Hz, if visible, is excluded from the search for the peaks. The threshold line can be activated in order to determine a threshold value representing the lower limit for the peak search. Depending on the threshold value and signal spectrum, it is also possible to set less than six multimarkers.



Activates the reference marker. The marker frequency can be changed using the STEP keys, the spinwheel or by entering numbers. For switching off, the softkey must be pressed again.



Activates the delta marker. If the delta marker has not been switched on before, the marker is automatically set to the greatest signal. The marker frequency can be changed using the STEP keys, the spinwheel or by entering numbers. The level and frequency difference between the delta marker and the reference marker is output in the marker field (A20) on the display. For switching off, the softkey must be pressed again.




MARKER 13

This function enables use of level/frequency markers.


The frequency 0 Hz is excluded from the search for the peaks.

Pressing **MARKER 13** automatically triggers the search for and identification of the maximum value on the trace if the marker has not already been activated.


Screen display:



Main menu




The marker is positioned to the peak signal of the spectrum (PEAK SEARCH).



The current marker frequency becomes the new centre frequency.



The current marker level becomes the new reference level.



The marker frequency becomes the new step size of the centre frequency. (Important with harmonics measurements!)



The marker frequency becomes the new start frequency.



The marker frequency becomes the new stop frequency.



Activates the (reference) marker. The marker frequency can be changed using the STEP keys, the spinwheel or by entering numbers. For switching off, the softkey must be pressed again.



Activates the delta marker. PEAK SEARCH is carried out automatically if the delta marker has not been switched on before. The level and frequency difference between the delta marker and the reference marker is indicated in the marker field (A20) of the display. For switching off, the softkey must be pressed again.

Left-hand supplementary menu MARKER



The sweep is performed until the marker position is reached. Then the frequency is measured using the built-in frequency counter and output in the marker field (A20) of the display. The sweep is automatically continued after completion of the measurement. The process is automatically repeated until the function is switched off by pressing the softkey again, or the marker position is changed.

With reference marker and delta marker switched on, the frequency is measured at both positions and the difference is then indicated in the marker field (A20).

Note:

The largest signal within the resolution bandwidth is always counted. If the resolution bandwidth contains several signals, the frequency range can be limited to ensure that the desired signal has the largest amplitude. The minimum countable amplitude must be at least 10 dB higher than the noise.




This function enables automatic tracking of the analyzer centre frequency with drifting signals. It corresponds to the function AUTO TRACK. PEAK SEARCH and MARKER TO CENTER FREQ are carried out following each sweep. This procedure is only possible as long as the drifting signal remains within the display range of a window on the screen or, with active threshold line, the signal level exceeds the threshold value. Otherwise, tracking is interrupted but remains active.



Activates the ZOOM function about the marker. The input of the span is activated. If the span is entered, the sweep is stopped at the marker position and the frequency measured using the built-in IF counter. Then the measured frequency becomes the new centre frequency and the span is set as required.

This function is helpful in particular if a signal is to be immediately analyzed with a high resolution from a large span. The function corresponds to the AUTO ZOOM function.



The phase noise is measured at the marker position, the bandwidth and all necessary correction factors being taken into account. The phase noise is output in the marker field (A20) of the display in dBm/Hz.

MARKER
PEAK

The marker is set to the greatest signal in the spectrum. The signal at the frequency 0 Hz, if visible, is automatically excluded if the threshold line is not active or its level is smaller than the greatest signal in the spectrum.

MARKER
NXT. PEAK

Each time the key is pressed, the marker is set to the next (smaller) maximum. The signal at the frequency 0 Hz, if visible, is automatically excluded. By activating the threshold line, it can be used to determine a threshold value representing the lower limit in the search for the peaks.

MARKER
MIN

The marker is set to the smallest signal value in the spectrum.

MARKER
NXT. MIN

Each time the key is pressed, the marker is set to the next (greater) minimum. By activating the threshold line, it can be used to determine a threshold value representing the upper limit in the search for minima.

Right-hand supplementary menu MARKER

When this menu is selected, the delta marker is automatically activated if it was not already switched on before.

DELTA M.
SPAN

The frequency difference between the two markers becomes the new span. The marker frequencies become the new start and stop frequency.

DELTA M.
STEP SIZE

The frequency difference between the two markers becomes the new step size by which the delta marker can be varied using the STEP keys.

PHASE
NOISE

Level line 1 and frequency line 1 are set to the level/frequency value of the reference marker.

The difference between the point of intersection of level and frequency line and the marker is determined and output in dBc/Hz in the marker field (A20) of the display, the current noise bandwidth and the correction factors being taken into account.

REF.
FIXED

Using this function, level line 1 and frequency line 1 are set to the level/frequency value of the reference marker. The difference between the point of intersection of level and frequency line and marker is output in the marker field (A20). The position of the level and frequency line can also be changed in the DISPLAY LINE menu, thus enabling level and frequency measurements with reference to a point outside the measuring curve.

The two lines are switched off by pressing this softkey again.

N dB
DOWN

In addition to the reference marker, two further markers are activated whose level is N dB smaller. The level value can be changed using the STEP keys, the spinwheel or by entering numbers. The frequency difference between these markers is output in the marker field. When this function is activated, all other multimarkers are switched off. If the N dB value cannot be formed (e.g. if the signal approaches the noise level), "invalid BW" is displayed in the marker field (A20).

SHAPEFAC
60dB/3dB


In addition to the reference marker, four further markers are activated the level value of which is 3 dB/60 dB smaller. One marker of each pair is smaller in frequency than the reference marker and one marker is greater in frequency.

The shape factor of the analyzed signal is output in the marker field (A20) of the display.

When this function is activated, all other multimarkers are switched off. If the 60-dB value cannot be formed (e.g. if the signal approaches the noise level), the display "invalid shape factor" is output in the marker field (A20).

SHAPEFAC
60dB/6dB

Corresponds to the function SHAPE FACTOR 60 dB/3 dB, except that the level of the first pair of markers is 6 dB smaller than that of the reference marker.



AUTO 14

The user can be relieved of routine procedures by means of various automatic procedures:

- adjustment of RF attenuation dependent on reference level and input mixer level for full-scale deflection;
- adjustment of any signal level to the reference line of the display (AUTO RANGE);
- switching on of DC isolation at socket RF INPUT 37;
- tracking of centre frequency in line with a signal of variable frequency (TRACK) and modification of the span to a preset value (ZOOM).

An automatic function, if switched on, is indicated by the corresponding LED on the front panel of the display unit.

Caution!

- In the case of AUTO RANGE, especially in mode LOW NOISE, ensure that no problems occur due to non-linearities (e.g. intermodulation products) as an erroneous measurement may otherwise be made.
- RF attenuators of at least 10 dB are always switched on to protect the input attenuator and to avoid additional frequency response. In the case of measurements at highest sensitivity (but additional frequency response as soon as the source impedance deviates from 50 Ω), the RF attenuation can be reduced below a value of 10 dB by means of an entry using RF ATTENUATION MANUAL.


Screen display:




The RF attenuation can be entered via the numeric keypad, the STEP keys or the spinwheel. The attenuation value remains fixed and is not changed if the reference level is shifted.

Note:

If the RF attenuation is below 10 dB when switching off the instrument, the "RF-ATT. COUPLED" mode is automatically entered upon switching on again in order to prevent damage to the input attenuator caused by an exceeded level.




The RF attenuation is automatically changed by changing the reference level. The attenuation depends on the reference value and the operating mode selected (LOW NOISE, LOW DISTORTION, NORMAL).



Mixer reference level -20 dBm (for full deflection). The operating mode is displayed by inverting the softkey field. Sets step size of RF attenuation to 5 dB.



A switch is automatically made to AC coupling if the start frequency is larger than the limit frequency of the AC coupling (1 MHz).



Mixer reference level -40 dBm (for full deflection). The operating mode is displayed by inverting the softkey field. Sets step size of RF attenuation to 1 dB.



This function enables automatic tracking of the analyzer centre frequency with drifting signals. It corresponds to the function REF MARKER TRACK. PEAK SEARCH and MARKER TO CENTER FREQ. are carried out following each sweep. This is only possible as long as the drifting signal remains in the display range of a window on the screen or, with active threshold line, the signal level exceeds the threshold value. Otherwise, tracking is interrupted but remains active.



Switching on and off the AUTORANGE function for automatic adjustment of attenuation by determining the maximum amplitude and correction of the reference level (attenuation) following each complete sweep.



The RF ATTENUATION function is switched to COUPLED. The active AUTORANGE function is displayed by inverting the softkey field and by the LED in the AUTO field. The AUTORANGE function is switched off by pressing the softkey again.

The input of the span is activated. When the span is entered, the sweep is stopped at the marker position and the frequency measured using the built-in IF counter. Then the measured frequency, the new centre frequency and the selected span are set. This function corresponds to the MARKER ZOOM function.

The AUTORANGE function is automatically switched off if no stable condition is obtained after three sweeps (e.g. due to overloading or heavily varying signals).




COUPLED FUNCTIONS 15

Selection of menu for automatic coupling and manual setting of span, resolution bandwidth, video bandwidth and sweep time.

Screen display:



Submenu COUPLING MANUAL:




Main menu




Fixed setting of resolution bandwidth with facility for changing this function value by data entry.



Activation of automatic coupling of resolution bandwidth to span.



Fixed setting of video bandwidth with facility for changing this function value by data entry.



Activation of automatic of video bandwidth to resolution bandwidth and span.

SWEEP T.
MANUAL

Fixed setting of sweep time with facility for changing this function value by data entry.

SWEEP T.
COUPLED

Activation of automatic coupling of sweep time to video bandwidth, resolution bandwidth and span.

COUPLING
DEFAULT

Automatic coupling of resolution bandwidth, video bandwidth and sweep time to the span with the default values (cf. Fig. 2-4: Schematic display of coupling mode "COUPLING FUNCTIONS").

COUPLING
MANUAL

Selection of a submenu.

Coupling of resolution bandwidth, video bandwidth and sweep time to the span with selectable factors.

Submenu COUPLING MANUAL

RBW/VBW
PULSE


In the case of pulsed signals, it is usually desired that the signal provided by the resolution filter is displayed as unmodified as possible. It is therefore necessary to make the video bandwidth significantly larger than the resolution bandwidth. This can be achieved using this function. The displayed value of the resolution bandwidth corresponds to the pulse bandwidth of the filter (approx. 6-dB value). The video bandwidth is set to a factor of 10 larger than the resolution bandwidth.

RBW/VBW
SINE

The video bandwidth is approximately the same as the resolution bandwidth. This is also the default value since this results in no considerably longer sweep time and no negative influences on discrete (sinewave) signals.

RBW/VBW
NOISE


In the case of noise measurements, a video bandwidth much smaller than the resolution bandwidth is usually used to enable averaging of the displayed (video) signal. The RBW/VID:NOISE function is available for this purpose where a video bandwidth smaller by a factor of 10 is automatically used.



This function can be used to change the ratio RBW/VBW using the spinwheel **32**, the STEP keys **33**, **34** or by a numeric input **31**.



This function defines the number of selection filter bandwidths per span. The value can basically be set very high, but this has the disadvantage that the sweep time is correspondingly long (increases with the square of the filter bandwidth). In SPAN LOG mode the minimum value is limited to 5.



Using this function and a preset sweep time, especially when the limit values of 20 ms or 2000 s are reached, the optimum settings of the resolution and video bandwidths corresponding to the span can be automatically determined by pressing the softkey.

The change of the resolution bandwidth applies only for this setting. When this setting is changed again, the normal coupled function algorithm is applied.





Fig. 2-4.1 Overview of coupling functions



FREQUENCY 26

This menu enables universal entry of the start frequency, stop frequency, centre frequency and span. In addition to the usual combinations


centre frequency with span and
start frequency with stop frequency,

all other combinations are possible using the function FIXED, e.g.

start frequency with span or
stop frequency with span or
fixed start frequency with variable centre
frequency.

The function CENTER FREQUENCY is immediately active after pressing the hardkey FREQUENCY. The softkey field CENTER FREQUENCY is coloured accordingly and the command line activated for a frequency entry or variation.

Screen display:



Main menu



The start frequency can be changed by an entry or variation. If this key is pressed, the relationship to the stop frequency is displayed in the softkey field STOP FIXED.

The start frequency is fixed by pressing this key.

SPAN
MANUAL

The span can be changed by an entry or variation. The relationship to the centre frequency in the softkey field CENTER FIXED is displayed by pressing this key.

SPAN
FIXED

The span is fixed by pressing this key.

CENTER
MANUAL

The centre frequency can be changed by an entry or variation. The relationship to the span is displayed in the softkey field SPAN FIXED by pressing this key.

CENTER
FIXED

The centre frequency is fixed by pressing this key.

STOP
MANUAL

The stop frequency can be changed by an entry or variation. The relationship to the start frequency is displayed in the softkey field START FIXED by pressing this key.

STOP
FIXED

The stop frequency is fixed by pressing this key.

Supplementary menu FREQUENCY

FREQ.-
OFFSET

Entry of a frequency offset in the command line.

The deviation of the frequency displayed on the screen from the actual frequency is indicated by the field FRQOFS in the status line (A2) on the display.

CFSS*
.1 SPAN

The center frequency is changed by 10 percent of the span to higher or lower frequencies by pressing the STEP keys.

CFSS*
.5 SPAN

The center frequency is changed to a frequency 50 percent higher or lower by pressing the STEP keys.

CFSS*
MANUAL

The center frequency is entered as a numerical value or varied step by step.
Application: measurement of signals within specific frequency limits.

CFSS*
CENTER

The step size corresponds to the center frequency. This function is important when measuring harmonics. This key is pressed after tuning to the fundamental wave, and tuning to the harmonics takes place using the STEP key.

*Abbreviation for CENTER FREQUENCY STEP SIZE.



SPAN 27

Used to set the span. The display field is inverted. The current value of the span appears in the command line.

A variation is possible using the STEP keys and/or the spinwheel or by entering a number.

Screen display:



Switchover to zero span, i.e. no frequency variation is available anymore. If the input level is varied (amplitude modulation), a time/amplitude display of the input signal is obtained (similar to an oscilloscope display).



Switchover between linear and logarithmic frequency axis. The linear frequency axis is displayed with a relative scaling (10 divisions with span/10). The logarithmic frequency axis is displayed by dividing the sweep into linear subsweeps with absolute scaling (10 or 5 divisions per decade). The decades are additionally labelled at the bottom of the grid. The linear subsweeps are formed and calculated also with changes in frequency setting prior to the first sweep. All values displayed are backed up by measuring data. This is achieved by variable oversampling. For each subsweep the respective resolution bandwidth, the video bandwidth and the sweep time are automatically set, provided that the "COUPLED" modes are selected.



Entry of any span by means of a variation using the STEP keys 33, 34, the spinwheel 32 or by entering a number.



Sets the largest possible span.


Note:

The calculation of subsweeps and the logarithmic division takes a few seconds. It is therefore recommended to enter the required instrument settings (especially frequency parameters) in SPAN LIN mode before activating the SPAN LOG mode.

For entering the SPAN LOG mode, the stop-to-start-frequency ratio must exceed 1.4.

$$\frac{f_{Stop}}{f_{Start}} > 1.4$$

In this mode, the AUTORANGE and AUTOTRACK functions are not active. The frequency parameters can only be entered via the numeric keypad. The spinwheel and the STEP keys do not work (see above note).



HOLD 35

HOLD 35 can be used to call two different functional modes:

- switch-off of data variation
- switch-off of front panel keys and controls

Screen display:



Elimination of disable of all front panel controls by pressing both functions UNLOCK.



All front panel controls, i.e. also the functions PRESET 43 and POWER ON 46 are disabled (this is important when operating in cramped conditions in a vehicle).



The LED ENABLED goes out in the function field DATA VARIATION by pressing the softkey LOCK DATA, and data variation using the spinwheel 32 or the STEP keys 33, 34 is no longer possible.



Return to the last set menu.



UNITS 40

A menu of units is output on the screen. The corresponding softkey field is inverted and the current unit output in field (A11) on the screen.

Screen display:

dBm	dB μ V	dB μ A	dB	V	A	W
-----	------------	------------	----	---	---	---

Supplementary menu:

dB μ V/m	dB μ V/ MHz	dB μ V/ m MHz	dB μ A/m	dB μ A/ MHz	dB μ A/ m MHz	dBpW	PROBE CODE
--------------	--------------------	----------------------	--------------	--------------------	----------------------	------	---------------



etc.




Selection of required unit.

If the unit "dB" is selected, all displays (markers, display lines, etc.) are relative to the current reference level. The reference level is displayed in the unit selected before.

Switching on and off the coding of transducers connected to socket 39.

When connecting a transducer (also with correspondingly coded correction factor) the display "PROBE CODE" is activated automatically. The coded unit is displayed in the unit field (A11). The unit can be overwritten by means of the other softkeys, the correction factor being retained.


When the transducer is removed, the unit "dBm" is automatically selected.



LEVEL RANGE 41

Selection of menu for the displayed level range.

Screen display:



...



Selection of level range to be displayed. (The measurement of the specified range always takes place with the full resolution of the internal 12-bit A/D converter.)



The measurement is made linearly, the scale in dB or % (toggle function).




The inscription shows absolute values or values relative to the reference level (toggle function). If the inscription is in % in the case of a linear measurement, this key has no function.



REF LEVEL 42

Selection of menu for the reference level.

Screen display:




The field REFERENCE LEVEL is inverted. The command line contains e.g. REFERENCE LEVEL: -40 dBm. The reference level can be changed using the keyboard, STEP keys and spinwheel.

Caution:

If the AUTO RANGE function is active, the reference level is matched to the maximum signal following each sweep.



Entry of a mathematical offset of the reference level. The deviation of the displayed value from the physically set value is indicated by the readout of LVLOFS in the status line (A2) on the display.



The inscription shows absolute values or values relative to the reference level (toggle function). If the inscription is in % in the case of a linear measurement, this key has no function.



SAVE 29

Up to 9 instrument settings can be stored using SAVE and a subsequent digit. The stored setting can be additionally protected against overwriting by using SAVE ". " "digit". The write protection can be eliminated for the setting using RECALL ". " (also with PRESET).

Using SAVE 1 to 4, the current TRACE memory 1 to 4 is stored together with the instrument setting. Thus, the four trace memories remain stored even after switching off the instrument.



RECALL 30

The stored settings are made on the instrument using RECALL and a subsequent digit. The write protection for the stored setting is eliminated using RECALL ". ".

Using RECALL 1 to 4, the associated TRACE memory 1 to 4 is again copied into the respective TRACE. In order to avoid inadvertent overwriting, the respective TRACE memory is automatically switched to the operating mode VIEW.


The RECALL 0 function is used to obtain the basic setting of the instrument, which corresponds to the PRESET function.

However, in contrast to the PRESET function, the built-in self test is not performed.



COUPLING 36

The input can be either DC-coupled or AC-coupled using this function. The function is displayed on LEDs (AC or DC).



LOCAL 25

The keyboard functions are disabled in REMOTE mode (IEC bus remote control). The keyboard is enabled again by pressing the LOCAL key, and the instrument enters the LOCAL state.

2.3.7 RECEIVER

2.3.7.1 Theory of Operation

In the RECEIVER mode, the Spectrum Analyzer automatically operates with a frequency span set to zero, i.e. with fixed oscillator frequency.

The instrument is thus a fixed frequency receiver the receive frequency of which can be set by numeric input, by means of the STEP keys or by rotating the spinwheel in the entire frequency range. The bandwidth can be varied in the same manner in the range from 6 Hz to 3 MHz after pressing the bandwidth key.

For the RECEIVER mode in particular, the analyzer is provided with an AM IF amplifier with automatic level control (with AM over more than 60 dB), an FM IF limiter amplifier and AM or FM demodulators. The demodulated signals can be monitored via headphones. The internal loud-speaker only serves for acoustic indication.

The power output of the built-in AF amplifier is sufficient for operation of an external loud-speaker system which is not excessively loaded (with normal ambient noise level).

Unwanted noise is suppressed by a micro-processor-controlled squelch which can be set with respect to the response level.

The low-frequency signal (the demodulated IF signal) is displayed on the screen so that it can also be optically estimated and evaluated.

The demodulators are especially designed for the normal audio range <20 Hz to >20 kHz. Narrowband FM (modulation index <1 to 1) or broadband FM (modulation index up to about 50) can be used in FM operation, with AM modulation depths of <5 % up to max. 100 %.

The RECEIVER mode is largely separated from the main operating mode ANALYZER in order to enable rapid switching between these applications without the need for time-consuming new entry of parameters.

The major settings in the operating mode such as

- receive frequency
- reference level
- resolution and video bandwidth
- sweep time

can be set independently of the ANALYZER mode and are automatically set again when the operating mode is changed.

The only exception is the receiver frequency:

It is automatically changed in the ANALYZER mode when the centre frequency is changed by data input or variation or when, with active marker, the position of the reference marker is changed.

The ANALYZER mode thus enables selection of a signal with a marker. The signal can be immediately demodulated and evaluated in the time domain by switching to the RECEIVER mode.

In the RECEIVER mode, the function keys are to be used as in ANALYZER mode.

The following function keys are inoperative, however (since not relevant in this mode):

- MULTI MARKER 12
- SPAN 27
- LEVEL RANGE 41

The COUPLED FUNCTION menu allows for manually varying the resolution bandwidth, the video bandwidth and the sweep time. The softkeys "COUPLED" and "DEFAULT" have no functions.

In addition to the short and total calibration the HELP menu allows to calibrate the frequency offset (indicating the offset of the FM demodulator) by means of the CAL AF softkey.

The softkey GRID ABS/REL is omitted in the selection of the menu for the reference level REF LEVEL.


The softkeys AUTO RANGE...AUTO ZOOM are omitted in the menu selection for the AUTO functions.

The RECEIVER menu is followed by the explanation of the function menus the meaning of which is not the same as in ANALYZER mode.


2.3.7.2 RECEIVER Menu

In contrast to the ANALYZER mode, the RECEIVER mode is provided with a main menu which is automatically displayed when changing the mode via the MODE key. This menu can also be selected from the function menus via the MENU UP key.

Screen display:



Submenu DEMODULATION:



Main menu

RECEIVER
FREQ.

The receiver frequency can be changed using the spinwheel, the STEP keys or by entering numbers.

REF.
LEVEL

The reference level is entered. The current reference level is displayed in the command line in the selected unit. The reference level can be changed by numeric input or data variation.

BW
RES.

The resolution bandwidth is set by data input and variation.


With FM demodulation active, the associated span is simultaneously matched if the function FM COUPLED is active.

BW
VIDEO

The video bandwidth is set by data input and data variation.



The sweep time can be changed by numeric input, data variation via the spinwheel or using the STEP keys.



Selection of a submenu.

Switchover of AM and FM demodulator with setting of modulation depth.



The screen display can be switched between spectrum (frequency domain) and demodulated signal (time domain) using the function DISPLAY RF/AF. For display of the spectrum, the parameters of ANALYZER mode are used, i.e. centre frequency, span, reference level, sweep time and resolution bandwidths. These parameters can be selected independently in the RECEIVER mode. The display can thus be changed without the need for new entry of these values. Switching between the operating modes takes place via the MODE key.



After pressing this softkey, the volume of the signal can be varied by rotating the spinwheel.

A bar display for the volume (in order to avoid problems with SQUELCH mode) is to be found in the upper part of the display on the right.

Supplementary menu RECEIVER

The SQUELCH function is switched on for suppression of unwanted noise, if the receive signal is missing or too weak. The B1 bit (pin 15) at USER PORT B (configured to output) depends on the level of the demodulated signal.

Signal level $\geq$ squelch level: Bit B1 = 1

Signal level $<$ squelch level: Bit B1 = 0

If the signal level is below the squelch level, also a delay time can be set which has to pass before bit B1 becomes 0. However, the volume is immediately reduced in each case. USER PORT B can thus be used for control of tape recording depending on the applied signals ("Carrier Operated Relay" = C.O.R.) – provided that the port configuration corresponds to "output".



Switching on and off of the SQUELCH function for suppression of unwanted noise if the receive signal is missing or too weak.

Note:

The SQUELCH function is only active at the end of a sweep, i.e. a level variation during the sweep does not lead to immediate reaction by the SQUELCH function.



The SQUELCH threshold is selected via the threshold function by numeric input or variation using spinwheel or STEP keys.

Selection of this function leads to display of the spectrum in the frequency range, thus enabling optimum setting of the SQUELCH threshold. The demodulated signal is again displayed in the time range by pressing the softkey again or selecting another menu.

Submenu DEMODULATION

C.O.R DEL.
ON OFF

Switching on and off the delay time for control of bit B1 depending on the Squelch function.

C.O.R DEL.
TIME

Entering a delay time of 100 ms to 100 s for control of bit B1 depending on the Squelch function. The delay can be retriggered, i.e. if the signals falls below the Squelch level for less than the delay time, this does not lead to switchover of bit B1.

If a delay time is entered even though USER PORT B is configured to "input", the warning message

"Port B configured for Input"
is read out in the command line.

AM


Activation of AM demodulator with selection between 100 % and 10 % modulation depth for full deflection on the screen. The grid is labelled accordingly. The maximum modulation frequency is 20 kHz.

FM

FM
COUPLED

Activation of FM demodulator. It is possible to select a span between ± 200 kHz, ± 20 kHz, ± 2 kHz and ± 200 Hz. The selection of the span is automatically matched to the resolution bandwidth if a corresponding input is made and the function FM COUPLED is activated. The maximum modulation frequency is 20 kHz.


Explanation of the function menus whose meaning differs from that in ANALYZER mode:



DISPLAY LINE 6

The hardkey DISPLAY LINE is used to activate a menu for superimposing on the screen additional lines for measuring the signal. The status of the corresponding display line is indicated by inverted (= switched on) or coloured (= active input) representation of the softkey field.


Screen display:



Switching on and off of two horizontal display lines whose position can be changed using the spinwheel, the STEP keys or by entering numbers. The output depends on the selected type of demodulation, i.e. modulation depth in % for AM or span in kHz for FM demodulation. For switching off, the softkey must be pressed again.




Switching on and off of two vertical display lines whose position can be changed using the spinwheel, the STEP keys or by entering numbers. The output depends on the sweep time in μ s, ms or s. For switching off, the softkey must be pressed again.




MARKER 13

This function enables use of level/time markers.

Screen display: (FM demodulation)



Screen display: (AM demodulation)



The active marker is set to the greatest signal value.



The active marker is set to the next (greater) minimum.




The active marker is set to the next (smaller) maximum.




The reference marker is set to the maximum, the delta marker to the minimum of the signal. The current FM deviation is displayed in the marker field (A20). The measurement is performed automatically following each sweep.



The active marker is set to the smallest signal value.



The reference marker is set to the maximum, the delta marker to the minimum of the signal. The average value generated from the positive and negative peak deviation measured in this way results in the offset from the signal, referred to the receiver frequency. The offset is displayed in the marker field (A20). The measurement is performed automatically following each sweep.



The reference marker is set to the maximum, the delta marker to the minimum of the signal. The average value of the modulation depths measured in this way is displayed as modulation depth in % in the marker field (A20). The measurement is performed automatically following each sweep.



Activation of the reference marker. The marker time can be varied by numeric entry using the STEP keys and the spinwheel. It is switched off by pressing the softkey again.



Activation of the delta marker. If the delta marker has not been switched on before, a search for the peak is performed automatically.

The time difference and the modulation depth or span difference are displayed in the marker field (A20).

For switching off, press the softkey again.



FREQUENCY 26

This menu permits to enter the receiver frequency as well as the variation step sizes.

Screen display:

RECEIVER FREQ.	R.F. STEP SIZE			FREQ.- OFFSET
	MANUAL	R.F.	.5 RBW	.1 RBW

RECEIVER
FREQ.

The receiver frequency can be changed by input via the numeric keypad, using the spinwheel or the STEP keys.

R.F. S.
.5 RBW

The step size for variation of the receiver frequency using the STEP keys corresponds to half the resolution bandwidth.

R.F. S.
MANUAL

Using the STEP keys, the receiver frequency can be varied by the value entered in the step size function.

R.F. S.
.1 RBW

The step size for variation of the receiver frequency using the STEP keys corresponds to 1/10 of the resolution bandwidth.

R.F. S.
RF

This function reads in the current receiver frequency as new step size for the STEP variation.

FREQ.
OFFSET

Input of a frequency offset in the command line.

The deviation of the frequency displayed on the screen from the actual frequency is indicated by the field "FRQOFS" in the status line (A2).

2.3.8 SETUP

2.3.8.1 Theory of Operation

In the operating mode SETUP, all interfaces of the instrument can be configured for the operation:

- IEC bus
- PARALLEL INTERFACE
- USER PORT



In addition, the built-in real-time clock with calendar can be set. All current settings are visible on the display; the entries are made interactively following selection via the softkeys. All settings are stored in a CMOS RAM with battery backup so that they are preserved even when the instrument is switched off.

With the exception of HELP, all function keys are inoperative in this operating mode.

None of the data of the SETUP menu is changed by PRESET, except for the reference which is switched to "internal" and the user ports A and B which are programmed for input mode.

2.3.8.2 SETUP Menu

Screen display:



The IEC-bus address of the analyzer is selected by numeric input. Permissible values are the addresses 0 to 30; the address 20 is factory-set.

The terminator need not be selected since, in accordance with the definition in the standard IEC-625.2, the analyzer detects "Line Feed" (LF = 0AH) and/or the END message (EOI) in Listener mode and generates both in Talker mode.



Selection of the printer for hardcopy outputs from the display of the analyzer. The printer is selected using the STEP keys. The following printers are supported:

- R&S PDN
- R&S PDN COLOR
- R&S PUD3
- NEC P6/P7 and compatible 24-needle printers



Selection of the plotter for hardcopy outputs from the display of the analyzer. The plotter is selected using the STEP keys, the IEC-bus address of the plotter is selected by numeric input after pressing the softkey again. The following plotters are supported:

- R&S DOP
- HP GL (hp-Graphics language)

The colours can be selected via the plotter pens.

In general, the pen assignment is as follows:

Pen 1: grid, labelling, text
Pen 2: date and time, markers
Pen 3 to pen 6: TRACE 1 to TRACE 4



Configuration of USER PORT A (8 data lines) as input or output port. In input mode the current bit pattern is displayed, in output mode the bit pattern to be output can be changed by numeric input after pressing the softkey again.



Configuration of USER PORT B (4 data lines) as input or output port. In input mode the current bit pattern is displayed, in output mode the bit pattern to be output can be changed by numeric input after pressing the softkey again.



Input of the time in the 24-hour format via the numeric keypad. The time is output in the hardcopy output in the command line.



Switchover between internal and external reference frequency (10 MHz) (socket 76 at rear of instrument) by means of STEP keys.



Input of the date with day: month: year via the numeric keypad. The date is output in the hardcopy output in the command line.

2.4 Remote Control of Instrument

2.4.1 IEC Bus

The analyzer is fitted with an IEC bus interface as standard. The interface corresponds to the IEC 625-1 or IEEE 488.1 standard and to IEEE 488.2 also approved of by the IEC commission. This standard describes data transfer formats and common commands etc.

The bus connection socket **61** is fitted to the rear of the display unit. The analyzer is equipped with the 24-contact socket according to the IEEE 488 standard. The interface contains three groups of bus lines:

1. Data bus with 8 lines DIO 1 to DIO 8

Data transmission is bit-parallel and byte-serial with the characters in ISO 7-bit code (ASCII code).

DIO 1 represents the least significant bit and DIO 8 the most significant bit.

2. Control bus with 5 lines

This is used to transmit control functions:

ATN (Attention)
becomes active Low when addresses, universal commands or addressed commands are transmitted to the connected devices.

REN (Remote Enable)
enables the device to be switched to the remote status.

SRQ (Service Request)
enables a connected device to send a Service Request to the controller by activating this line.

IFC (Interface Clear)
is activated by the controller in order to set the IEC interfaces of the connected devices to a defined status.

EOI (End or Identify)
can be used to identify the end of data transfer and is used with a parallel poll.

3. Handshake bus with 3 lines

Used to control the data transfer timing.

NRFD (Not Ready For Data)
an active Low on this line signals to the talker/controller that one of the connected devices is not ready to accept data.

DAV (Data Valid)
is activated by the talker/controller shortly after a new data byte has been applied to the data bus.

NDAC (Not Data Accepted)
is held at active Low by the connected device until it has accepted the data present on the data bus

Detailed information on the data transfer timing is available in the IEC 625-1 standard.

According to the IEC 625-1 standard, devices controlled via the IEC bus can be equipped with different interface functions. Table 2-2 lists the interface functions applicable to the analyzer:

Table 2-2 Interface functions

Control characters	Interface function
SH1	Source Handshake function, complete capability
AH1	Acceptor Handshake function, complete capability
L4	Listener function, complete capability, unaddress if MTA
T6	Talker function, complete capability, capability to reply to serial poll, unaddress if MLA
SR1	Service Request function, complete capability
PP1	Parallel Poll function, complete capability
RL1	Remote/Local switchover function, complete capability
DC1	Device Clear function, complete capability
DT1	Device Trigger function, complete capability
C1, C2, C3, C11	Controller function, system controller, transmits IFC, REN and interface messages. Controller function can be transferred and received.

2.4.1.1 Setting the Device Address

The device address can be set in the SETUP menu using the IEC-bus function. The address between 0 and 30 is entered using the numeric keys and remains stored when the device is switched off. The instrument is factory-set to address 20.

The address is the decimal equivalent of bits 1 to 5 of the Talker or Listener address. This form is also used with the IEC-bus command of the controller.

2.4.1.2 Local/Remote Switchover

The device is in the Local state (manual mode) when it is switched on and after the PRESET key has been pressed.

If the analyzer is addressed as a Listener by a controller (using the BASIC commands IECOUT or IECLAD in the case of R&S controllers), it enters the Remote state in line with the standard and remains in this state after data transfer has been completed. This is indicated by the REMOTE LED. All controls on the front panel except the LOCAL, PRESET and ON keys are disabled.

There are two methods to return to the Local state:

- by the addressed command GTL (Go to Local) from the controller.
- by pressing the LOCAL key. Data output from the controller to the analyzer should be stopped before pressing the LOCAL key for otherwise the analyzer will immediately enter the Remote state again. The function of the LOCAL key can be disabled by the controller by sending the universal command LLO (Local Lockout).

The other device settings are not changed when switching from Remote to Local state or vice versa.

The softkey menus are not indicated in the Remote state, since proper operation is not possible.

When the analyzer is switched to the Local state, the respective main menu of the current operating mode or, in ANALYZER mode, the Frequency menu is indicated.

2.4.1.3 Interface Messages

Interface messages (according to IEC 625-1/IEEE 488 standard) are transmitted to the device on the data lines where the Attention line ATN is active (Low).

2.4.1.3.1 Universal Commands

The universal commands have codes between 10 and 1F hexadecimal (see Table 2-5). They act, without previous addressing, on all devices connected to the bus.

Table 2-3 Universal commands

Command	Basic command with R&S controllers	Function
DCL (Device Clear)	IECDCL	Aborts processing of the currently received commands and sets the command processing software to a defined initial status. The device setting is not changed.
LLO (Local Lockout)	IECLLO	The LOCAL key is disabled.
SPE (Serial Poll Enable)	IECSPE *	Ready for serial poll.
SPD (Serial Poll Disable)	IECSPD *	End of serial poll.

* The BASIC command "IECSPL adr, status" contains the commands "IECSPE" and "IECSPD" and additionally reads the status of the device with address "adr" and stores this in the integer variable "status".

2.4.1.3.2 Addressed Commands

The addressed commands have codes between 00 and 0F hexadecimal (see Table 2-5). They only act on devices addressed as Listeners (by the BASIC command "IECLAD addr").


Table 2-4 Addressed commands

Command	Basic command with R&S controllers	Function
SDC (Selected Device Clear)	IECSDC	Aborts processing of the currently received commands and sets the command processing software to a defined initial status. The device setting is not changed.
GTL (Go To Local)	IECGTL	Change to Local state (manual operation)
GET (Group Execute Trigger)	IECGET	Starts a sweep

Table 2-5 ASCII/ISO and IEC-character set

Control characters					Numbers and special characters					Upper-case letters					Lower-case letters				
0	NUL		16	DLE		32	SP	48	0	64	@	80	P	96	.	112	p		
1	SOH	GTL	17	DC1	LLO	33	!	49	1	65	A	81	Q	97	a	113	q		
2	STX		18	DC2		34	"	50	2	66	B	82	R	98	b	114	r		
3	ETX		19	DC3		35	#	51	3	67	C	83	S	99	c	115	s		
4	EOT	SDC	20	DC4	DCL	36	\$	52	4	68	D	84	T	100	d	116	t		
5	ENQ	PPC	21	NAK	PPU	37	%	53	5	69	E	85	U	101	e	117	u		
6	ACK		22	SYN		38	&	54	6	70	F	86	V	102	f	118	v		
7	BEL		23	ETB		39	'	55	7	71	G	87	W	103	g	119	w		
8	BS	GET	24	CAN	SPE	40	(	56	8	72	H	88	X	104	h	120	x		
9	HT	TCT	25	EM	SPD	41	)	57	9	73	I	89	Y	105	i	121	y		
10	LF		26	SUB		42	*	58	:	74	J	90	Z	106	j	122	z		
11	VT		27	ESC		43	+	59	;	75	K	91	[	107	k	123	{		
12	FF		28	FS		44	,	60	<	76	L	92	\	108	l	124			
13	CR		29	GS		45	-	61	=	77	M	93	]	109	m	125	}		
14	SO		30	RS		46	.	62	>	78	N	94	^	110	n	126	~		
15	SI		31	US		47	/	63	? / UNL	79	O	95	-	111	o	127	DEL		
Addressed commands			Universal commands			Listener addresses				Talker addresses				Secondary addresses and commands					

Code:



2.4.1.4 Device Messages

Device messages (to IEC 625-1) are transmitted on the data lines, in which case the Attention line is High, i.e. not active. The ASCII code (ISO 7-bit code) is used (see Table 2-5).

As can be seen in Table 2-6, the device messages can be grouped according to two different aspects.

Tabelle 2-6 Device messages

Type of commands	Direction of transfer	
	Messages received by the analyzer	Messages sent by the analyzer
Device independent (common) commands (in line with the IEEE 488.2 standard)	see Table 2-7	see Table 2-8
Device-specific commands (dependent on device characteristics)	see Table 2-9	see Table 2-9

In the following text, device messages received by the analyzer are referred to as commands.

Commands with a "?", such as "FREQUENCY: CENTER?" request the analyzer to output a set value where the same format is used as in the command table. For the given example, this is:

"FREQUENCY: CENTER 123.45678E + 6",

where the basic unit always applies (Hz in this case).

2.4.1.4.1 Commands Received by the Analyzer in Listener Mode (Controller to Device Messages)

Input buffer:

All commands received are buffered in a memory of max. 2560 bytes; it is also possible to process command lines which are longer. In this case, the part of the command line which was first received is already processed in the device.

Command syntax:

Fig. 2-5 shows the syntax of a command line (program message). Every command line must end with a terminator.

Terminators:

- New line (ASCII code 10 decimal)
- End (EOI line active) together with the last useful character of the command line or the new line character.

Since the carriage return character (ASCII code 13 decimal) is permissible as a filler without effect before the terminator, the combination of carriage return + new line is permissible.

All IEC-bus controllers from Rohde & Schwarz send terminators accepted by the device as standard. A command line may require more than one line on the controller screen since it is only limited by the terminator. The terminator is automatically added to the end of command text with most IEC-bus controllers.

Separators:

A command line may contain several commands (program message units) separated by semi-colons (;).

Command structure:

A command may consist of the following parts:

- Only a header
Example: *RST
- Header and question mark (Query)
Example: F:C?

This combination requests the analyzer to transfer the desired data to an output buffer in order to transfer them via the IEC bus as soon as it is addressed as a Talker (see Section 2.4.1.4.2).

- Header and number

Examples: F:C 123.5E6
F:C 123.5MHZ

To remain in accordance with the IEEE 488.2 standard, the header and number(s) must be separated by at least one space (ASCII code 32 decimal). In the case of device-specific commands, the number can be supplemented by a unit.

- Header and string

Example: SPAN FULL

The headers and their meanings are explained in Sections 2.4.1.4.3 and 2.4.1.4.4.

Lower case/upper case letters:

Lower case letters are permissible and are equivalent to the corresponding upper case letters. Thus units can be used in the usual form (e.g.: dBm) instead of the notation using upper case letters which is also permissible (e.g. DBM).

Spaces:

Additional spaces may be inserted at the following points:

- before a header;
- between header and number;
- before and after commas (,) and semicolons (;)
- before the terminator.

Numeric values:


Only decimal values are allowed as numeric values, the following notations are permissible:

- With and without sign
e. g. 5, +5, -5
- With and without decimal point, any position of decimal point is permissible.
e. g. 1.234, -100.5, .327


- With or without exponent to base 10, "E" or "e" is used as the exponent character.
e. g. .451, 451E-3, +4.51e-2
- The exponent is permissible with or without a sign, also a space is permissible instead of the sign.
e. g. 1.5E+3, 1.5E-3, 1.5E 3
- Leading zeros are permissible in the mantissa and exponent.
e. g. +0001.5, -01.5E-03
- The length of the number, including the exponent, may be up to 20 characters. The number of digits for the mantissa and exponent is only limited by this condition. Digits which exceed the resolution of the device are rounded up or down; they are always considered for the order of magnitude (power of ten).
e. g. 150000000, 0.00000032

Note: Specification of the exponent alone (e.g.: E-3) is not permissible, 1E-3 is correct).

Command line



Zahlenwert



SP: Any character with ASCII code 0 to 9 and 11 to 32 decimal, especially space.

Fig. 2-5 Syntax diagram of a command line

2.4.1.4.2 Messages Sent by the Analyzer in Talker Mode (Device to Controller Messages)

The device sends messages via the IEC bus if it

- has been requested to provide data in its output buffer by one or more query messages with a question mark within one command line,
- indicates by setting bit 4 (message available) in the status byte that the requested data are now present in the output buffer (see also Section 2.4.1.5), and
- has been addressed as a talker (BASIC command "IECIN adr, string variable").

Note that the command line with the data request must be transmitted directly before the talker is addressed. If another command line is present in between, the output buffer is cleared. The maximum length of the output buffer is 2560 bytes.

A query message is formed by adding a question mark "?" onto the header of Table 2-9, e.g. "SPAN?".

If the device is addressed as a Talker directly after the query message, the bus handshake is disabled until the requested data are available. This simple synchronization procedure is certainly meaningful with the analyzer if the execution of a query message can take place independent of the execution and termination of a sweep.


The syntax of the messages sent by the analyzer is shown in Fig. 2-6. The syntax is similar to that for commands received by the FSA.

A new line (ASCII code 10 decimal) together with end (line EOI active) is used as terminator.


The transmission of "header and numbers" makes it possible that the messages sent by the analyzer can again be returned to the analyzer in the same form, without any amendments as setting commands. Thus a setting made on the keyboard can be read, stored in the controller and repeated later via the IEC bus.

- If the analyzer receives several query messages, it also returns several messages within one line separated by semicolons (;).
- Several numbers can be sent as a reply to certain query messages (e.g. MARKER?), they are separated by commas (,).
- Header and numbers are always separated by spaces.
- Headers only consist of upper-case letters and the characters ":", "_", and "*".
- The syntax of the numbers is described in Fig. 2-6. The exact form of the numbers of each message is described in Tables 2-8 and 2-9.
- Messages sent by the analyzer do not contain units. In the case of physical variables, the numbers are referred to the basic unit specified in Table 2-9.

Output message line



Number



SP: Space (ASCII code 32 decimal)
 ASCII text: Reply to command *IDN? (see Table 2-8)

Fig. 2-6 Syntax diagram of messages sent by the analyzer

2.4.1.4.3 Device-independent Commands (Common Commands)

These commands are listed in Tables 2-7 and 2-8 and can be split up into the following groups:

- Commands which refer to the Service Request function with the associated status and mask registers
- Commands for device identification
- Commands which refer to the Parallel Poll function
- Commands for triggering sequences

- Commands for device-internal sequences (reset, calibrate) and for synchronizing sequences.

These are taken from the IEEE 488.2 standard, which ensures that these commands have the same effect in different devices.

The headers of these commands consist of a star (*) followed by three letters.

Table 2-7 Device-independent commands (common commands) received by the analyzer

Command	Number, range	Meaning
*RST	---	Reset Acts on the instrument setting like the PRESET key, however without automatic self-test. This command does not change the status of the IEC-bus interface, the set IEC-bus address, the mask register of the Service Request function and the output buffer. A current Service Request is only reset if it has not been produced by a message in the output buffer.
*PSC	0 to 65535	Power On Status Clear (reset on power-up) If >0: with power-up, the Service Request Enable mask register (SRE) and the Event Status Enable mask register (ESE) are cleared in addition. If 0: the above-mentioned registers retain their contents when the device is switched on and off. This enables a Service Request when the device is switched on.
*OPC	---	Operation Complete (ready signal) Sets bit 0 (Operation Complete) in the ESR, if all previous commands have been processed (see Section 2.4.1.7).
*CLS	---	Clear Status • Sets the status registers (ESR and STB) to zero. The mask registers of the Service Request function (ESE and SRE) are not changed. • Clears the output buffer. A present Service Request is cleared (see Section 2.4.1.5).
*ESE	0 to 255	Event Status Enable The ESE mask register is set to the specified value which is interpreted as a decimal number (see Section 2.4.1.5).
*SRE	0 to 255	Service Request Enable The SRE mask register is set to the specified value which is interpreted as a decimal number (see Section 2.4.1.5).

Command	Number, range	Meaning
*PRE	0 to 65535	Parallel Poll Enable The Parallel Poll Enable mask register is set to the specified value which is interpreted as a decimal number (see Section 2.4.1.5).
*PCB	0 to 30	Pass Control Back Specify the address of the controller to which the bus control is to be returned after completion of the plotter output.
*TRG	---	Trigger Starts a sweep. Same function as GET message.
*RCL	1 to 9	Recall Recall a stored device setting. Same function as RECALL key 30.
*SAV	1 to 9	Save Save a current device setting. Same function as SAVE key 29.
*WAI	---	Wait To Continue Only process the subsequent commands when all previous commands have been completely executed (see Section 2.4.1.7).

Table 2-8 Device-independent commands sent by the analyzer

Command	Output message Data value		Meaning
	No. of digits	Range	
*IDN?	23	Alpha-numeric	Identification Query The following identification text is sent via the IEC bus as a reply to the IDN? command (always without header). Example: Rohde&Schwarz, FSB,0,1.0 Rohde&Schwarz = Manufacturer FSB = model 0 = reserved for serial number (not used with the analyzer) 1.0 = firmware version (for example)
*PSC?	1	0 or 1	Power On Status Clear Query To read the status of the Power On Clear flag, see *PSC in Table 2-7
*OPC?	1	1	Operation Complete Query (ready message) The message "*OPC1" is entered into the output buffer and bit 4 (message available) set in the status byte if all previous commands have been completely executed. Bit 0 (operation complete) is also set in the ESR (see Section 2.4.1.7).
*ESR?	1 to 3	0 to 255	Event Status Register Query The contents of the ESR are output in decimal form and the register then set to zero.
*ESE?	1 to 3	0 to 255	Event Status Enable Query The contents of the ESE mask register are output in decimal form.
*STB?	1 to 3	0 to 255	Status Byte Query The contents of the status byte are output in decimal form.
*CAL?	1	0 or 1	Calibration Query A short calibration is triggered. The reply 0 is output if the calibration is terminated properly, otherwise reply 1.

Command	Output message Data value		Meaning
	No. of digits	Range	
*SRE?	1 to 3	0 to 255	Service Request Enable Query The contents of the SRE mask register are output in decimal form.
*TST?	1 to 3	0 to 255	Self-Test Query Execution of device self-test routine. An output value "0" indicates that the self-test has been terminated correctly.
*IST?	1	0 or 1	To read the current device status (see Section 2.4.1.5)
*PRE?	1 to 3	0 to 255	The contents of the Parallel Poll Enable register are output in decimal form.

2.4.1.4.4 Device-specific Commands

All analyzer functions which can be set using the keyboard can also be controlled via the IEC bus. The effect of the setting commands is the same as the corresponding entry via the keyboard.

According to the output in the display, the values of all setting parameters can also be read out via the IEC bus, especially the marker frequency and marker level values.

Table 2-9 shows the setting commands and the data request commands with the associated messages sent by the analyzer.

The headers are the same as the key designations or similar to them. This results in easy-to-read (self-documenting) programs.

The headers can be abbreviated by omitting any characters at the end (e.g. LEV instead of LEVEL). The shortest possible notation is shown in Table 2-9 in **bold print**.

Many headers consist of several parts separated by colons (:), e.g. "FREQUENCY:START". The abbreviations can be used in each part of the header (e.g.: "F:STA").

Certain headers contain the underline character (ASCII code 95 decimal) to facilitate reading.

All setting commands which must be assigned values are listed in Table 2-9 in the column "Data". Certain commands may also have a character string as the data, e.g. "SPAN FULL" for a frequency span across the complete frequency range of 2 GHz, or "SPAN ZERO" for receiver mode.

A unit can be added directly to the numbers in the setting commands (e.g.: 125.3 MHz, or also 125.3E3 kHz). The permissible units are listed in Table 2-9. They may also be abbreviated and written with lower-case or upper-case letters. If no unit is used, the respective default unit applies (Hz, dBm, dBV, %, dB, see Table 2-9).

Table 2-9 Device-specific setting commands

Command	Data	Units	Meaning
ATTENUATION ATTENUATION?	0 to 81 dB INCREMENT DECREMENT COUPLED	DB -- -- --	Preamplification Increment Decrement Coupling on
AUTO:RANGE :AC_DC	ON OFF ON OFF	-- -- -- --	Auto range on Auto range off Automatic input coupling AC on off
BANDWIDTH:RESOLUTION :RESOLUTION? :VIDEO :VIDEO?	6 Hz to 3 MHz INCREMENT DECREMENT COUPLED FIXED 1Hz, 3 Hz, 10 Hz, to 3 MHz INCREMENT DECREMENT COUPLED FIXED	HZ (default) KHZ MHZ GHZ -- -- -- -- -- -- HZ (default) KHZ MHZ GHZ -- -- -- --	Resolution bandwidth Increment Decrement Automatic coupling on Automatic coupling off Video bandwidth Increment Decrement Automatic coupling on Automatic coupling off
CALIBRATION:SHORT :TOTAL :AF	-- -- --	-- -- --	Short calibration Total calibration Calibration AF unit
CAL_CORRECTION	ON OFF	-- --	Incorporation of cal cor- rection values
CAL_DATA?	--	--	Binary readout of calibration data

Command	Data	Units	Meaning
COUPLING:DEFAULT	--	--	Automatic coupling of resolution bandwidth, video bandwidth and sweep time to span
:RES-VIDEO :RES-VIDEO?	0,01...100 INCREMENT DECREMENT	-- -- --	Coupling factor Res./video bandwidth Increment Decrement
:SPAN-RES :SPAN-RES?	SINE PULSE NOISE	-- -- --	Factor = 1 Factor = 0,1 Factor = 10
:SPAN-RES :SPAN-RES?	1...9999 INCREMENT DECREMENT	-- -- --	Coupling factor Span/res. bandwidth Increment Decrement
:INPUT	AC DC	-- --	Input coupling AC Input coupling DC
DATE DATE?	dd, mm, yy	--	Date (day, month, year)
DELTAMARKER	Start frequency ... Stop frequency 0...Sweep time INCREMENT DECREMENT ON OFF	HZ KHZ MHZ GHZ S MS US NS -- -- -- --	Change delta marker frequency (only with span > 0) Change delta marker time (only with span > 0Hz) Increment Decrement Delta marker on Delta marker off
DELTAMARKER?	--	--	Output of delta marker frequency and level (span > 0 Hz) or time and level (span = 0 Hz)
DELTAMARKER:FREQUENCY?	--	--	Output of delta marker frequency (span > 0 Hz)
:TIME?	--	--	Output of delta marker time (span = 0 Hz)
:LEVEL?	--	--	Output of delta marker level

Command	Data	Units	Meaning
DELTAMARKER:PEAK	--	--	Peak-Search
:NEXT_PEAK	--	--	Next Peak Search
:MIN	--	--	Minimum Search
:NEXT_MIN	--	--	Next Min Search
:PHASE_NOISE	ON	--	Phase noise marker on
	OFF	--	Phase noise marker off
:COUNT	ON	--	Frequency counter
	OFF	--	switched on
:N_DB_DOWN	0to150 dB	DB	N-DB-DOWN marker
	ON		on
	OFF		off
:CENTER	--	--	DELTA MARKER value becomes
:START	--	--	- centre frequency
:STOP	--	--	- start frequency
:REFERENCE	--	--	- stop frequency
	--	--	- reference level
:CF_STEP	--	--	Step size of centre frequency = delta marker frequency
:SPAN	--	--	Span = delta marker frequency
:NEXT_MULTI	--	--	Delta marker to next multimarker
:PREVIOUS_MULTI	--	--	Delta marker to previous multimarker
:SHAPE_FACTOR:F_60DB_3DB?	--	--	Shape factor 60 dB/3 dB
:F_60DB_6DB?	--	--	Shape factor 60 dB/6 dB
DETECTOR	COUPLED	--	Detector mode
	AUTOPEAK	--	- coupled
	POS_PEAK	--	- normal
	NEG_PEAK	--	- positive peak
	SAMPLE	--	- negative peak
		--	- sample
DISPLAY:LINE1	(Ref. Level- Level Range)	DBM	Display line 1
:LINE1?	... Ref. Level		
	INCREMENT	--	Increment
	DECREMENT	--	Decrement
	ON	--	on
	OFF	--	off
:LINE2	"	"	Display line 2
:LINE2?			

Command	Data	Units	Meaning
ERRORS?	--	--	Output of error number 0 No error 20 Parser fatal error 21 Misplaced token 22 Incorrect syntax 23 Illegal command 24 Ambiguous command 25 Illegal character data 26 Ambiguous character data 27 Numeric data out of range 28 Illegal suffix 29 Ambiguous suffix 30 *OPC failed 31 Marker not active 32 Deltamarker not active 33 Multimarker not active 34 Output queue overflow; some output data lost 35 Previous output not read by controller or attempt to read output data from empty output queue 36 Invalid Block Data; Transmission aborted 39 Line not active 40 Invalid Shape factor 41 Transducer Factor Table not active
ERA?	--	--	Output event status register A
ERA ERA?	0...255	--	Enable register for event status register A

Command	Data	Units	Meaning
LEVEL:MIXER :MIXER? :RANGE :RANGE? :REFERENCE :REFERENCE? :REFERENCE:OFFSET :REFERENCE:OFFSET?	-10 to -140 dBm INCREMENT DECREMENT NORMAL LOW_NOISE LOW_DISTORTION COUPLED	DBM -- -- -- -- -- --	Mixer level Increment Decrement normal low noise low distortion coupled
	110 dB 100 dB 50 dB 20 dB 10 dB 1 dB	DB	Display range level
	-130 to + 30 dBm INCREMENT DECREMENT	DBM -- --	Reference level Increment Decrement
	-116 to + 120 dB INCREMENT DECREMENT	DB -- --	Reference level offset
LIMIT_CHECK:LINE1 : : : : :LINE8	ON OFF	-- --	Limit-Check on off
	UPPER LOWER	-- --	Check upper limit lower limit
	TRACE, trc_nr	--	Selection of trace to be tested
LINESTYLE:GRID LINESTYLE:DISPLAY:LINE1 :LINE2 :FREQUENCY:LINE1 :LINE2	SOLID DASHED DOTTED DASHED-DOTTED	-- -- -- --	Grid line style Solid Dashed Dotted Dashed-dotted
	"	"	Display line style 1
	"	"	Display line style 2
	"	"	Frequency line style 1
	"	"	Frequency line style 2

Command	Data	Units	Meaning
MARKER	Start frequency ... Stop frequency	HZ KHZ MHZ GHZ	Change marker frequency (only with span > 0 Hz)
	0...sweep time	S Ms Us Ns	Change marker time (only with span = 0 Hz)
	INCREMENT DECREMENT	-- --	Increment Decrement
	ON OFF	-- --	Marker on Marker off
MARKER?	--	--	Output of marker frequency and level (span > 0 Hz) or time and level (span = 0 Hz)
MARKER:FREQUENCY?	--	--	Output marker frequency (span > 0 Hz)
:TIME?	--	--	Output marker time (span = 0 Hz)
:LEVEL?	--	--	Output marker level
:FORM	TRIANGLE CIRCLE CROSS X-CROSS	-- -- -- --	Change marker form Triangle Circle Cross (vertical) Cross (diagonal)
MARKER:PEAK	--	--	Peak Search
:NEXT_PEAK	--	--	Next Peak Search
:MIN	--	--	Minimum Search
:NEXT_MIN	--	--	Next Min Search
:NOISE	ON OFF	-- --	Noise marker on Noise marker off
:COUNT	"	--	Frequency counter switched on
:FIXED	"	--	"Freeze" marker
:TRACK	"	--	Signal track on/off
:ZOOM	0 to 2 GHz	HZ KHZ MHZ GHZ	Signal zoom

Command	Data	Units	Meaning
:CENTER	--	--	Marker to - centre frequency - start frequency - stop frequency - reference level
:START	--	--	
:STOP	--	--	
:REFERENCE	--	--	
:CF_STEP	--	--	Step size of centre frequency = marker frequency
:NEXT_MULTIMARKER	--	--	Marker to next multimarker
:PREVIOUS_MULTIMARKER	--	--	Marker to previous multimarker
MODE	ANALYZER RECEIVER SETUP	-- -- --	Operating mode Analyzer Receiver Setup
MONITOR	ON OFF	-- --	Monitor on Monitor off
MULTIMARKER	Start frequency ... Stop frequency	HZ KHZ MHZ GHZ	Set multimarker
MULTIMARKER?	--	--	Output of number, frequency and level of all active multimarkers
MULTIMARKER:FREQUENCY?	--	--	Output of all multimarker frequencies
:LEVEL?	--	--	Output of all multimarker levels
:PEAK	--	--	Peak Search
:SET	--	--	Set multimarker to marker position
:CLEAR	--	--	Clear multimarker at marker position
:CLR_ALL	--	--	Clear all multimarkers
:A? to :F?	--	--	Output of level and frequency of multimarkers A to F
:FREQUENCY:A? to :FREQUENCY:F?	-- --	-- --	Output of frequency of multimarkers A to F
:LEVEL:A? to :LEVEL:F?	-- --	-- --	Output of level of multimarkers A to F

Command	Data	Units	Meaning
N_DB_DOWN:LINE :LINE?	0... Level Range INCREMENT DECREMENT ON OFF	DB -- -- -- --	N-dB-down line Increment Decrement on off
PLOT:ADDRESS :ADDRESS? :CURVE :SCREEN :TYPE	0 to 30 -- -- HP_GL DOP	-- -- -- -- --	IEC-bus address of plotter Plot curve Plot screen Plotter code: HP-GL DOP
PRINT PRINT:TYPE	-- PDN PDN_COLOR PUD3 NEC_P6	-- -- -- -- --	Hardcopy on printer Type of printer: R&S PDN R&S PDN Color R&S PUD3 NEC P6/P7
PROBE_CODE	ON OFF	-- --	Coding socket on Coding socket off
REFERENCE	INTERNAL EXTERNAL	-- --	Internal reference External reference
REFERENCE:LINE :LINE?	(Ref.Level - Level Range) ... Ref.Level INCREMENT DECREMENT ON OFF	DBM -- -- -- --	Reference line Increment Decrement on off
RESOLUTION:COUNTER	10 kHz 1 kHz 100 Hz 10 Hz 1 Hz 0.1 Hz	HZ	Resolution of frequency counter
SCALING:GRID:LINEAR	--	--	Linear scaling in %
:GRID:LOG	--	--	Linear scaling in dB
:ABSOLUTE	--	--	Scaling in absolute values
:RELATIVE	--	--	Scaling referred to reference level

Command	Data	Units	Meaning
SCREEN:BRIGHTNESS :BRIGHTNESS?	0 to 63	--	Brightness
:COLOR:GRID :GRID?	0-15, 0-15, 0-15	--	Colour (R, G, B) Grid
:CURVE1 :CURVE1?	0-15, 0-15, 0-15	--	Curve 1
:CURVE2 :CURVE2?	0-15, 0-15, 0-15	--	Curve 2
:SOFTKEY :SOFTKEY?	0-15, 0-15, 0-15	--	Softkeys
:BACKGROUND :BACKGROUND?	0-15, 0-15, 0-15	--	Background
:DEFAULT	--	--	Default colour
:COLOR:SET_DEFAULT	--	--	Setting the default colour
SERVICE SERVICE?	a, bb, cc, ddddd	--	Service functions: dddd = 0, if no entry of data is required
SPAN SPAN?	0 to 2 GHz FULL ZERO INCREMENT DECREMENT COUPLED FIXED LINEAR LOGARITHMIC	Hz (Default) KHz MHz GHz -- -- -- -- -- -- -- --	Frequency range 0 to 2 GHz 0 Hz Increment Decrement Frequency coupling on Frequency coupling off linear frequency axis logarithmic frequency axis
SWEEP:TIME :TIME?	(Span = 0 Hz:) 200 μ s 2 ms 400 μ s 4 ms 800 μ s 8 ms 1 ms 10 ms (Span $\geq$ 0 Hz:) 20 ms to 1980 s INCREMENT DECREMENT COUPLED FIXED	S (default) MS US NS -- -- -- --	Sweep time Increment Decrement Coupling on Coupling off
:CONTINUOUS :DISPLAY	--	--	Continuous sweep
:SINGLE	ON OFF	-- --	Display on/off for single Sweep
:START	--	--	Single sweep
	--	--	Restart of sweep

Command	Data	Units	Meaning
TERMINATOR	LF_EOI EOI	--	Set terminator for data output
TEXT:LINE1 :LINE1?	#0...	--	Text line 1
:LINE2 :LINE2?	#0...	--	Text line 2
THRESHOLD:LINE :LINE?	(Ref. level Level range) ... Ref. level INCREMENT DECREMENT ON OFF	DBM -- -- -- --	Threshold line Increment Decrement on off
TIME TIME?	hh, mm, ss	--	Time
TIME:LINE1 :LINE1?	0 ... sweep time INCREMENT DECREMENT ON OFF	S Ms Us Ns -- -- -- --	Time line 1 Increment Decrement on off
:LINE2 :LINE2?	"	"	Time line 2
TOLERANCE:LINE1 : : :LINE8 :LINE1? : : :LINE8?	n, freq, lvl (, freq, lvl ...) ON OFF CLEAR COPY,line_nr SHIFT,freq,lvl	-- (n) HZ (freq) KHZ MHZ GHZ DBM (lvl)	Enter sample points of tolerance lines: n: number of sample points (max. 16) freq: sample point frequency lvl: sample point level Tolerance line on off Copy to line_nr Shift by freq: Frequency difference lvl: level difference

Befehl	Daten	Einheiten	Bedeutung
TRACE?	--	--	New start of sweep and readout of data
TRACE:WRITE	1...4	--	New start of sweep and writing of trace buffer n
:MAXHOLD	1...4	--	Max. hold buffer n
:AVERAGE	1...4	--	Average buffer n
:AVERAGE:SAMPLES :SAMPLES?	0...32767	--	Number of sweeps for average
:VIEW	1...4	--	Stop writing to buffer n
:BLANK	1...4	--	Clear buffer n
:COPY	1...4, 1...4 (n) , (m)	--	Copy buffer n → m
:DIFFERENCE	2...4	--	Form difference Trace 1 = trace 1 – trace n
	REF_LINE	--	Trace 1 = trace 1 – reference line
	OFF	--	Difference formation off
:BLOCK:T_1 bis :T_4	#0....	--	Write binary data to traces 1 to 4
:T_1? bis :T_4?	#0....	--	Read out traces 1 to 4 binary
:RESTORE:T_1 bis :T_4	#0...	--	Write binary data to traces 1 to 4 and restore hardware setting
TRANSDUCER:FACTOR1 : : :FACTOR4 :FACTOR1? : : :FACTOR4?	n, freq, lvl (, freq, lvl ...)	-- (n) HZ (freq) KHZ MHZ GHZ DB (lvl)	Enter tables w. sample points for antenna correction n: number of sample points (max. 25) freq: sample point frequency lvl: sample point level Correction - on - off - clear table - copy to tab_nr
	ON OFF		
	CLEAR COPY,tab_nr		

Command	Data	Units	Meaning
TRIGGER:FREE :LINE :VIDEO :EXTERNAL :SLOPE :LEVEL :LEVEL?	--	--	Mode of triggering: Free run
	--	--	Line
	--	--	Video
	--	--	Extern
	POSITIVE NEGATIVE	-- --	positive edge negative edge
	0 to 63	--	Trigger level (only for TRIGGER:VIDEO, TRIGGER:EXTERNAL)
	INCREMENT DECREMENT	-- --	Increment Decrement
			Output of trigger level
UNIT	DBM	--	Output unit: dBm
	DB	--	dB
	DBUV	--	dB μ V
	DBUV_M	--	dB μ V/m
	DBUV_MHZ	--	dB μ V/MHz
	DBUV_MMHZ	--	dB μ V/mMHz
	DBUA	--	dB μ A
	DBUA_M	--	dB μ A/m
	DBUA_MHZ	--	dB μ A/MHz
	DBUA_MMHZ	--	dB μ A/mMHz
	DBPW	--	dBpW
	V	--	V
	A	--	A
	W	--	W
USER_PORT:A :A? :B :B?	INPUT OUTPUT 0 to 255	-- -- --	USER PORT A
	INPUT OUTPUT 0 to 15	-- -- --	USER PORT B

Additional commands for RECEIVER mode

Command	Data	Units	Meaning
COR_DELAY	100 ms to 100 s	S Ms Us Ns	Delay time Carrier operated Relay
	INCREMENT DECREMENT	-- --	Increment Decrement
	ON OFF	-- --	on off
DELTAMARKER	0 ... sweep time	S Ms Us Ns	Delta marker
	INCREMENT DECREMENT	-- --	Increment Decrement
	ON OFF	-- --	Delta marker on Delta marker off
DELTAMARKER?	--	--	Output of delta marker time and level
DELTAMARKER:TIME?	--	--	Output of delta marker time
:LEVEL?	--	--	Output of delta marker level
:MOD_DEPTH?	--	--	Output of modulation depth (only with AM)
:DEVIATION?	--	--	Output of frequency deviaiton (only with FM)
:OFFSET?	--	--	Output of frequency offset (only with FM)
:PEAK	--	--	Peak-Search
:NEXT_PEAK	--	--	Next Peak Search
:MIN	--	--	Minimum Search
:NEXT_MIN	--	--	Next Min Search
DEMODULATION:AM	100% 10%	PCT	Type and range of demodulation
:FM	200kHz 20kHz 2kHz 200Hz	HZ KHZ MHZ GHZ	
	COUPLED	--	Automatic matching to resolution bandwidth

Command	Data	Units	Meaning
FREQUENCY:RECEIVER :RECEIVER? :RECEIVER :STEPSIZE :STEPSIZE?	0 to 2GHz	HZ KHZ MHZ GHZ	Demodulation frequency
	INCREMENT DECREMENT	-- --	Increment Decrement
	"	"	Step size of demodulation frequency
MARKER MARKER? MARKER:TIME? :LEVEL? :FORM :PEAK :NEXT_PEAK :MIN :NEXT_MIN	0... Ablaufzeit	S Ms Us Ns	Change marker time
	INCREMENT DECREMENT	-- --	Increment Decrement
	ON OFF	-- --	Marker on Marker off
	--	--	Output of marker time and level
	--	--	Output marker time
	--	--	Output marker level
	TRIANGLE CIRCLE CROSS X_CROSS	-- -- -- --	Change marker form - Triangle - Circle - Cross - X cross
	--	--	PeakSearch
	--	--	Next Peak Search
	--	--	Minimum Search
	--	--	Next Min Search
SQUELCH SQUELCH?	-150 to 30 dBm	DBM	Squelch level
	INCREMENT DECREMENT	-- --	Increment Decrement
	ON OFF	-- --	on off
VOLUME VOLUME?	0 to 63	--	Volume

2.4.1.5 Service Request and Status Register

The following Fig. shows the status registers and the effective links between them. To remain in accordance with the IEEE 488.2 standard, the Status Byte (STB) and its associated mask register (SRE), which are also present with older devices, have been supplemented by the Event Status Register (ESR) and its Event Status Enable Mask Register (ESE).




Fig. 2-7 Status registers

A bit is set to "1" in the ESR in the case of certain events (e.g. fault, ready signal), see Table 2-11. These bits remain set until they are cleared by reading the ESR (by the command *ESR?) or by the following conditions:

- The commands *RST or *CLS
- Switching on the AC supply (the power-on bit is, however, set in this case).

Using the ESE mask register, the user can select the bits in the ESR which also set the sum bit ESB (bit 5 in the status byte) via which a service request can be triggered. The sum bit is therefore only set if at least one bit in the ESR and the corresponding bits in the ESE are set to "1". The sum bit is automatically cleared again if the previous condition is no longer fulfilled, e.g. if the bits in the ESR have been cleared by reading the ESR or if the ESE has been modified.

The ESE mask register is written by the command "*ESEvalue" ("value" is the contents in decimal form) and can be read again by the command *ESE?. It is set to "0" when the AC power is switched on if the power on status clear flag is "1" (*PSC1).The ESE mask register is not changed by other commands or interface messages (DCL, SDC).

The bits listed in Table 2-10 are used in the status byte (STB):

Table 2-10 Bit allocation of status byte

Bit number	Bus line	Designation	Meaning
3	DIO 4	ESBA	Sum bit of the Event Status register A for limit check on tolerance lines T1 to T8.
4	DIO 5	MAV	Message Available Indicates that a message, which can be read, is present in the output buffer. The bit is "0" if the output buffer is empty.
5	DIO 6	ESB	Sum bit of the Event Status Register
6	DIO 7	RQS	Request Service

Note that the status register bits are numbered from 0 to 7 in compliance with the standard, but the bus data lines are designated DIO1 to DIO8.

Event-Status Register A:

To remain in accordance with the IEEE 488.2 standard defining registers ESR and ESE, an "Event Status Register A" ERA and its associated Enable register "ERAE" have additionally been defined in the analyzer to control bit 3 "ESBA" in the status byte .




Fig. 2-8 Event Status Register A

With Limit Check activated the associated bit in the Event Status Register ERA is set for the respective tolerance line T1 to T8 at the end of a sweep in case of violation of the upper or lower limit ("LIMITCHECK:LINE 1 UPPER" or "LIMIT-CHECK:LINE 1 LOWER").

Table 2-11 Bit allocation of ESR

Bit-Number	Meaning
7	Power On Is set when the instrument is switched on or if the power returns following a failure.
6	User Request The user can set this bit by actuating the LOCAL key – irrespective of whether the instrument setting is REMOTE or LOCAL – and thus generate a Service Request with a corresponding setting of the mark registers. This function is useful if test routines require manual operation as well as control via the IEC bus.
5	Command Error Is set if one of the following faults is detected in the received commands: ● Syntax error ● Illegal unit ● Illegal header ● A number has been combined with a header where no number is allowed.
4	Execution Error Is set if one of the following errors was detected during execution of the received commands ● A number is outside the permissible range (for the respective parameter). ● A received command is not compatible with the current device setting.
3	Device-dependent Error Is set if functional errors occur.
2	Query Error This bit is set: ● If the controller wishes to read data from the analyzer but no query message has previously been output. ● If the data present in the output buffer of the analyzer have not been read out and a new command was sent to the instrument instead. The output buffer is cleared in this case.
1	Request Control Is used by the device to obtain the controller function for the plotter after a "PLOT:CURVE" or "PLOT SCREEN" command.
0	Operation Complete This bit is set by the commands *OPC and *OPC? if all previous commands have been executed.

Using the SRE mask register, the user can determine whether the ESB, ESBA and/or MAV bits of the status byte are set, and whether a Service Request is sent to the controller by activating the SRQ line. Since each bit in the SRE mask register is assigned to the corresponding bit in the status byte, the following possibilities result (see Table 2-12), and the combinations thereof.

Table 2-12 Bit allocation of the SRE

Contents of SRE (decimal)	Set bit No. in SRE	Effect
0	--	No Service Request
8	3	Service Request if ESBA bit is set (at least 1 bit set and not masked in the ESR A)
16	4	Service Request if MAV bit is set (message in output buffer)
32	5	Service Request if ESB bit is set (at least 1 bit set and not masked in the ESR)

The Service Request Enable mask register (SRE) is written by the command `"*SRE value"` ("value" is the contents in decimal form) and can be read again by the command `*SRE?`. It is set to "0" when the AC power is switched on, if the power-on clear flag is "1"; the Service Request function of the analyzer is thus disabled. The SRE mask register is not changed by other commands or interface messages (DCL, SDC).

Several devices can trigger a Service Request simultaneously, the open collector drivers generate an OR function on the SRQ line. The controller must read the status bytes of the devices in order to identify the device which has triggered the Service Request. A set RQS bit (bit 6/DIO7) indicates that the device is sending a Service Request.

The status byte of the analyzer can be read in the following manner:

- By the command `*STB?`.

The contents are then output in decimal form. The status byte is not changed by reading out, and the Service Request is not cleared.
- By a Serial Poll.

(With R&S controllers: IEC SPL adr, status.) The contents are transferred in binary form as one byte. The RQS bit is then set to "0" and the Service Request becomes inactive; the other bits of the status byte are not changed.

The status byte is cleared:

- By the command `*CLS`.

This command clears the ESR and the output buffer; the ESB and MAV bits in the status byte are also set to "0". This in turn clears the RQS bit and the Service Request.
- By reading the ESR (`*ESR?` command) or setting the ESE mask register to "0" (`*ESE` command) and by reading the contents of the output buffer.

2.4.1.6 Resetting of Device Functions

The following table lists the various commands and events which cause individual device functions to be reset.

Table 2-13 Resetting of various device functions

Event	Power on		DCL, SDC (Device Clear, Selected Device Clear)	Commands	
	Power-on-clear flag			*RST	*CLS
	0	1			
Basic device setting	--	--	--	Yes	--
Set Event Status Register ESR to zero	Yes	Yes	--	Yes	Yes
Set mask registers ESE and SRE to zero	--	Yes	--	--	--
Clear output buffer	Yes	Yes	Yes	--	Yes
Clear Service Request	Yes	1)	2)	3)	Yes
Reset command processing and input buffer	Yes	Yes	Yes	--	--

1) Yes, but "Service Request on power on" is possible.

2) Yes, if only caused by message in output buffer.

3) Yes, if not caused by message in output buffer.

2.4.1.7 Command Processing Sequence and Synchronization

The commands received by the analyzer are first stored in an input buffer which can accommodate up to 2560 characters. Once the terminator has been received, the commands are processed in the sequence in which they were sent. During this time, the IEC bus can be used for communication with other devices. Command lines which exceed the capacity of the input buffer are processed in several sections. The bus is occupied during this time.

OPERATION COMPLETE:

The commands *OPC and *OPC? (operation complete) are used as feedbacks to inform on the time at which processing of the received commands was terminated and a sweep (if any) has been completely executed.

*OPC sets bit 0 in the ESR, and a Service Request can then be triggered if all previous commands have been executed.

*OPC? additionally provides a message in the output buffer and sets bit 4 (MAV) in the status byte.

For synchronization with a complete sweep the function "Operation Complete" can be used with the following commands:

SWEEP: START
SWEEP: SINGLE
SWEEP: CONTINUOUS

WAIT:

This synchronization can be established within a command line by the command "**WAI", i.e. all subsequent commands are only executed when the previous commands have been completely executed. This may be favourable in the case of very short sweep times.

2.4.1.8 Error Handling

All errors detected by the analyzer in connection with operation via the IEC bus are indicated in the ESR by setting a bit (bit 2, 4 or 5, see Table 2-11). Function faults are signalled by setting of bit 3. These bits remain set until the ESR is read or is cleared by the commands *RST or *CLS. This is in line with the standard IEEE 488.2 and enables triggering of a Service Request and program-controlled evaluation of the type of error.

The Query command "ERRORS?" allows for a detailed error detection (see Table 2-9).

2.4.1.9 Programming Examples

The following section is provided to give the user an easy approach to programming the analyzer via IEC bus.

The examples are tailored to the Rohde & Schwarz BASIC (version 2.02) but can easily be varied for application at other controllers.

The examples are successively completed by further functional parts, which are explained in detail.

Note:

Generally, all programs should be given procedure names and labels to be independent of BASIC line numbers.

At the beginning of a program the terminator "LF" (acc. to standard IEEE488.2 the only legal terminator) should be set for the system controller.

```
10000Prolog:
10010                                REM Setup Controller
10020    IEC TERM 10: IEC TIME 5000
10030                                REM Analyzer Bus Address
10040    Fsa=20
10050                                REM ... other init stuff
10060    False%=0: True%=1
10070    RETURN
10080 REM -----
```

The variables False% and True% are used in the examples for a better understanding of the program.

Apart from the setting for the IEC bus, the initialization of the instrument attached is necessary:

```
10100Fsa_reset:
10110                                REM Reset status reg's
10120                                REM and analyzer setting
10130    IEC OUT Fsa,"*CLS;*RST"
10140    RETURN
10150 REM -----
```

Example 1: Sending a setting command

The first example shows how to send a setting command to the analyzer, in order to set a centre frequency of 100 MHz and a span of 1 MHz.

```
100 REM ===== Send commands to analyzer
110 REM prologue + reset device
120 GOSUB Prolog
130 GOSUB Fsa_reset
140 REM send new setting
150 IEC OUT Fsa,"FREQUENCY:CENTER 100MHZ; SPAN 1MHZ"
160 REM
170 END
180 REM =====
10000Prolog:
10010 REM Setup Controller
10020 IEC TERM 10: IEC TIME 5000
10030 REM Analyzer Bus Address
10040 Fsa=20
10050 REM ... other init stuff
10060 RETURN
10070 REM -----
10100Fsa_reset:
10110 REM Reset status reg's
10120 REM and analyzer setting
10130 IEC OUT Fsa,"*CLS;*RST"
10140 RETURN
10150 REM -----
```

This example also contains the procedures "Prolog" and "Fsa_reset"; in the following examples only the new program parts are listed.

Example 2: Reading a setting

This example is used for sending the same setting to the analyzer as in example 1, but with abbreviated commands. The sweep time which is automatically set by the device is then read and output on the screen:

```
100 REM ===== Read analyzer settings
110 REM Init section
120 GOSUB Prolog
130 GOSUB Fsa_reset
140 REM Setup analyzer
150 IEC OUT Fsa,"F:C 100M;SPAN 1M"
160 REM Read device setting
170 IEC OUT Fsa,"SWEEP:TIME?"
180 IEC IN Fsa,Swptime$
190 PRINT Swptime$
200 END
210 REM =====
```

Example 2: Sweep and synchronization

The program part for synchronization with sweep is often required, e.g. to evaluate the peak signal after a complete sweep. The easiest way to obtain the synchronization is by using the *"*WAI"* command. The IEC bus commands in the example below are not executed until completion of the sweep; the bus, however, is busy during this time.

This simple procedure should be applied when short sweep times are set on the analyzer and no further actions are planned on the controller during the sweep.

Example 3a: WAIT command

```
100 REM ===== take sweep,wait + read peak
110                                REM Init section
120  GOSUB Prolog
130  GOSUB Fsa_reset
140                                REM setup analyzer
150  IEC OUT Fsa,"F:C 100M;SPAN 1M"
160                                REM take sweep and wait
170  IEC OUT Fsa,"SWEEP:SINGLE;*WAI"
180                                REM marker to peak signal
190  IEC OUT Fsa,"MARKER:PEAK;MARKER?"
200  IEC IN Fsa,Marker$
210                                REM freq. + level of marker
220  PRINT Marker$
230  END
240 REM =====
```

A second possibility of synchronization is provided by the command *Operation Complete* *"*OPC?"* or *"*OPC"* which can be used with or without Service Request (for **OPC?*).

The **OPC?* command forces the device to send a message to the output buffer and to simultaneously set the MAV bit in the status byte. The output of the message may now be waited for - which corresponds to the **WAI* command procedure - or, with appropriate configuration, a Service Request can be triggered. It is not necessary for the message to be read, since sending further commands to the analyzer automatically causes the output buffer to be cleared.

Example 3b: *OPC? query without Service Request

```
100 REM ===== take sweep, sync + read peak
110 REM Init section
120 GOSUB Prolog
130 GOSUB Fsa_reset
140 REM setup analyzer
150 IEC OUT Fsa, "F:C 100M;SPAN 1M"
160 REM start sweep
170 IEC OUT Fsa, "SWEEP:START;*OPC?"
180 REM sync by read OPC msg
190 IEC IN Fsa, Dummy$
200 REM marker to peak signal
210 IEC OUT Fsa, "MARKER:PEAK;MARKER?"
220 IEC IN Fsa, Marker$
230 REM freq. + level of marker
240 PRINT Marker$
250 END
260 REM =====
```

Example 4: Service Request

The most flexible method of synchronizing the sweep is represented by the *Service Request*.

The system controller is provided with an interrupt routine which can be processed upon every Service Request (asynchronous to the normal program run).

During this procedure the calling devices are determined by polling. The status byte information then initiates the device-specific actions accordingly.

The following statement is added to the main program for enabling the controller to service interrupt routines:

```
nnn ON SRQ GOSUB Srq_interrupt
```

The following example shows a Service-Request routine

Example 4a: Service Request Routine

```
12000Srq_interrupt:
12010                                REM SRQ Interrupt
12020                                REM Poll analyzer
12030    IEC SPL Fsa,Stb%
12040    IF (Stb% AND 64)=0 THEN GOTO Poll_next_device
12050                                REM Analyzer request
12060    Fsa_srq%=True%
12070                                REM Clear status reg's
12080    IEC OUT Fsa,"*CLS"
12090Poll_next_device:
12100                                REM ... poll other devices
12110Srq_exit:
12120                                REM reenable SRQ-Interrupt
12130    ON SRQ1 GOSUB Srq_interrupt
12140    RETURN
12150 REM -----
```

This Service Request routine may be extended for servicing further devices attached and/or additionally evaluating error messages via the Event Status register.

The configuration of the *Event Status register* ESE and the *Service Request Enable* register must be appropriate for the analyzer to generate a Service Request at the end of a sweep.

Bit 0 is set in the Event Status register at the end of a sweep by the *OPC command - thus generating a Service Request, if released by the mask register SRE.

The routine of the example below is used for configuration of the registers, for triggering a sweep and for synchronization to the sweep end. In this simple example this is achieved by testing the Boolean variable Fsa-srq% set in the Service Request routine.

Of course, a series of other actions can be carried out in the controller within this sequence, such that parallel processing is done between analyzer and controller.

The controller does not check the complete sweep until this is required by the subsequent actions.

Example 4b: Sweep with Service Request

```
10300Take_sweep:
10310                                REM take sweep with sync
10320    Fsa_srq%=False%
10330                                REM enable SRQ on OPC
10340    IEC OUT Fsa,"*CLS;*ESE 1;*SRE 32"
10350                                REM start single sweep
10360    IEC OUT Fsa,"SWEEP:SINGLE;*OPC"
10370                                REM loop: sweep end?
10380Wait_for_sweep_complete:
10390    IF Fsa_srq%=False% THEN GOTO Wait_for_sweep_complete
10400                                REM that's it !
10410    RETURN
10420 REM -----
```

New routines have been added to the complete example for control of the sweep with Service Request as shown in the following:

Example 4c: Sweep synchronisation with Service Request

```

100 REM ===== take sweep, sync + read peak
110 REM Init section
120 GOSUB Prolog
130 GOSUB Fsa_reset
140 REM enable SRQ-interrupt
150 ON SRQ1 GOSUB Srq_interrupt
160 REM setup analyzer
170 IEC OUT Fsa, "F:C 100M;SPAN 1M"
180 REM now take one sweep
190 GOSUB Take_sweep
200 REM marker to peak signal
210 IEC OUT Fsa, "MARKER:PEAK;MARKER?"
220 IEC IN Fsa, Marker$
230 REM freq. + level of marker
240 PRINT Marker$
250 END
260 REM =====
10300 Take_sweep:
10310 REM take sweep with sync
10320 Fsa_srq%=False%
10330 REM enable SRQ on OPC
10340 IEC OUT Fsa, "*CLS;*ESE 1;*SRE 32"
10350 REM start single sweep
10360 IEC OUT Fsa, "SWEEP:SINGLE;*OPC"
10370 REM loop: sweep end?
10380 Wait_for_sweep_complete:
10390 IF Fsa_srq%=False% THEN GOTO Wait_for_sweep_complete
10400 REM that's it !
10410 RETURN
10420 REM -----
12000 Srq_interrupt:
12010 REM SRQ Interrupt
12020 REM Poll analyzer
12030 IEC SPL Fsa, Stb%
12040 IF (Stb% AND 64)=0 THEN GOTO Poll_next_device
12050 REM Analyzer request
12060 Fsa_srq%=True%
12070 REM Clear status reg's
12080 IEC OUT Fsa, "*CLS"
12090 Poll_next_device:
12100 REM ... poll other devices
12110 Srq_exit:
12120 REM reenable SRQ-Interrupt
12130 ON SRQ1 GOSUB Srq_interrupt
12140 RETURN
12150 REM -----

```

Example 5: Output to the plotter

The *Pass Control* protocol is used by the controller for output of the complete screen contents or the measuring curve from the analyzer to the IEC bus plotter.

This means that the controller function is passed to the analyzer for control of the plotter. The analyzer then addresses the plotter as listener. After plotter output the controller function is again passed to the controller.

The *Pass Control Back* command "PCB" is used to inform the device about the address of the controller to which the controller function was returned again.

The controller can perform further actions during the plotter output - except for IEC bus control of devices. The "Wait Take Control" command is used for waiting for the analyzer to pass the controller function.

```
10500Plot_screen:
10510                                REM controller address
10520    Controller=1
10530                                REM configure PCB
10540    IEC ADR Controller: IEC OUT Fsa,"*PCB "+STR$(Controller)
10550                                REM send plot command
10560    IEC OUT Fsa,"PLOT:SCREEN"
10570                                REM pass control > analyzer
10580    IEC TAD Fsa: IEC TCT
10590                                REM wait for plot complete
10600    IEC WTCT
10610                                REM that's it !
10620    RETURN
10630 REM -----
```

Example 6: Reading trace data and instrument settings

The contents of traces 1 to 4 can be read from the analyzer with the appropriate query. This also applies for the associated instrument setting required for measuring the trace record. This record is transferred with binary notation and consists of 2190 bytes. The first 1802 bytes represent 901 measuring values of the trace, the following represent the complete instrument setting. For binary data transfer the analyzer is configured to terminate on EOI, since a terminator cannot be identified in binary mode.

The records read in can be saved on disk - with the variable `Filename$` being preassigned in this case.

An array is required to read in binary data, which must be dimensionized accordingly.

Example 6a: Reading in and storing trace data

```
10700Tr1_store:
10710                                REM store trace 1 on disk
10720    OPENO# 1,Filename$
10730                                REM terminator EOI
10740    IEC TERM 1
10750                                REM read trace 1
10760    IEC OUT Fsa,"TRACE:BLOCK:T_1?"
10770    IEC IN Fsa,Tr1$
10780                                REM store and close file
10790    PRINT# 1,Tr1$: CLOSE# 1
10800                                REM restore terminator
10810    IEC TERM 10
10820    RETURN
10830 REM -----
```

The instrument data read in above the trace data are coded according to the table in Section 2.4.1.10. The values for the reference level, the measuring range and the reference level offset can be used to convert trace data (corresponding to the A/D converter values) to level values. When restoring the trace data the trace buffer can either only be displayed (Example 6b) or completely reconfigured together with the instrument setting (Example 6c)

Example 6b: Transfer of trace data to the analyzer

```
10840Tr1_load:
10850                                REM load trace_1
10860    OPENI# 2,Filename$
10870    Tr1$=INPUT$(2500,#2): CLOSE# 2
10880                                REM config. binary transfer
10890    IEC OUT Fsa,"TERMINATOR EOI"
10900                                REM send trace_1 data
10910    IEC OUT Fsa,"TRACE:BLOCK:T_1 #0"+Tr1$
10920                                REM reconfigure to default
10930    IEC OUT Fsa,"TERMINATOR LF_EOI"
10940    RETURN
10950 REM -----
```

Example 6c: Restoring trace data and instrument setting

```
10960Tr1_restore:
10970                                REM restore trace + setting
10980    OPENI# 2,Filename$
10990    Tr1$=INPUT$(2500,#2): CLOSE# 2
11000                                REM config. binary transfer
11010    IEC OUT Fsa,"TERMINATOR EOI"
11020                                REM send trace_1 + setting
11030    IEC OUT Fsa,"TRACE:RESTORE:T_1 #0"+Tr1$
11040                                REM reconfigure to default
11050    IEC OUT Fsa,"TERMINATOR LF_EOI"
11060    RETURN
11070 REM -----
```

The following programming example shows the handling of routines by saving a measurement on a disk. The array size must be sufficiently dimensionized and the file name - including the path name - preassigned.

Example 6d: Measurement with subsequent saving on disk

```
100 REM ===== take sweep and save on disk
110                                REM Init section
120    GOSUB Prolog
130    GOSUB Fsa_reset
140                                REM enable SRQ-interrupt
150    ON SRQ1 GOSUB Srq_interrupt
160                                REM define array + filename
170    DIM Tr1$(2500)
180    Filename$="A:TRACE1.DAT"
190                                REM setup analyzer
200    IEC OUT Fsa,"F:C 100M;SPAN 1M"
210                                REM now take one sweep
220    GOSUB Take_sweep
230                                REM marker to peak signal
240    IEC OUT Fsa,"MARKER:PEAK;MARKER?"
250                                REM store trace_1 on disk
260    GOSUB Tr1_store
270    END
280 REM =====
```

Example7: Fast readout of trace data

As in the preceding examples, also in this case a trace record is read out from the instrument. This is achieved by the "TRACE"? command which initiates several actions in the analyzer:

- Start of a sweep (without graphics display on screen)
- Synchronization to end of sweep
- Output of the binary trace data via the IEC bus

In this example, 10 sweeps are saved in one record for subsequent evaluation. Saving of the trace record is carried out in parallel to the next measurement performed by the analyzer. Sweep rates of approx. 130 ms including saving on hard disk are thus obtained.

```
100 REM ===== take 10 sweeps+save on disk
110 REM Init section
120 GOSUB Prolog
130 GOSUB Fsa_reset
140 REM define array + filename
150 DIM Tr$(2500)
160 Filename$="TRACE.DAT": OPENO# 1,Filename$
170 REM EOI for binary transfer
180 IEC TERM 1
190 REM setup analyzer
200 IEC OUT Fsa,"F:C 100M;SPAN 10M;SWEEP:SINGLE"
210 REM now take one sweep
220 IEC OUT Fsa,"TRACE?": IEC IN Fsa,Tr$
230 REM loop for 9 sweeps
240 FOR I=1 TO 9
250 IEC OUT Fsa,"TRACE?": PRINT# 1,Tr$: IEC IN Fsa,Tr$
260 NEXT I
270 REM save last sweep on disk
280 PRINT# 1,Tr$
290 CLOSE# 1
300 END
310 REM =====
```

2.4.1.10 Trace Record

The trace record consists of 2190 bytes. The first 1802 bytes represent the 901 A/D converter values of the trace buffer. The following bytes represent the complete instrument setting:

0000: int trace_buffer [901]

A/D-Converter result at start-freq.	00	00	00	00
-------------------------------------	----	----	----	----

⋮

1800:

A/D-Converter result at stop-freq.	00	00	00	00
------------------------------------	----	----	----	----

Calculation of the level value

For conversion of the binary trace data into level values, the 16-bit values must be shifted by 4 bits to the right. Due to the 12-bit resolution of the A/D converter, the result is a value between 0 and 4095. The value "3938" corresponds to the reference level set.

Level conversion:

1. Log. Scaling

$$level[i] = \frac{(buffer[i] \gg 4) - 3938}{3938} \cdot range + ref. level$$

2. Lin. Scaling

$$level[i] = 2000 \cdot lg \left[\frac{(buffer[i] \gg 4)}{3938} \right] + ref. level$$

Level, range and ref. level are indicated in 1/100 dB.

1802: unsigned char state [0]

07	06	05	04	03	02	01	00
----	----	----	----	----	----	----	----

Function:	0	---
	1	Power Up Display
	2	---
	3	Frequency Analyzer
	4	Scalar Network Analyzer
	5	---
	6	Communication Analyzer
	7	Receiver
	8	---
	9	---
	10	Setup

1803: unsigned char state [1]

07	06	05	04	03	02	01	00
----	----	----	----	----	----	----	----

- Hardkey:
- 0 ---
 - 1 ---
 - 2 Special Function
 - 3 Display Line
 - 4 Marker
 - 5 Multi Marker
 - 6 Sweep
 - 7 Trace
 - 8 Trigger
 - 9 Coupled Function
 - 10 Auto
 - 11 Frequency
 - 12 Span
 - 13 Reference Level
 - 14 Level Range
 - 15 Units
 - 16 ---
 - 17 ---
 - 18 Main-Menu Receiver
 - 19 Receiver Frequency
 - 20 Receiver Display Line
 - 21 Receiver Marker
 - 22 Main-Menu Scalar Network
 - 23 ---
 - 24 Main-Menu Communication Analyzer


1804: unsigned char state [2]

07	06	05	04	03	02	01	00
----	----	----	----	----	----	----	----

- Hardkeys/
- Data entry:
- 0 nothing active
 - 2 Screen
 - 3 Display
 - 5 Plot
 - 6 Help
 - 7 Save
 - 8 Recall
 - 9 Hold
 - 10 Mode
 - 20 Float
 - 21 Signed Float
 - 22 Integer
 - 23 Signed Integer
 - 24 Number


- 1805: int reference [0] Reference Level * 0.01 dB
- 1807: int reference [1] Reference Level Offset * 0.01 dB
- 1809: int tglevel Level Tracking Generator * 0.01 dB
- 1811: int tgoffset Leveloffset Tracking Gen. * 0.01 dB
- 1813: unsigned char rfatt RF-Attenuation * 1 dB
- 1814: unsigned char tgatt TG-Attenuation * 1 dB
- 1815: int mixlev Mixer level * 0.01 dB

1817: unsigned char gain [0] Range Frequency Analyzer



1818: unsigned char gain [1] spare

1819: unsigned char gain [2] Units



1820: unsigned char mode [0] Trace 1

07	06	05	04	03	02	01	00
----	----	----	----	----	----	----	----

- mode
- 000 blank
 - 001 view
 - 010 clr/write
 - 011 Max.Hold
 - 100 Average
 - 101 ---

- difference
- 0000 trace 1 + const.
 - 0001 trace 2 + const.
 - 0010 trace 3 + const.
 - 0011 trace 4 + const.
 - 0100 trace 5 (clr/wr.)
 - 0101 trace 6 + const.
 - (transmission)
 - 0110 trace 7 + const.
 - (reflection)
 - 0111 trace 8
 - 1000 trace 9
 - 1111 level line

- difference
- 0 - off
 - 1 - on

1821: unsigned char mode [1] Trace 2

07	06	05	04	03	02	01	00
----	----	----	----	----	----	----	----

same as trace 1

1822: unsigned char mode [2] Trace 3

07	06	05	04	03	02	01	00
----	----	----	----	----	----	----	----


same as trace 1

1823: unsigned char mode [3] Trace 4


07	06	05	04	03	02	01	00
----	----	----	----	----	----	----	----

same as trace 1


1824: unsigned char mode [4] Sweep




1825: unsigned char mode [5] Coupling




1826: unsigned char mode [6] Auto





1827: unsigned char mode [7] AC/DC



1828: unsigned char mode [8] Span





1829: unsigned char mode [9] CF-Step





1830: char span_rbw [6] ratio Span/Resbw

1836: char rbw_vbw [6] ratio Resbw / Vidbw * 1000

1842: unsigned char ifcount resolution IF-Counter



1843: unsigned char spfunc [0] Detector



1844: unsigned char spfunc [1] Transducer Table

07	06	05	04	03	02	01	00
----	----	----	----	----	----	----	----

Transducer Correction

0 off

1 on

Active Table

000 - Table 1

001 - Table 2

010 - Table 3

011 - Table 4

1xx - spare

1845: unsigned char spfunc [2]

07	06	05	04	03	02	01	00
----	----	----	----	----	----	----	----

1846: unsigned char spfunc [3]

07	06	05	04	03	02	01	00
----	----	----	----	----	----	----	----

1847: unsigned char spfunc [4] Reference

07	06	05	04	03	02	01	00
----	----	----	----	----	----	----	----

Reference

0 - internal

1 - external

1848: unsigned char spfunc [5] Mixer

07	06	05	04	03	02	01	00
----	----	----	----	----	----	----	----

Mixer level

0 - normal

1 - manual


1849: unsigned char spfunc [6]

07	06	05	04	03	02	01	00
----	----	----	----	----	----	----	----


1850: unsigned char spfunc [7]

07	06	05	04	03	02	01	00
----	----	----	----	----	----	----	----

1851: unsigned char spfunc [8] 75 Ohm



1852: unsigned char tgmode



1853: int avg_num


Average - Samples

- 0 Continuous Sample Mode
 - 1 ... 1000 Real Average Mode
- Single Sweep: Stop Sweep
after avg_num Samples
(*OPC on IEEE Bus)

1855: unsigned char spare [35]

1890:	char offset [6]	Frequency Offset	* 1Hz
1896:	char center [6]	Center Frequency	* 1Hz
1902:	char span [6]	Span	* 1Hz
1908:	char cstep [6]	Center Freq. Stepsize	* 1Hz
1914:	char start [6]	Start Frequency	* 1Hz
1920:	char stop [6]	Stop Frequency	* 1Hz
1926:	long swptim	Sweeptime	* 100μsec
1930:	char resbw [6]	Resolution Bandwidth	* 0. 1Hz

1936: unsigned char vidbw




Video Bandwidth

0	-	1 Hz
1	-	3 Hz
2	-	10 Hz
3	-	30 Hz
4	-	100 Hz
5	-	300 Hz
6	-	1 kHz
7	-	3 kHz
8	-	10 kHz
9	-	30 kHz
10	-	100 kHz
11	-	300 kHz
12	-	1 MHz
13	-	3 MHz

1937:	char center1 [6]	log Sweep
1943:	char span1 [6]	log Sweep
1949:	char [6]	spare
1955:	char start1 [6]	log Sweep
1961:	char stop1 [6]	log Sweep
1967:	char [113]	spare

2080: unsigned int rxmode



2082: int volume
 2084: int squelch
 2086: int trigger

 2088: char span_rf [6]

 2094: char center_rf [6]
 2100: char center_af [6]

 2106: char cfss [6]
 2112: char rfss [6]

 2118: int reference_rf [4]
 2126: int reference_af [4]

 2134: char resbw_rf [6]
 2140: char resbw_af [6]

 2146: unsigned char vidbw_rf
 2147: unsigned char vidbw_af

 2148: unsigned long swptim_rf
 2152: unsigned long swptim_af

 2156: unsigned char rfatt_rf
 2157: unsigned char rfatt_af

 2158: unsigned char mode5_rf

 2159: unsigned char mode6_rf
 2160: unsigned char mode6_af

 2161: unsigned char gain_rf

 2162: unsigned char mode9_rf
 2163: unsigned char mode9_af

 2164: unsigned char mode4_rf
 2165: unsigned char mode4_af

 2166: unsigned int trigger_rf
 2168: unsigned int trigger_af

 2170: unsigned int sq_delay
 2172: unsigned char tline_rf

 2173: unsigned char [17] spare
 .
 .
 .
 2190

2.5.2 Parallel Printer Interface (Centronics)

2.5.2.1 Interface Characteristics

The Centronics interface is used to output texts and graphics to matrix printers. The interface has the following characteristics:

- 8-bit parallel unidirectional data transfer
- handshake using three signal lines
- additional lines for printer messages

Transmission of data and control signals is carried out with a TTL level in positive logic. The output levels are:

"0" = Low < +0.4 V
"1" = High > +2 V

The maximum line length is 6 m.

2.5.2.2 Pin Assignment and Signal Designations





Fig. 2-10 Pin assignment for centronics interface

Table 2-15

Pin	I/O	Signal	Function
1	O	/STROBE	Sync signal for data accept
2	O	DATA1 (LSB)	Data bus (transmit line for 8 bits in parallel)
3	O	DATA2	
4	O	DATA3	
5	O	DATA4	
6	O	DATA5	
7	O	DATA6	
8	O	DATA7	
9	O	DATA8 (MSB)	
10	I	/ACK	Printer set /ACK = LOW to show ready to receive next character
11	I	BUSY	Printer set BUSY = HIGH to signal not ready to receive further characters (e.g. input buffer is full)
12	I	PAPER END	Set to High when out of paper (or ink). Locks out transmission of further characters
13	I	SELECT	Show printer status: H = printer is on-line L = printer is off-line (fault or test)
31	O	/INIT /INPUT PRIME	Resets printer to initial status (equivalent to a reset)
32	I	/FAULT	Indicates error state of printer, e.g. offline, paper end (dependent on printer type)
18		+ 5 V	From printer power supply for interface circuits
14, 16, 19...27, 30, 33, 17		GND GND GND Shield	

/ = Signal inverted (active Low)

2.5.2.3 Signal Timing Sequence



2.5.3 Serial Interface

The serial interface is used for data communication between peripheral devices, e.g. MODEMs, terminals, line printers and paper tapes, as well as for the connection to a computer network. This interface is supported by the controller function FS-K1.

2.5.3.1 Interface Characteristics

- Serial data transfer
- Bidirectional data transfer via two separate lines
- Data transfer rate programmable from 50 to 19200 baud
- High signal-to-noise ratio with ± 11 V level
- Lines of several 100 m lengths possible
- Operation possible with or without hand-shake




Fig. 2-11 Pin assignment for the RS-232-C-interface

2.5.3.2 Interface Data

	V.24/V.28 RS-232-C
Line length max.	15 m
Transmission rate max.	20 kbaud
Driver:	
Type	asymm.
Voltage (idle)	$< \pm 25$ V
Output voltage with load of	± 5 to 15 V 3 to 7 Ω
Receivers:	
Max. number	1
Type	asymm.
Input voltage max.	± 25 V
Input voltage min.	± 3 V
Input resistance	3 to 7 Ω

Table 2-16 Pin assignment for RS-232-C interface

Pin	I/O	Signal name	Function
1	-	Shield	Shielded ground
7	-	Ground	Signal ground
2	O	TxD Transmit Data	Transmitted data
3	I	RxD Receive Data	Received data
4	O	RTS Request to send	Spectrum Analyzer signals ready to receive data. Transmitting section of external device is activated.
5	I	CTS Clear to send	Data transmitting section of Spectrum Analyzer is activated.
6	I	DSR Data set ready	Signals to Spectrum Analyzer that external devices are attached and ready for operation.
20	O	DTR Data Terminal ready	Spectrum Analyzer signals ready for operation.
23	O	Tx	Transmitter signal element timing for external device
24	I	TxC Rx C	Transmitter/receiver signal element timing from external device

2.5.3.3 Pin Assignment and Signal Designations

For serial operation, the 25-pin connector as shown in fig. 2-11 is used. The connector RS 232 of the spectrum analyzer is wired up in accordance with the CCITT standard V.24/V.28 for a DTE.

Note: The DCD line (Data Carrier Detected) provided with pin 8 according to the standard is not switched and can automatically be operated with CTS via jumpers X37 and X30 on the I/O Board of the display unit.

2.5.4 External Floppy Interface

The floppy disk station can be connected to the EXT. FLOPPY socket at the rear of the analyzer (see Fig. 2-12).



External socket
(connector solder side)

Fig. 2-12 37-pin Cannon connector

2.5.4.1 Pin Assignment and Signal Description

Table 2-17

Pin	I/O	Signal name	Function
21	O	/READY	Signals device ready (power on, disk inserted and rotating)
22	I	/Side Sel	Selects one of the two heads Low = Side 1 Low = Side 2
23	O	/R-Data	Carries raw read data. Signals a Low pulse for each change in magnetization.
24	O	/W Prot	Determines if floppy disk may be written to. Low locks out the write signal. The 5 1/4" floppy disk is protected when the write protect notch is covered.
25	O	/Track 0	Signals first track. Used to determine position after power-on.
26	I	W-Gate	Selects signals for Write Data and Read Data. High = Read Data active Low = Write Data active Use of a write protected diskette internally prevents writing.


Pin	I/O	Signal name	Function
27	I	/W-Data	Carries data to be written. A switch from High to Low causes an impulse at the write head. The signal works only during Write Gate = Low.
28	I	/Step	Moves the head one track in the direction indicated by /Direction Select for each Low impulse. When /Write Gate is Low no step is possible.
29	I	/Dir	Defines the direction of movement for the head. High = toward rim Low = toward hub
30	I	/Motor on	Turns on the motor of the disk drive. A jumper in the drive allows the select signal to be used.
31	I	/D-Sel 2	n.c. (external, "B") (external, "A") Allows selection of the different drives if more than one is installed.
32	I	/D-Sel 1	
33	I	/D-Sel 0	
34	O	/Index	Indicates the start of track with a Low impulse for each rotation.
36	I	/Head Load	Lowers the head to the floppy disk. The drive must also be selected and /Ready = Low. Also turns on the access LED.
20.1 35.2 37			n. c.
3... 19		GND	ground

2.5.5 External Video Interface

The analyzer allows connection of an external colour monitor. For this purpose five BNC sockets are available on the rear of the unit. The socket COMPOSITE VIDEO may also be connected to a video printer. Please note that the analyzer uses a line frequency of approx. 30 kHz.

Connection is carried out using a 70-Ω coaxial cable. For connector lengths of under 2 m no visible degradation of display quality is noticeable when 50-Ω lines are used. A special connecting cable with a 9 pin socket is available for IBM-PC/AT compatible monitors with a line frequency of approx. 30 kHz under the designation:

Video Cable R-G-B-SYNC EZ-1 837.1514.02



2.5.5.1 Interface Description

- Internal resistance 75 Ω
- Composite video signal (BAS signal monochrome) as well as
- Composite sync. and red, green, blue
- Field frequency of 50 Hz, non-interlaced
- Line frequency 29.41 kHz
- Pixel frequency (bandwidth) 40 MHz
- Colour monitor:
 - Four BNC sockets
 - Video signal RGB 0.3 to 1 V into 75 Ω (positive)
 - Composite sync 0 to 2 V into 75 Ω (negative)

2.5.5.2 Signal Timing Sequence

Figure 2-13 shows the composite video timing diagram within a picture and within a line.

Within the timeframe of a picture (20 msec.) 512 lines at 34 μsec. each are written. Approx. 2.6 msec. are provided for picture return together with the field sync pulse.

Each line (of 34 μsec.) is composed of 1024 pixels of 25 nsec. each. Approx. 8.4 μsec. are provided for the line return and the line sync pulse.





Fig. 2-13 Time frame of COMP.VIDEO, picture (above) and line (below)

The connectors R, G, and B show the same timeframe as the signal COMPOSITE VIDEO. However, the sync pulses of 0 V are not present. The voltage is 0.3 to 1 V at full brightness.

Figure 2-14 shows the signal SYNC for a screen frame. It is composed of 560 line sync pulses and one field sync pulse.




Fig. 2-14 Timeframe synchronization

2.5.7 User Port

2.5.7.1. Interface Characteristics

These interfaces allow control of a test adapter or test items as well as input of external TTL signals.

This interface also contains a supply voltage of +5V for external circuits. Control of the port lines is supported via the SETUP menu of the analyzer, or may be realized using a corresponding program on the analyzer. The interface does not allow interrupts but must be queried by the program.

Control is carried out using BASIC instructions via IEC bus commands.

2.5.7.2 Pin Assignment and Signal Designations




Fig. 2-17 25-pin Cannon connector

Table 2-18

Pin	Signal	Function
1	A0 (LSB)	I/O-Port A
2	A1	
3	A2	
4	A3	
5	A4	
6	A5	
7	A6	
8	A7 (MSB)	
9	GND	
10	GND	
11	GND	
12	GND	
13		n. c.
14	B0 (LSB)	I/O-Port B
15	B1	
16	B2	
17	B3 (MSB)	
18		n. c.
19		
20		
21		
22		n. c. n. c. Load to max. 500 mA n. c.
23		
24	+ 5 V	
25		

2.5.7.3 Electrical Characteristics

The user port is controlled by two TTL bus transceivers. Their specifications are shown in Table 2-19.

Table 2-19 Electrical characteristics of the bus transceivers 74LS245

Parameter	Conditions	Value
VIH High-level input voltage VIL Low-level input voltage VT + - VT- Hysteresis		min 2V max 0.8V min 0.2V, typ 0.4V
VOH High-level output voltage	IOH = -3mA -15mA	min 2.4V, typ 3.4V min 2V
VOL Low-level output voltage	IOL = 12mA 24mA	max 0.4V max 0.5V
IIH High-level input current IIL Low-level input current II Input current at maximum VI	VIH = 2.7V VIH = 0.4V VI = 5.5V	max 20 µA max -0.2 mA max 0.1 mA
IOS Short-circuit output current	(max 1s)	min -40 mA max -225mA
IOZH Off-state output current High IOZL Off-state output current Low	VO = 2.7V VO = 0.4V	max 10 µA max -200 µA


2.5.8 PROBE CODE

2.5.8.1 Interface Characteristics

This interface provides for the DC supply and takes into account the specific characteristics of transducers connected in series.

2.5.8.2 Pin Assignment and Signal Designations

Pin assignment of the 12-pin Tuchel connector
(Front view):



Pin	Signal
A	Ground
B	+ 10 V (max. 50 mA)
C	$\mu\text{V/m}$ (electr. field strength)
D	μA
E	10 dB
F	20 dB
G	40 dB
H	80 dB
J	$\mu\text{A/m}$ (magnet. field strength)
K	-10 V (max. 50 mA)
M	Reversed sign of factor

2.6 Index

	Page
A	
AC coupling	2.26, 2.47 - 2.48, 2.55, 2.64, 2.66, 2.100
Addressed commands	2.77 - 2.80
Ambient temperature	2.7, 2.9, 2.14
ANALYZER mode	2.16, 2.20 - 2.26
AUTO	2.2, 2.54 - 2.55, 2.67
AUTORANGE	2.54
Average samples	2.35, 2.47 - 2.48
Averaging	2.48
B	
BACK	2.4, 2.16, 2.18, 2.27 - 2.30, 2.40 - 2.42, 2.44, 2.62
BACK SPACE	2.4, 2.18
Basic setting	2.17, 2.20, 2.26, 2.42, 2.66
Battery replacement	2.20, 2.42
BLANK	2.47 - 2.48
Blower	2.7, 2.9, 2.14
Brightness	2.27, 2.138
Buffer battery	2.20
C	
Calendar	2.75
Calibration routine	2.32, 2.42 - 2.43
Carrier Operated Relay	2.69
Centre frequency	2.26, 2.50 - 2.51, 2.54, 2.55, 2.59 - 2.60, 2.67, 2.69, 2.112
CENTRE FREQUENCY STEP SIZE	2.26, 2.60
Centronics interface	2.9, 2.134
Changes of states	2.17
CLEAR	2.31, 2.34, 2.36, 2.39, 2.47 - 2.49, 2.64
Cold start	2.42
Colour monitor	2.8, 2.22, 2.137
Colour print	2.40
Colour setting	2.27 - 2.29
Command line	2.20, 2.26, 2.37, 2.47, 2.59 - 2.61, 2.65, 2.68, 2.70, 2.74, 2.76
Command processing	2.109 - 2.110
Command structure	2.81 - 2.84
Command syntax	2.81 - 2.84
Common Commands	2.84 - 2.85
Controller function MS-DOS	2.20
Copy	2.33, 2.37, 2.48
Correction curve	2.33
Correction tables	2.33

Correction values	2.32-2.33, 2.43
Counter	2.35
C.O.R. DELAY	2.68 – 2.69
COUPLED FUNCTIONS	2.56 – 2.58
COUPLING	2.2, 2.22, 2.56 – 2.57
Coupling mechanism	2.57 – 2.58
Cursor	2.37 – 2.39

D

Data entry	2.17 – 2.18, 2.56 – 2.57, 2.67 – 2.68
Data request command	2.83, 2.107
Data variation	2.4, 2.17 – 2.18, 2.62, 2.68 – 2.69
Date	2.76, 2.88
DC coupling	2.66
Default setting	2.17, 2.20, 2.26, 2.42, 2.66
Delay time	2.69 – 2.70, 2.102
Delete	2.33, 2.37, 2.39, 2.43, 2.108
DELTA MARKER	2.30, 2.49 – 2.52, 2.72 – 2.73
Demodulated signals	2.67, 2.69
DETECTOR mode	2.32, 2.35
Deviation	2.2, 2.10, 2.21 – 2.22, 2.56, 2.70 – 2.71
Device address	2.78
Device messages	2.81
Device status	2.42
Diagram lines	2.30, 2.36, 2.71
Difference formation	2.37, 2.48, 2.51 – 2.52
DISPLAY	2.1, 2.6 – 2.7, 2.9, 2.14 – 2.15, 2.18 – 2.19, 2.27, 2.29 – 2.30, 2.33 – 2.34, 2.36, 2.43, 2.45 – 2.46, 2.48 – 2.49, 2.52, 2.60, 2.65, 2.68 – 2.69, 2.71, 2.75 – 2.76, 2.121 – 2.122
DISPLAY LINE	2.36 – 2.39
DISPLAY RF/AF	2.68 – 2.69
DISPLAY OFF	2.45

E

ENTER	2.4, 2.17
Entry of new data	2.38, 2.67
Entry of text	2.41
ERROR	2.110
Error detection	2.110
Error messages	2.14, 2.20, 2.25, 2.43, 2.115
ERROR REPORT	2.14, 2.25, 2.42 – 2.43
Event Status Enable	2.85, 2.87, 2.104, 2.106
Event Status Register	2.85, 2.87, 2.104 – 2.105, 2.106, 2.108 – 2.110, 2.11

External colour monitor	2.8, 2.28, 2.137
External floppy interface	2.136
External keyboard	2.19

F

Floppy interface	2.136
FM demodulator	2.42, 2.67, 2.69 – 2.70
FM deviation	2.72
FREE	2.26, 2.43, 2.46
FREQUENCY	2.59 – 2.60, 2.74
Frequency counter	2.51
Frequency counter resolution	2.32
FRQOFF	2.25
Fuse	2.8, 2.10, 2.12

H

Hardcopy output	2.33, 2.40, 2.44, 2.75 – 2.76
Hardkeys	2.15 – 2.16, 2.18, 2.20, 2.26, 2.59, 2.122
Header	2.81 – 2.84, 2.87 – 2.88, 2.107
Headphones	2.67
HELP	2.42 - 2.44, 2.67, 2.75

I

IEC bus	2.22, 2.24, 2.37, 2.40, 2.75, 2.77, 2.81, 2.83, 2.87 – 2.88, 2.107, 2.110 – 2.111, 2.120, 2.133
IEC bus address	2.75 – 2.76, 2.85
IEC bus interface	2.85, 2.133
Initialization display	2.20, 2.42
Input buffer	2.81, 2.134
Input impedance	2.32
INSTRUMENT STATE	2.43
Interfaces	2.77, 2.133 - 2.141
Interface functions	2.77
Interface messages	2.77, 2.79, 2.105, 2.108

K

Keyboard	2.17 - 2.19, 2.65 - 2.66, 2.74, 2.83, 2.88, 2.139
Keyboard interface	2.139

L

Level	2.5, 2.7, 2.18, 2.22, 2.26, 2.32 – 2.33, 2.36 – 2.37, 2.39, 2.49 – 2.52, 2.54, 2.72, 2.94, 2.96, 2.99 – 2.100, 2.139
Level calibration	2.5, 2.42
LEVEL RANGE	2.5, 2.26, 2.64
LIMIT CHECK	2.36 – 2.38, 2.1062.1222.78.78 – 2.79.61
LIMIT CHECK	2.36 – 2.38, 2.106
Limit line	2.38
LIN	2.1, 2.21, 2.26 – 2.29, 2.36 – 2.37, 2.43, 2.44, 2.46 – 2.48, 2.52, 2.61, 2.64, 2.71, 2.75, 2.81, 2.83, 2.92, 2.97, 2.99 – 2.101, 2.106, 2.122
Linear frequency axis	2.61
LOCAL	2.66, 2.78
Local Lockout	2.78 – 2.79
LOCK DATA	2.62
LOG	2.21, 2.26, 2.44, 2.61, 2.64
Logarithmic frequency axis	2.61
LOGO R&S	2.25, 2.29
Loudspeaker	2.67
LOW noise	2.35, 2.54
LOW DISTORTION	2.35, 2.54
Lower limit line	2.38
LVLOFF	2.25

M

Main menu	2.15, 2.27, 2.30, 2.32, 2.36, 2.42, 2.47, 2.50, 2.56, 2.59, 2.68, 2.78
MARKER	2.2, 2.14, 2.26 – 2.28, 2.30, 2.43, 2.47, 2.49 – 2.53, 2.55, 2.63, 2.67, 2.72 – 2.73, 2.76, 2.83, 2.113 – 2.114, 2.116, 2.119, 2.122
Marker field	2.35, 2.49, 2.51 – 2.53, 2.72 – 2.73
Marker symbol	2.28
Mask register	2.85, 2.104, 2.107, 2.109, 2.115
MAX HOLD	2.47 – 2.48
Maximum value	2.50
Menu width	2.15
Measuring unit	2.26
Mixer reference level	2.55
Mixer level	2.32
Mode	2.15 – 2.16, 2.78, 2.122, 2.129
MODE-Menü	2.20
Modulation depth	2.70 – 2.71, 2.73, 2.102
Monitor electronics	2.28
MSG	2.25, 2.43
MULTI MARKER	2.2, 2.43, 2.49, 2.67

N

NdB	2.36 – 2.37, 2.53
New entry of data	2.38, 2.67
Noise bandwidth	2.52
Normalizing	2.37, 2.48
Numbers	2.18, 2.82 – 2.83
Numeric entries	2.18, 2.82 – 2.83

O

Offset	2.73
Offset correction	2.42
OPERATION COMPLETE	2.110
Overload message	2.43
Oversampling	2.61

P

PARALLEL INTERFACE	2.9, 2.75, 2.134
PEAK SEARCH	2.36, 2.49 – 2.51, 2.55
Phase noise	2.21, 2.51
PLOT	2.1, 2.19, 2.40 – 2.41, 2.97, 2.107, 2.117
Plotter	2.19 – 2.20, 2.40 – 2.41, 2.76, 2.117
Plotter type	2.76
Preferred setting	2.27 – 2.29, 2.48
PRESET	2.6, 2.16, 2.20, 2.26, 2.42 – 2.43, 2.62, 2.66, 2.75, 2.78
Printer	2.19, 2.33, 2.40 – 2.42, 2.44, 2.75, 2.134
PROBE CODE	2.5, 2.63, 2.97, 2.141

Q

Query messages	2.81, 2.83
----------------------	------------

R

R & S Logo	2.25, 2.29
Real time clock	2.75
RECALL	2.4, 2.18, 2.66, 2.86
Receiver frequency	2.67 – 2.68, 2.73 – 2.74
RECEIVER mode	2.16, 2.20, 2.67 – 2.70
Reference	2.2, 2.51, 2.75, 2.97
Reference frequency	2.76
REFERENCE LEVEL	2.6, 2.50, 2.63 – 2.65, 2.67 – 2.69
Reference line	2.48

Reference oscillator	2.10, 2.14
Remote	2.66, 2.77 – 2.78, 2.107, 2.133
Replacement fuses	2.12
Replacement of batteries	2.20, 2.42
Reset	2.28, 2.84 – 2.85, 2.109
Resolution bandwidth	2.2, 2.21 - 2.22, 2.25 - 2.26, 2.51, 2.56 - 2.58, 2.61, 2.67 - 2.68, 2.70, 2.74
RF attenuation	2.5, 2.25 – 2.26, 2.54
RUN	2.26, 2.46

S

Sample points	2.33, 2.37 – 2.38
SAVE	2.4, 2.18, 2.47, 2.66, 2.86
Scaling	2.61, 2.64, 2.121
SCREEN	2.1, 2.25, 2.27 – 2.29, 2.40, 2.107, 2.117
Search for minima	2.52
Search for peaks	2.36, 2.49, 2.52
Separator	2.81
Serial interface	2.135
Service Request	2.3, 2.37, 2.77, 2.85, 2.88, 2.104 – 2.110, 2.113 – 2.116, 2.133
Service Request Enable mask register	2.85, 2.88, 2.108
Service routines	2.32
SETUP	2.16, 2.40, 2.75, 2.78, 2.96
SHAPE FACTOR	2.50, 2.53
SINGLE SWEEP	2.45, 2.48, 2.110, 2.113, 2.115 – 2.116, 2.120
Softkey	2.15 – 2.18, 2.20, 2.26, 2.34, 2.36 – 2.39, 2.45 – 2.47, 2.49, 2.51 – 2.52, 2.55, 2.58, 2.62 – 2.63, 2.67, 2.69, 2.71, 2.73, 2.75 – 2.76
Space	2.81 – 2.84
SPAN	2.3, 2.18, 2.21, 2.25 – 2.26, 2.45, 2.50 – 2.52, 2.55 – 2.61, 2.67, 2.69, 2.81, 2.83, 2.88, 2.112 – 2.114, 2.116, 2.119 – 2.120, 2.122, 2.126 – 2.127, 2.130
SPAN LIN	2.61
SPAN LOG	2.61
SPECIAL FUNCTIONS	2.1, 2.15, 2.31 – 2.35
Squelch	2.67, 2.69
Start	2.10, 2.21, 2.25, 2.33, 2.38, 2.40, 2.44 – 2.45, 2.52, 2.59, 2.88, 2.130, 2.139
States	2.17
Status byte	2.83, 2.87, 2.104 – 2.106, 2.108, 2.110, 2.113
Status changes	2.17
Status line	2.25, 2.43, 2.46, 2.60, 2.65, 2.74
Status registers	2.85, 2.104 – 2.105
Step size	2.4, 2.19, 2.50, 2.52, 2.60, 2.74
Stop frequency	2.21, 2.26, 2.51 – 2.52, 2.59 – 2.60
Submenu	2.15, 2.27, 2.29 – 2.38, 2.42 – 2.43, 2.47 – 2.48, 2.56 – 2.57, 2.68, 2.70
Subsweeps	2.61

SWEEP	2.2, 2.7, 2.10, 2.21, 2.26, 2.45, 2.48, 2.56 – 2.58, 2.68 – 2.69, 2.110, 2.112 – 2.116
Sweep time	2.2, 2.21 - 2.22, 2.25, 2.45, 2.56 - 2.58, 2.69, 2.71, 2.112, 2.120
Synchronization	2.84, 2.110, 2.120

T

Terminator	2.81 - 2.84, 2.110
Text entry	2.41
Threshold line	2.26, 2.49, 2.51 – 2.52, 2.55
Threshold value	2.26, 2.36, 2.46, 2.49, 2.51 – 2.52, 2.55, 2.69, 2.99
Time	2.76
Tolerance lines	2.36 - 2.38, 2.105 - 2.106
Total calibration	2.42
TRACE	2.47 – 2.48
TRACE data	2.47
TRACE memory	2.40, 2.47 – 2.48, 2.66
Trace record	2.118, 2.121 – 2.132
TRACK	2.17, 2.36, 2.50 – 2.51, 2.54 – 2.55
Tracking	2.51, 2.55
Transducer	2.63, 2.141
Transducer factors	2.32
TRIGGER	2.2, 2.26, 2.43, 2.46
TRIGGER EXTERNAL	2.46
TRIGGER SLOPE	2.46
TRIGGER VIDEO	2.46
Trigger line	2.46
Trigger threshold	2.46

U

UNCAL	2.25
UNDO function	2.4, 2.18
Units	2.20, 2.63, 2.82 - 2.83
Unit key	2.17 - 2.18
Universal commands	2.79
UNLOCK	2.18, 2.62
Upper limit value	2.38
USER PORT	2.8, 2.20, 2.24, 2.69 – 2.70, 2.75 – 2.76, 2.140

V

Variable oversampling	2.61
Variation of data	2.83, 2.107
Video bandwidth	2.2, 2.21, 2.26, 2.56 – 2.58, 2.61, 2.67 – 2.68, 2.90

Video printer 2.8, 2.137

VIEW 2.47 – 2.48, 2.66, 2.100

Voltage selector 2.8, 2.10, 2.12

Volume 2.69

W

WAIT 2.110, 2.113

Write protection 2.66

Z

ZOOM 2.17, 2.50 – 2.51, 2.54 – 2.55, 2.67, 2.95



ROHDE & SCHWARZ

Bilder
Figures
Figures

Supplement to Data Sheet FSB

The specifications given in the data sheet PD 756.8384.21 have been modified as follows:

Residual FM

Span ≤ 5 MHz < 3 Hz PP/2 in 10 s
(RBW = 10 Hz, VBW = 10 Hz)

Measurement error

RF frequency response
 $f \leq 40$ MHz $\leq \pm 1$ dB, ref. level > -30 dBm
(RF attenuation = 10 dB and DC coupling, ref. to 100 MHz)

Resolution bandwidth switching
calibrated RBW < 10 Hz $< \pm 1$ dB


AC/DC switching of input coupling $f > 3$ GHz (-0.3 dB/GHz $+ 0.4$ dB)

Spurious responses


Internal, without input signal
Input terminated with 50Ω
RF attenuation = 0 dB, $f < 1$ MHz, $f > 4.7$ GHz, $f = 1.585$ GHz to ≤ -100 dBm

FM demodulator

Data given are valid for signal levels between 0 and -30 dBm below the ref. level
VBW = 10 kHz, signal-to-noise ratio > 60 dB



Anzeige-Teil Display Unit



HF-Teil RF Unit

Bild 2-1-Frontansicht FSB
Fig. 2-1 Front panel FSB

68

67

66


65

64


82

81





Anzeige-Teil
Display Unit



HF-Teil
RF Unit

Bild 2-2 Rückansicht FSB
Fig. 2-2 Rear panel FSB

Spectrum Analyzer FSB



ROHDE & SCHWARZ

Spectrum Analyzer FSB for precise from RF up to microwave.

All our spectrum analyzers are based on the philosophy that we are only satisfied with the best. The microwave analyzer FSB shows that our development team has again been successful in producing an instrument for the future.


The Spectrum Analyzer FSB is the first analyzer with a continuous frequency range from 100 Hz to 5 GHz (5.2 GHz) whose inherent noise is below -145 dBm (6 Hz). The useful display range on the colour screen of 105 dB with a measuring range of >170 dB shows that the FSB is truly exemplary.

Its performance with respect to frequency span, phase noise, intermodulation-free range and resolution bandwidths is also worth emphasizing. The hardware and software are based on a flexible strategy which results in the highest possible operating convenience as well as upward compatibility.

The FSB is predestined for all selective level measurements. It is a top-of-the-range instrument for measurements associated with mobile radio, directional radio, satellite communication and for measurements according to CEPT regulations.



measurements



High-performance technology:

- ☐ Continuous frequency range from 100 Hz to 5 GHz (5.2 GHz)
- ☐ Extremely low inherent noise of -145 dBm (6 Hz)
- ☐ Useful display range 105 dB with measuring range >170 dB
- ☐ Very low phase noise (<-110 dBc (1 Hz) at 1 kHz from carrier)
- ☐ Fundamental wave mixing
- ☐ Large intermodulation-free dynamic range (>100 dB)
- ☐ Exceptional frequency accuracy resulting from start/stop synchronization
- ☐ Quasi-continuously variable resolution bandwidths from 6 Hz to 30 kHz and from 80 kHz to 3 MHz. Variable with constant shape factor
- ☐ Calibrated AM / FM demodulators

High-resolution 9-inch colour monitor with clear, complete display of test curves, grid, parameters, markers, function menus etc.

Numerous evaluation functions for up to 4 curves. 32 marker functions and evaluation facilities with frequency and level lines.

Automatic measuring functions integrated (e.g. autoranging, autozoom).

Modern compact housing with display unit and RF unit. Electromagnetically screened. Can be fitted in 19-inch cabinets. Transportable with handles at the front and sides. Assigned the design award "Good industrial design".

Simple and fast operation using hardkeys (single-function keys), softkeys (screen menu) and spinwheel.

Numerous outputs for test data: interfaces for hardcopy and video printers, plotter, external monitor, oscilloscope or floppy disk drive.

Temperature-controlled, low-noise fans.

Uncomplicated and convenient: the operation of the FSB.

The FSB is as easy to use as a pocket calculator.

It carries out a selftest as soon as it is switched on.

If you then want to select basic functions, it is no longer necessary to use 2 or even 3 steps. The pressing of one key is sufficient.

Setting parameters can be coupled for signal analysis. You only need to change one value, all others are adapted automatically. For example, the ratio between resolution bandwidth and video bandwidth.


If repeated measurements are necessary, you can store instrument settings and recall them as required. Measuring sequences can be executed automatically when using the controller function.

A built-in RF limiter protects the FSB and can detect overloads, even outside the displayed frequency range.

Spinwheel, step keys

A single spinwheel is sufficient to change the FSB parameters. Magnetic latching ensures that each setting is carried out quickly, exactly and without faults – in small steps or over a large range.

Two step keys are also available for coarse adjustment of parameters.



Softkeys, hardkeys

The combined hardkey and softkey concept of the FSB shows how numerous measurements can be made accessible without complicated operation.


The hardkeys (mono-function keys) are assigned fixed functions for calling menus (e.g. markers), selecting parameters (e.g. frequency) or entering values (numeric keys).



The softkeys are assigned varying functions depending on the selected menu. Since all 8 softkeys are located directly below the 8 displayed functions along the bottom edge of the screen, incorrect pressing of a key is practically impossible.

Menu operation

The screen menus lead directly to the result – you can forget complicated tree structures with the FSB. If more than 8 functions are offered, the menu is extended horizontally to the left or right.



Screen display

The FSB contains a 9-inch color screen with high graphics resolution on which all important parameters and results can be read directly. All data and information such as functions, status line, scaling and command line are arranged logically on the screen. The display of the result is never impaired.

LED panel

The LED panel clearly indicates the current status of 4 trace memories. All 5 operating modes of the 4 trace memories can be seen directly. This is very useful when operating with different evaluation criteria.

Future-oriented with a flexible concept.

Right from the beginning we designed the Spectrum Analyzer FSB as a flexible instrument. It provides a "system solution" and not an "isolated solution".

This guarantees upward-compatibility. The FSB can handle any new task and any increase in complexity whether as an individual instrument or a complex test system. Hardware and software can be extended and modified without difficulty.

The decision to purchase the Spectrum Analyzer FSB is therefore also a decision in favour of sensible investment.

Modular hardware

Hardly any other spectrum analyzer can provide the perfect modular and extendable hardware solution of the FSB.

The instrument is divided into a display unit and an RF unit. The display unit can thus be combined with all other RF units of the spectrum analyzer family from Rohde & Schwarz.

External screen

A separate color monitor or a large-display beamer can be connected via an RGB output for special workstations or for training and presentation purposes.

External keyboard


The Keyboard PCA-Z1 provides even more convenience for screen documentation.



Further data processing via PC

Complex measuring and test systems with large quantities of data are much faster and more efficient in conjunction with personal computers. To enable storage and further processing of results, the Spectrum Analyzer FSB can therefore be connected to any IEC-bus-compatible PC e.g. the Rohde & Schwarz Process Controller PSA with a 40-MByte Winchester disk.

The Dual Floppy Drive LAS-Z11 can also be connected in conjunction with the integrated computer function (80186/16-bit CPU, 256-Kbyte RAM) to enable storage of basic test programs.



Flexible software concept

The FSB has comprehensive digital processing facilities with which measurements in the laboratory or during production can be greatly simplified.

The convenient IEC-bus programming and the numerous internal evaluation functions facilitate fast development of user software. If required, customer-specific software can also be written by Rohde & Schwarz.


The FSB can be integrated into an automatic test system via the IEC 625/IEEE 488 interface bus.

Printer/plotter


The FSB enables simple logging of results on a printer, video printer or IEC bus plotter with an optimum resolution and display size.



The FSB opens-up new applications.



The FSB provides highest sensitivity into the middle GHz range.



The FSB operates with a continuous frequency range from 100 Hz to 5.2 GHz

Continuous frequency range from AF up to microwave

Many measuring problems necessitate the use of increasingly broadband investigations: for example, mobile radio applications can be handled better by comprehensive spectrum analysis of the fundamental and the harmonics all at once.

The FSB with its wide, continuous frequency range and its convincing dynamic response over the complete band provides an answer without compromise:

A modern receiver concept with high intermediate frequency and fundamental mixing, including mixer stages with a wide dynamic range and low-noise IF amplifiers, spreads the range of analysis from AF up to microwave.

An attenuator adjustable in

1-dB steps up to 5 GHz enables an optimum mixer level. Automatic functions controlled by the firmware depending on the reference level keep the level at the first mixer almost constant.

The generation of internal interference is minimized.

High frequency accuracy and spectral purity

The synthesizer concept of the FSB is tailored to typical measuring problems:

Frequency spans up to 5 MHz are fully synchronized with a high resolution. For spans above this value, the superb accuracy is achieved by synchronization of the start and stop frequencies of the yig oscillator which provides

exceptionally good phase noise data for the first conversion as a result of its bipolar crystal transistor.

Since the parameters of this microwave synthesizer set new standards close to the carrier, the FSB is the ideal instrument for assessing the spectral purity from multiplexed reference signals up to dielectric stabilized microwave oscillators.

The smallest resolution bandwidth of the FSB is 6 Hz which means that line-frequency interference can be detected just as well as non-harmonic subsidiary waves.

The quasi-continuously variable bandwidths means that an optimum compromise can be found between resolution, frequency span and sweep time for all measuring tasks.

Large, selectable level display range with numerous level units

Measurements of even very small signals in the GHz range are required for satellite applications, for research in the field of radio-astronomy and many other applications.

The FSB guarantees a very high sensitivity (-145 dBm) up to 5 GHz together with high immunity to overloading, as characterized by the intermodulation-free range of more than 100 dB.

The logarithmic precision amplifier and the high resolution of the A/D converter provide a display variable from the smallest level resolution (LIN or 0.1 dB per graticule) up to a display range

of 110 dB. The optional logarithmic division of the frequency axis is worth emphasizing:

The displayed frequency span is produced from several subranges with matched resolution bandwidths. Variable oversampling ensures that all displayed values are backed up by measured values.

High measuring convenience


The FSB has a large number of automatic test routines:

- ☐ Marker functions with up to 8 markers
- ☐ Level, frequency and bandwidth corrections
- ☐ Selftest
- ☐ Adaptation to signal type
- ☐ Selectable operating modes
LOW NOISE and LOW DISTORTION.


The FSB thus provides exceptionally high operating convenience which largely eliminates errors and greatly accelerates measurements.

All important functions and parameters are displayed clearly on the standard 9-inch color monitor, even for complex applications, with several curves displayed simultaneously.

The FSB also contains a demodulator module as standard thus enabling unknown signals, which are amplitude or frequency modulated, to be identified easily using headphones or the internal loudspeaker. The demodulated signal can be displayed on the colour screen at the same time with high level resolution in the frequency range up to 20 kHz.



Low phase noise and attenuation of spurious in the FSB provide ideal prerequisites for the analysis of microwave oscillators




Several trace memories can simultaneously display a signal according to different evaluation criteria (e.g. max. hold and average)

Applications.

In addition to the applications possible with the FSA range of instruments, the main applications of the Spectrum Analyzer FSB are in the fields of mobile radio, directional radio, satellite communication and the associated CEPT regulations.


In addition, the FSB is at home in any modern RF laboratory concerned with the development or manufacture of receiver modules, tuners, amplifiers, filters or oscillators.




Harmonics measurement

INSTRUMENT STATE				
REF. MARKER	FREQUENCY / TIME	LEVEL	TRIGGER	FREE
DELTA MARKER	889.7777777 MHz	-24.84 dBm		
MULTI MARKER 1	5.777777777 MHz	-25.08 dBm		
MULTI MARKER 2	889.7777777 MHz	-24.04 dBm		
MULTI MARKER 3	1.779555555 GHz	-53.49 dBm		
MULTI MARKER 4	2.688888888 GHz	-48.36 dBm		
MULTI MARKER 5	3.682222222 GHz	-67.66 dBm		
MULTI MARKER 6	4.495111111 GHz	-67.97 dBm		
DISPLAY LINE 1				
DISPLAY LINE 2				
THRESH. LINE				
LEVEL LINE				
N dB DOWN LINE				
FREQUENCY LINE 1				
FREQUENCY LINE 2				


The multi-marker function of the FSB enables additional output of a detailed frequency list



Subsidiary wave measurements Result of spurious outputs of a yig oscillator




Phase noise measurements Phase noise measurement with logarithmic display



Mixer measurements


Conversion loss of a mixer stage
 ① RF signal / ② Local oscillator
 ③ $f_{osc} - f_{in}$ / ④ $f_{osc} + f_{in}$



Pulse spectrum

Spectrum of two radar systems at the same centre frequency

You can depend on our service.



50 years experience


Rohde & Schwarz has already been developing and manufacturing electronic equipment for more than 50 years. This experience, combined with high quality, have made Rohde & Schwarz one of the most well-known international suppliers of RF measuring instruments.

Individual consultation

The central position of the development team within the company, means that customer requirements can be largely converted into reality. Individual consultation and support by trained engineers are of prime importance for Rohde & Schwarz at every point of customer contact.

Servicing

Rohde & Schwarz has a world-wide network of companies and representatives. Our supporting organizations in over 80 countries ensure that you obtain the best from your spectrum analyzer.



Servicing comprises a complete package with instruction, training, calibrating, maintenance, repair and documentation.



Information and training

Rohde & Schwarz supports every customer with detailed product documentation, user manuals etc. Our comprehensive know-how is passed-on by many publications, application notes (e.g. "Fundamentals of spectrum analysis with the Spectrum Analyzer FSA"), lectures and customer seminars as well.

Training courses with small groups of participants provide intensive training on all important applications with all instruments of the spectrum analyzer family.



FSB Specifications.

FREQUENCY

Frequency range

DC coupling	100 Hz to 5.0 GHz (5.2 GHz)
AC coupling	100 kHz to 5.0 GHz (5.2 GHz)
Frequency offset	can be entered up to ± 500 GHz
Frequency resolution	1 Hz
Step keys	span/10
Spinwheel	span/900

Selectable frequency display

LIN

LOG

linear frequency response displayed on a linear frequency axis with a relative scale (10 divisions with span/10)

n linear sweeps displayed on a logarithmic frequency axis with an absolute scale (10/5 divisions per decade).

"Variable oversampling" ensures that all displayed values are backed up by measured values. A continuously adjustable interpolation mode is available for fast measurements. (stop frequency/start frequency > 1.4)

Frequency reference

Internal

Mechanical settability

Aging

Temperature drift

Run-in response

External (switch-selected)

R.A. = frequency reference accuracy

$< 1 \times 10^{-8}$

$< 5 \times 10^{-10}$ /day (after 30 days)

$< 1 \times 10^{-7}$ /year

$< 5 \times 10^{-8}$ (0 to 55°C)

$< 1 \times 10^{-7}$ after 10 min. at +25°C

10 MHz

Frequency display

Evaluation aids

Resolution

Error

Span > 5 MHz

Span 10 Hz to 5 MHz

markers and cursor lines

span/900

$< 8 \times 10^{-3} \times \text{span}$;

$< 5 \times 10^{-3} \times \text{span}$

(sweep time ≥ 100 ms)

$< 2.5 \times 10^{-3} \times \text{span} \pm \text{RBW}$

$\pm \text{freq.} \times \text{R.A.}$;

$< 2.5 \times 10^{-3} \times \text{span}$

$\pm \text{freq.} \times \text{R.A.}$

(sweep time ≥ 100 ms)

RBW = resolution bandwidth;

R.A. = freq. reference accuracy

Additional frequency error

Without calibration

RBW < 3 kHz

$3 \text{ kHz} \leq \text{RBW} \leq 30 \text{ kHz}$

$80 \text{ kHz} \leq \text{RBW} \leq 150 \text{ kHz}$

$150 \text{ kHz} < \text{RBW}$

With calibration

Drift of filter centre frequency

at constant ambient temperature

after 1-h warmup period

RBW < 1 kHz

Frequency drift

Span > 5 MHz

(frequency drift occurring only

during sweep, not added from

sweep to sweep)

Span ≤ 5 MHz

resulting from centre frequency offset of IF filter

< 700 Hz

$< 15\% \text{ RBW}$

$< 35\% \text{ RBW}$

$< 15\% \text{ RBW}$

$< 10\% \text{ RBW}$ or < 10 Hz
(the higher value applies)

< 10 Hz/min

at constant ambient temperature, after 1-h warmup period

$< \pm 200$ kHz per minute of sweep time
corr. to ref. frequency drift

Frequency counter

measures the frequency of the signal on which

the marker is placed;

marker to be at least 20 dB from noise and

from point of intersection with adjacent signal

10 kHz to 0.1 Hz

(freq. $\times$ R.A.) $\pm 2 \times$ resolution

Counter resolution

Error

Frequency span

Setting range

Resolution

Step key increments

Spinwheel

Error

Span ≤ 5 MHz

Span > 5 MHz

Frequency steps per span

0 Hz/10 Hz to 2 GHz

2 Hz

0.5 $\times$ span or 1 $\times$ span

span/900

$\pm 2 \times 10^{-3} \times \text{span}$

$\pm 5 \times 10^{-3} \times \text{span}$

≥ 1000

SPECTRAL PURITY

Phase noise

At $f_{in} \leq 100$ MHz

Frequency span

phase noise in dBc (1 Hz)

≤ 100 kHz

> 100 kHz

to 5 MHz

> 5 MHz

Frequency offset

> 100 Hz

> 1 kHz

> 10 kHz

> 30 kHz

> 100 kHz

> 300 kHz

At $f_{in} > 100$ MHz

Frequency offset

< 1 kHz

> 1 kHz

≤ -95

≤ -105

≤ -110

≤ -113

≤ -115

≤ -115

≤ -115

≤ -120

≤ -107

≤ -110

≤ -115

≤ -120

≤ -105

≤ -115

≤ -120

≤ -90

≤ -105

≤ -115

≤ -120

≤ -120

≤ -120

≤ -120

≤ -120

≤ -120

≤ -120

≤ -120

≤ -120

≤ -120

≤ -120

≤ -120

≤ -120

≤ -120

≤ -120

≤ -120

≤ -120

≤ -120

≤ -120

≤ -120

Sidebands

Frequency offset

n $\times$ AC supply frequency

m $\times$ line frequency (29.4 kHz)

100 kHz (span ≤ 5 MHz)

~ 10.7 MHz

Other

at discrete frequencies (in dBc)

> 70 , if measurable by phase noise

> 80

> 90

> 90

> 75 , for $f > 1$ MHz

> 75 , for $f > 1$ MHz

> 75 , for $f > 1$ MHz

> 75 , for $f > 1$ MHz

> 75 , for $f > 1$ MHz

> 75 , for $f > 1$ MHz

> 75 , for $f > 1$ MHz

> 75 , for $f > 1$ MHz

> 75 , for $f > 1$ MHz

> 75 , for $f > 1$ MHz

> 75 , for $f > 1$ MHz

> 75 , for $f > 1$ MHz

> 75 , for $f > 1$ MHz

> 75 , for $f > 1$ MHz

> 75 , for $f > 1$ MHz

> 75 , for $f > 1$ MHz

> 75 , for $f > 1$ MHz

> 75 , for $f > 1$ MHz

> 75 , for $f > 1$ MHz

Residual FM

Span > 5 MHz

Span ≤ 5 MHz

< 10 kHz PP/2 in 0.1 s (test bandwidth 10 kHz)

< 3 kHz PP/2 in 10 s

(RBW = 10 Hz; VBW = 10 Hz)

(VBW = video bandwidth)

FILTERS

Resolution filters

Type of filter

Bandwidths (-3 dB)

Error

Uncalibrated (in the range

10 to 300 kHz, the specified

bandwidth error does not apply

5 decoupled circuits

< 10 Hz (typ. 6 Hz) to 3 MHz



Source impedance
KEYBOARD

Rear panel, RF section

IF OUTPUT, 221.4 MHz
Impedance
VSWR
Gain referred to level
at input mixer
Bandwidth (10 dB)
IF OUTPUT, 21.4 MHz
Impedance
VSWR
Gain referred to level
at input mixer, ref. level
-10 dBm, att. 20 dB, normal
Bandwidth (-6 dB)
10-MHz reference
Output level with internal
reference ($Z_s = 50 \Omega$)
Input level with external
reference ($Z_{in} = 500 \Omega$)
SWEEP OUTPUT
Output voltage ($Z_L > 500 \Omega$)
START-SWEEP-STOP

30 Ω
JK 34 jack (for PCA-Z1)

BNC female
50 Ω
<2

-3 dB, ± 6 dB
>36 MHz
BNC female
50 Ω
 ≤ 2

+8 dB ± 2 dB
>10 MHz
BNC female

+10 dBm +3/-1 dB

0.1 to 1 V_{rms}
BNC female
0 to +5 V
BNC female;
positive TTL pulse ($\tau = 1.4 \mu s$)
occurring upon sweep start and stop

Rear panel, display section

IF OUTPUT (narrow), 21.4 MHz
Impedance
VSWR
Level with reference level
up to -90 dBm
Bandwidth
EXT SWEEP TRIG
Input impedance
Voltage range
VIDEO OUTPUT
Source impedance
Output voltage

BNC female
50 Ω
<2

-15 dBm ± 3 dB
corresp. to resolution bandwidth
BNC female
>8 k Ω
 ± 5 V; max. ± 20 V
BNC female
75 Ω
0 to 0.5 V into 75 Ω ,
proportional to vertically displayed measured
value

EXTERNAL MONITOR

Outputs
RED, GREEN, BLUE, COMP VIDEO
Clock frequency
Impedance
Output voltage
V SYNC
(vertical synchronization)

BNC female

40 MHz
75 Ω
0.3 to +1.4 V into 75 Ω

TTL level, fan-out 20 LS-TTL,
polarity selectable by internal jumpers
50 Hz $\pm 2\%$
0.8 ms

TTL level, fan-out 20 LS-TTL,
function and polarity selectable by internal
jumpers
29.4 kHz $\pm 2\%$
2 μs
37-contact Cannon D female, for LAS-Z11
25-contact Cannon D female

Line frequency
Sync pulses
EXT FLOPPY
RS-232
PARALLEL INTERFACE
(Centronics)
USER PORT

KEYBOARD
IEC 625 bus (IEEE 488)
Bus functions
Data transfer rate

36-contact Amphenol female
25-contact Cannon D female,
function definable in setup mode
JK 34 jack for PCA-Z1
24-contact Amphenol female
AH1, SH1, T6, L4, SR1, RL1,
PP1, DC1, DT1, C1 to C4, C10
 ≥ 350 kbyte/s

GENERAL DATA

Note:

Ambient conditions
Rated temperature range
Storage temperature range

Unless otherwise specified, all values
applicable to continuous sweep with coupled
functions in default coupling and calibrated;
based on IEC 714
to IEC 359, class I
0 to +55°C
-40 to +70°C;
the unit contains a lithium battery for buffer-
ing the CMOS RAMs. The battery capacity
and service life will be considerably reduced
at low or high temperatures, respectively.

Error of real-time clock
Max. relative humidity
EMC

≤ 2 min in 24 hours
20 to 90% (without condensation)
VDE 0871, limit class B;
postal regulation 526/527.79;
CISPR publication 11, 22;
FCC DOC 20780: Part 15, Subpart 5

Warmup period (0 to 55°C),
time required for attaining operating
temperature after cold start
Internal thermal equilibrium
(at constant outside temperature)
Power supply

1 h
4 hours
100/120/220/240 V $\pm 10\%$,
47 to 440 Hz (500 VA),
safety class I (to IEC 348 and VDE 0411)
435 mm x 413 mm x 590 mm
58 kg

Dimensions (W x H x D)
Weight

ORDERING DETAILS

Order designation

Spectrum Analyzer FSB
848.0020.52

Accessories supplied

Power cables (2 of), connection cables (2 of), manual

Recommended extras

Service Kit	FS-Z1	811.0010.02
Connection Cable Set (for servicing, 1 m)	FS-Z2	811.0304.02
Filter Element	FS-Z3	805.7900.02
Software for Computer Function	FS-K1	811.0610.02
Computer function (FS-K1 + PCA-Z1 + LAS-Z11)	FS-Z4	811.0810.02
Keyboard	PCA-Z1	375.7511.02
Floppy Disk Station	LAS-Z11	357.4014.02
Plotter	DOP	375.1213.02
24-pin Printer	PDN	351.4512.02
220 V	PDN	351.4512.03
117 V	PDN-B3	351.4912.02
Colour option	PCK	292.2013.10
IEC-bus Cable (1 m)	ZZA-94	396.4905.00
19" Adapter	ZZA-95	396.4911.00

Accessories for current, voltage and
field strength measurements

see accessories for Test Receivers ESH 2/ESH 3
(Data sheet 303 203) and ESV/ESVP
(Data sheet 342 403)



at a relative humidity
of >50%
Calibrated

Selection

Shape factor
-60 dB/-3 dB
-80 dB/-3 dB

Video filter

Bandwidths (-3 dB)
Error (VBW = 1 Hz to 1 MHz)
Selection

AMPLITUDE

Amplitude range

(at RBW of 10 Hz)

Maximum input power

DC

AC

Max. pulse spectral density

Max. pulse energy ($\tau = 10 \mu\text{s}$)

RF attenuation ≥ 10 dB

Max. pulse voltage

Level compression

RF level at input mixer

(measured at 21.4-MHz IF output)

$f \leq 36$ MHz; ≤ -15 dBm

$f > 36$ MHz; ≤ -10 dBm

Displayed inherent noise level

RF attenuation 0 dB, RBW 10 Hz,

VBW 1 Hz

200 Hz $\leq f < 1$ kHz

1 kHz $\leq f < 10$ kHz

10 kHz $\leq f < 100$ kHz

100 kHz $\leq f < 1$ MHz

1 MHz $\leq f < 40$ MHz

40 MHz $\leq f < 4.8$ GHz

4.8 GHz $\leq f < 5.0$ GHz

Indication of measured value

Measurement ranges

Resolution

Markers

Display

110 dB

other

A/D converter

Setting range

of reference level

LOG scale

LIN scale

Resolution

Keyboard, spinwheel

Step keys

LIN, 100 dB, 110 dB

other

Measurement error

Internal calibration source

(CAL OUTPUT)

Level

Frequency

RF frequency response

(RF attenuation = 10 dB

and DC coupling, ref. to 100 MHz)

$< \pm 30\%$

$< \pm 10\%$ (RBW ≥ 10 Hz),

$< \pm 1.5$ Hz (RBW < 10 Hz)

with step keys in increments of 1/3/10 and
with spinwheel and keyboard in increments of
typ. 5% (except from 30 to 80 kHz)

< 12

< 20

1st-order RC lowpass filter following

IF rectifier

1 Hz to 3 MHz

$\pm 20\%$

in increments of 1/3/10

< -140 to $+30$ dBm

0 V with DC coupling,

± 20 V with AC coupling

$+30$ dBm (RF attenuation ≥ 10 dB),

otherwise $+20$ dBm

61 dB $\mu\text{V}/\text{MHz}$

(RF attenuation > 10 dB)

1 mW/s

150 V

< 1 dB

< 1 dB

spurious excepted

< -85 dBm

< -105 dBm

< -110 dBm

< -115 dBm

< -130 dBm

< -140 dBm

< -137 dBm

internal electronic graticule with 11 to 13
(horizontal) level lines (top line corresp. to
reference level)

linear or logarithmic

110/100/50/20/10/1 dB

measurement range/4096, min. 0.01 dB

352 steps (341 for log. frequency axis)

360 steps (340 for log. frequency axis)

12 bits

the reference level can be set and measured
values displayed in all common units. A level
offset of -116 to $+120$ dB can be selected.

-90 to $+30$ dBm

-130 to $+30$ dBm

0.1 dB

10 dB

0.1 x measurement range

-20 dBm ± 0.2 dB

100 MHz $\pm 10^5$ x R.A.

$< \pm 1.0$ dB

Level drift

typ. < 0.10 dB/ $^{\circ}\text{C}$

(RF attenuation 10 dB, RBW 3 kHz, reference
level -20 dBm). The effect of this error can be
avoided by calibration.

Resolution bandwidth switching

Reference bandwidth = 3 kHz

(applicable for RBW < 10 Hz

and ambient temperature

$+20$ to $+30$ $^{\circ}\text{C}$)

Uncalibrated

Calibrated

RBW ≥ 10 Hz

RBW < 10 Hz

IF gain switching

referred to ref. level -20 dBm

(RF attenuation 10 dB;

RBW ≥ 10 Hz, $f > 40$ MHz)

Ref. level 0 to -60 dBm

Ref. level -60.1 to -120 dBm ..

$+2$ dB, -3 dB

$< \pm 0.3$ dB

$< \pm 1$ dB

without

$< \pm 1$ dB

$< \pm 2$ dB

$< \pm 1$ dB,

typ. $< \pm 0.4$ dB

$< \pm 1.3$ dB,

typ. $< \pm 0.6$ dB

RF attenuator

Adjustable in range from

0 to 81 dB in increments of;

Keyboard, spinwheel

Step keys

$f < 2$ GHz

Error per 5-dB increment

Total error

Max.

$f \geq 2$ GHz

Error per 5-dB increment

Total error

Max.

1 dB

5 dB

$< \pm 0.2$ dB

$\pm (0.3 + 1.3\%$ of attenuation) dB

1 dB

$< \pm 0.5$ dB

$\pm (0.5 + 2.5\%$ of attenuation) dB

2 dB

The data on the total error apply to attenuation values deviating from the basic 10-dB
setting, taking into consideration the frequency-dependent transmission loss incorporated
in the calibration at the 10-dB setting.

AC/DC switching of input coupling

RF attenuation ≥ 10 dB,

$f_{in} > 1$ MHz

Measurement range switching

LOG 110/100/50/20/10 dB

LOG $\leftrightarrow$ LIN/LOG 1 dB

Uncalibrated

Calibrated

Scaling

LOG scale (reference;

10 dB below ref. level)

Display

0 to -20 dB

RBW ≥ 30 Hz

RBW ≥ 10 Hz

RBW < 10 Hz

-20 to -90 dB

Total error 0 to -100 dB

LIN scale

RBW ≥ 10 Hz

RBW < 10 Hz

Error of calibration routine

$< \pm 0.5$ dB

referred to LOG 100 dB at ref. level

± 0.2 dB

$< \pm 1$ dB

$< \pm 0.2$ dB

$< \pm 0.1$ dB/dB

$< \pm 0.2$ dB/dB

$< \pm 0.5$ dB/dB

$< \pm 0.2$ dB/dB

$< \pm 1.5$ dB

$< \pm 5\%$ of ref. level

$< \pm 10\%$ of ref. level

$< \pm 0.2$ dB

Spurious responses

Internal (without input signal)

Input terminated with 50Ω ,

RF attenuation 0 dB

LO level at $f = 0$ Hz

Second-order harmonic distortion,

mixer level ≤ -30 dBm,

RF attenuation ≥ 10 dB

$f < 40$ MHz

$f \geq 40$ MHz

Third-order intermodulation

distortion ($\Delta f > 100$ kHz),

mixer level ≤ -30 dBm,

RF attenuation ≥ 10 dB

$f < 40$ MHz

$f \geq 40$ MHz

< -110 dBm

< -15 dBm

< -60 dBc $\rightarrow$ HSOI $\geq +30$ dBm

(HSOI = Harmonic Second Order

Intercept Point)

< -70 dBc $\rightarrow$ HSOI $\geq +40$ dBm

< -70 dBc $\rightarrow$ TOI $> +5$ dBm

(TOI = Third Order Intercept Point)

< -75 dBc $\rightarrow$ TOI $> +7$ dBm;

Other

Mixer level ≤ -40 dBm,
RF attenuation ≥ 10 dB

$f < 40$ MHz ≤ -70 dBc
 $f \geq 40$ MHz ≤ -75 dBc

Immunity to interference

Image frequency rejection
 $f_{in} + (2 \cdot 5421.4 \text{ MHz})$ referred to reference level
 $f_{in} + 442.8 \text{ MHz}$ > 80 dB, typ. 90 dB
 $f_{in} + 42.8 \text{ MHz}$ > 100 dB, typ. 115 dB
 $f_{in} + 8.388 \text{ MHz}$ > 100 dB, typ. 115 dB
IF rejection referred to reference level
221.4 MHz > 100 dB, typ. 110 dB
21.4 MHz > 100 dB, typ. 110 dB
4.194 MHz > 100 dB, typ. 110 dB

SWEEP

Sweep time

Span > 0 Hz

Setting ranges

20 ms to 2 s
2 to 20 s
20 to 1980 s

Error

Span = 0 Hz

Setting ranges

200 μ s to 10 ms
20 ms to 1980 s

Error

200 μ s to 10 ms
20 ms to 1980 s

Sampling rate

Time measurement

Resolution

Sweep mode

Trigger

Operating modes

Voltage range

Trigger threshold resolution

Step size

20 ms
200 ms
2 s
 $\leq \pm 10^{-3}$

Step size

1/2/4/8/10
see span > 0 Hz

$\leq \pm 1\%$
 $\leq \pm 10^{-3}$
1/8.9 μ s
with the aid of markers and cursor lines
sweep time/900

repetitive/single

free run,
line,
video,
external
 ± 5 V with external trigger
64 steps

DEMODULATION

Receiver mode
Display of demodulated signal

Marker function for measuring

Resolution

AM 0.1%
FM frequency span range/4096
Time sweep time/900

FM demodulator

Centre frequency offset
after AF calibration
(AF calibration not before
5 minutes after FM demodulation
is switched on)

FM deviation

2 kHz, 20 kHz, 200 kHz
200 kHz

Drift at constant ambient
temperature after 1-hour
warmup

FM deviation display error

Deviation 2 kHz, 20 kHz, 200 kHz
Modulation frequency
100 Hz to 5 kHz
DC to 15 kHz

FM linearity error

(deviation < 20 kHz,
modulation frequency < 5 kHz)

demodulation of received RF signal
vertically on a 10-line graticule as a function
of horizontal time base
modulation depth in %,
frequency deviation,
centre frequency deviation

0.1%
frequency span range/4096
sweep time/900

values applicable to signal levels 0 to -30 dB
below ref. level; VBW 10 kHz;
S/N ratio > 40 dB

$< 2\%$ of deviation
 < 40 Hz

< 10 Hz/min

$< 3\%$ of measured value
 $< 5\%$ of measured value

$< 1\%$

Residual FM (PP/2),
averaged over 5 sweeps
Synchronous FM at 50% AM,
modulation frequency 1 kHz,
VBW 3 kHz

< 20 Hz

< 500 Hz, typ. < 100 Hz

AM demodulator

Centre deviation of
unmodulated signal
Measurement range
100% AM
10% AM
Error of displayed mod. depth,
AM $< 80\%$ (plus residual AM),
mod. frequency 0.4 to 10 kHz

values applicable to signal levels -6 to -35 dB
below reference level

$< 2\%$ of fs
 $< 5\%$ of fs

$< 6\%$ of measured value
(with measurement range
10% AM $< 8\%$ of measured value)

Residual AM

PP/2
weighted to CCITT
(VBW 3 kHz, RBW 30 kHz,
averaged over 5 sweeps)
Synchronous AM, RBW 3 MHz,
FM deviation 50 kHz,
modulation frequency 1 kHz

$< 1\%$

typ. $< 0.1\%$

$< 3\%$

VDU

Monitor

Useful area
Brightness
Colours
Number of display memories
X resolution (electrical)
Y resolution (electrical)
Scaling

9" in line colour CRT
with 0.29-mm shadow mask pitch
157 mm x 118 mm
adjustable in 64 steps
selectable (16 from 4096)
4
1024 points
512 points
electronically superimposed,
calibrated graticule
alphanumeric display of essential parameters
as well as hints in English
R&S: Plotter DOP; HP-GL
curve arithmetic (exchange, subtract),
comparison with tolerance curves,
averaging,
peak hold
reference marker + delta marker
+ 6 multimarkers
signal track, marker to peak, marker to ref.
level, marker to centre freq. step size, marker
to center, marker to start/stop freq., marker to
peak/next peak/min/next min, marker zoom,
noise marker with normalization in dBm/Hz,
delta marker to span, delta marker with noise
normalization in dB (Hz), N dB down, shape
factor measurement 60/3 dB and 60/6 dB,
multimarker peak search, multimarker set/
clear/clear all, marker to next/previous multi-
marker;
receiver mode: delta marker
(measurement of modulation depth, frequency
deviation and offset)

Additional information

Output to plotter
Functions

Markers

Functions

INPUTS AND OUTPUTS

Front panel, RF section

RF INPUT 50 Ω
(100 Hz to 5.0 GHz)
Impedance
VSWR
RF attenuation = 0 dB
RF attenuation ≥ 10 dB

N female
50 Ω
 $f \leq 2.7$ GHz $f > 2.7$ GHz
 ≤ 3.0 ≤ 3.0
 ≤ 1.5 ≤ 1.8

CAL OUTPUT
(100 MHz, -20 dBm)
Impedance
VSWR
PROBE/CODE
(supply and coding connector,
e.g. for active or passive probes
and antennas)
Supply voltage

BNC female
50 Ω
 < 1.1

12-contact Tuchel female
 $+10$ V, max. 100 mA,
 -10 V, max. 100 mA

Front panel, display section

PHONES
Frequency range (-3 dB)
EMF

JK 34 jack
100 Hz to 15 kHz
 10 V_{pp}



ROHDE & SCHWARZ

GmbH & Co. KG

Mühlendorfstr. 15

D-8000 Munich 80

Telephone (089) 4129-0

Telefax (089) 4129-2164

Telex 5 23 703

Printed in the Fed. Rep. of Germany

Subject to change

Data without tolerances; order of magnitude only

